



# ScratchClient



Gerhard Hepp

---

## ScratchClient:



Gerhard Hepp

Publication date 2018-11-15

---

1. Summary .....	1
2. Introduction .....	2
3. Architecture .....	3
3.1. Architectural Decisions .....	4
4. Scratch remote sensor protocol .....	5
5. Configuration .....	6
5.1. Config file Syntax .....	6
5.2. GPIO Output .....	6
5.3. Inputs, outputs and scratch names. ....	6
5.4. Other features: parameters .....	8
5.5. Other features: webserver websocket plugin, html plugin .....	8
5.6. Adapter lifecycle .....	8
6. Adapter Types .....	10
6.1. GPIO Adapter .....	10
6.1.1. GPIO Adapter, input .....	10
6.1.2. GPIO Adapter, output .....	10
6.1.3. GPIO Adapter, output for PWM controlled Motor .....	10
6.1.4. GPIO Adapter, output for Servo motors .....	11
6.1.5. GPIO Adapter, output for Stepper motors .....	11
6.1.6. GPIO Adapter, various Adapters using multiple GPIO .....	11
6.1.7. Telephone Dial Plate Adapter .....	12
6.1.8. GPIO HCSR04 connected with one wire .....	12
6.2. SPI based Adapter .....	13
6.2.1. MAX31855 Thermocouple .....	13
6.2.2. MCP23S17 16-Bit IO Expander; PIFACE board .....	13
6.2.3. ADC MCP3202 .....	15
6.2.4. ADC MCP3008 .....	15
6.2.5. WS2801 LED Stripe .....	15
6.3. I2C-Adapters .....	16
6.3.1. ADS1015 ADC Converter .....	16
6.3.2. BH1750 Luminosity Sensor .....	16
6.3.3. BMP085 barometric pressure sensor .....	16
6.3.4. MPR121 Touch Controller .....	16
6.3.5. PCF8591 4 channel ADC and DAC .....	17
6.3.6. PCA9685 16-channel, 12-bit PWM LED controller .....	17
6.3.7. SN3218 LED controller, piGlow board .....	18
6.4. GPIO Wire adapter, w1-gpio .....	18
6.4.1. GPIO Wire adapter, DS1820 .....	18
6.5. Remote Communications .....	18
6.5.1. MQTT-Adapter .....	19
6.5.2. Remote Communications Adapter with scratchCommunicationsServer .....	20
6.5.3. Sonic Pi-Adapter .....	23
6.6. Scratch related Adapters .....	23
6.6.1. Broadcast Adapter .....	23
6.7. Operation System Adapters .....	24
6.7.1. Text To Speech Adapter .....	24
6.7.2. System Time Adapter .....	24
6.7.3. Operating system commands .....	24
6.7.4. Linux 'aplay' adapter .....	24
6.7.5. Linux 'arecord' adapter .....	25
6.7.6. Linux speech recognition adapter .....	25
6.7.7. Linux lirc Adapter .....	27
6.8. Adapters for special purpose Devices .....	30
6.8.1. Atmel atmega328 with custom firmware as ADC .....	30
6.8.2. Atmel atmega328 with custom firmware as frequency counter .....	30
6.8.3. Atmel atmega328 with custom firmware for DHT22, DHT11 .....	30
6.8.4. Test Adapter .....	31
6.8.5. Servoblaster .....	31
6.8.6. Raspberry Pi DMA Adapter RPIO2 .....	32
6.8.7. Raspberry Pi SenseHat .....	32
6.8.8. Pimoroni PianoHat .....	33
6.8.9. Smartphone positional sensor for scratch .....	33
6.8.10. USB barcode scanner .....	34
6.8.11. USB blink(1) .....	35
6.8.12. Adapter for SIM800 GSM Modem, SMS support .....	36
6.8.13. RFID Adapter .....	36
6.8.14. ScratchBoard, PicoBoard Adapter .....	36
6.8.15. GPS Adapter GY-GPS6MV2 .....	38
6.8.16. Arduino UNO Adapter .....	38
6.8.17. Arduino UNO Adapter for Neopixel .....	43
6.8.18. Arduino UNO_POWERFUNCTIONS_Adapter .....	44
6.8.19. Twitter_Adapter .....	46

6.8.20. Openweathermap_Adapter .....	46
6.8.21. LEGO WeDo 2.0 Adapter .....	47
6.9. Adapters using pigpiod-Daemon .....	54
6.9.1. Ultrasonic Distance Sensor HC-SR04 by pigpiod-Daemon .....	54
6.10. Pimoroni MICRO DOT PHAT board .....	54
6.11. Pimoroni SCROLL PHAT HD board .....	55
6.12. Minecraft on PI adapter .....	56
7. Configurations for Devices .....	57
7.1. Two wheel robot 'pi2go' .....	57
7.2. ExplorerHatPro .....	57
8. GUI, Web Interface for Monitoring .....	58
8.1. GUI Functions .....	58
8.1.1. Monitoring, Controlling .....	58
8.2. Compatibility .....	59
9. Installation, Operation .....	60
9.1. Quick Installation .....	60
9.2. Step by Step Installation .....	60
9.2.1. Base Packages Installation .....	60
9.2.2. ScratchClient Software Installation .....	60
9.2.3. SPI install .....	60
9.2.4. I2C install .....	61
9.2.5. Text to speech install .....	61
9.2.6. DMA library support (RPIO2) .....	62
9.3. Custom config files .....	62
9.4. Start scratchClient .....	62
9.5. Application Logging .....	63
9.5.1. Logging into Linux desktop notifications. ....	64
9.6. Stop scratchClient .....	64
9.7. Problems running scratchClient .....	65
9.7.1. Multiple Instances running .....	65
9.7.2. Installation Problems .....	65
9.8. Scratch Autostart .....	65
9.8.1. Start scratch into presentation mode .....	65
9.8.2. Enable remote connection (without user interaction) .....	65
9.8.3. Green Flag Event .....	66
9.9. scratchClient usage scenario .....	66
9.9.1. Local setup .....	66
9.9.2. Distributed setup A .....	66
9.9.3. Distributed setup B .....	67
10. Extending Functionality .....	68
10.1. Hacking the code .....	68
10.2. GPIO Names .....	68
10.3. Python Compatibility .....	68
10.4. License .....	68
11. Adapter Documentation .....	70
11.1. ADC_ADS1015_Input .....	70
11.2. ADC_DAC_PCF8591 .....	70
11.3. ADC_MCP3008_10_Input .....	71
11.4. ADC_MCP3202_10_Input .....	72
11.5. ADC_MCP3202_10_Zone_Input .....	72
11.6. ADC_MCP3202_12_Input .....	73
11.7. BipolarStepper .....	74
11.8. Blink_Adapter .....	75
11.9. CAP1208Adapter .....	75
11.10. CommunicationAdapter .....	77
11.11. DMA_PWM .....	78
11.12. DMA_PWM_ON_OFF .....	78
11.13. DMA_PWMServo .....	79
11.14. Festival_Adapter .....	79
11.15. Gpio_HCSR04_OnePin_Input .....	80
11.16. Gpio7segment .....	81
11.17. GpioButtonInput .....	82
11.18. GPIODialPlateEncoder .....	83
11.19. GPIOEncoder .....	83
11.20. GpioEventInput .....	84
11.21. GpioInput .....	84
11.22. GpioMotorPWM .....	85
11.23. GpioOutput .....	86
11.24. GpioOutputPWM .....	86
11.25. GpioOutputPWM_ON_OFF .....	87
11.26. GpioOutputPWMServo .....	87
11.27. GpioStateOutput .....	88

---

11.28. GpioValueInput .....	89
11.29. GpioValueOutput .....	89
11.30. GY_GPS6MV2 .....	90
11.31. HC_SR04_Adapter .....	91
11.32. HIDScanner_Adapter .....	91
11.33. IRODistanceInput .....	92
11.34. Linux_Adapter .....	93
11.35. Linux_APLAY_Adapter .....	93
11.36. Linux_ARECORD_Adapter .....	94
11.37. Linux_ASR_Adapter .....	94
11.38. LIRC_Adapter .....	95
11.39. Luminosity_BH1750_Input .....	96
11.40. MAX31855_Adapter .....	97
11.41. MCP23S17_Adapter .....	97
11.42. Microdot_Adapter .....	99
11.43. MinecraftAdapter .....	100
11.44. MQTT_Adapter .....	101
11.45. NEOPIXEL_Adapter .....	102
11.46. Openweathermap_Adapter .....	103
11.47. PianoHat_CAP1188_Adapter .....	104
11.48. Pico2Wave_Adapter .....	106
11.49. PicoBoard_Adapter .....	106
11.50. Pigpiod_DHT11_Adapter .....	108
11.51. Pigpiod_PWM_Adapter .....	108
11.52. Pressure_BMP085_Input .....	109
11.53. PWM_PCA9685 .....	109
11.54. PWM_SN3218 .....	112
11.55. RFID_Reader_Adapter .....	115
11.56. ScratchStartClickedAdapter .....	116
11.57. ScrollPhatHd_Adapter .....	116
11.58. SenseHat_Adapter .....	117
11.59. ServoBlaster .....	119
11.60. SonicPi_Adapter .....	120
11.61. TimeAdapter .....	121
11.62. Touch_MPR121 .....	121
11.63. Twitter_Adapter .....	123
11.64. UnipolarStepperModule .....	124
11.65. UnipolarStepperStep .....	125
11.66. UNO_Adapter .....	126
11.67. UNO_POWERFUNCTIONS_Adapter .....	127
11.68. W1_DS1820 .....	129
11.69. WebsocketXY_Adapter .....	129
11.70. Wire_SHTx .....	130
11.71. WS2801_Adapter .....	131
11.72. Adapter Data Types .....	131
12. Index .....	133
13. References .....	138

---

## Chapter 1. Summary

This document describes software connecting scratch to hardware on Raspberry Pi.

The goal is to have a flexible approach where hardware setup is basically configured instead of programmed.

There are ready to use adapters for basic IO capabilities, as buttons, switches, stepper driver, photointerrupters, PWM-driving outputs. SPI based devices are available for ADC, DAC and LED-Stripes.

Functionality is not only limited to hardware IO. Other examples are a Text to Speech interface or remote scratch-to-scratch-connection.


---

## Chapter 2. Introduction

Scratch does not allow direct interfacing to hardware.

For scratch version 1.4, as available on RaspberryPi raspbian, the 'Remote Sensor Protocol' allows to attach external processes which then interface to hardware.

When activated, scratch acts as a server on socket port 42001 and clients can connect to this socket.



The 'Remote Sensor Protocol' is described in /rsp/. It is not limited to sensors, but can also be used for controlling actors, write to files and many more functionalities.

Clients do not need to be located on the same computer with scratch, but could also be remote on a network.

The sensor protocol is generally usable on different computer platforms, and not limited to Raspberry Pi. The Raspberry Pi offers easy to be attached GPIO (general purpose Input Output), which leads to simple and low cost implementations in controlling hardware.

The data exchange are

- broadcast events from scratch to client. Broadcasts are used for simple commands like 'start' or 'stop'.
- sensor-updates from scratch to client. Sensor-updates are similar to broadcasts, but carry an additional value.
- sensor-updates from client to server
- broadcast events from client to scratch.

Sensor-updates are used to carry additional values like voltage measurements, speed values, or pin state like '0' or '1'.

There are some client implementations available for this protocol. See /simon/ and /silent/, there are many if you search the net.

For an afterschool workshop for 7th class programming novices, I needed a flexible approach to have hardware attached to scratch. The available implementations are either too specialized or lack some flexibility in configuration.

The code provided here is partially based on code from /simon/, which was basically reorganized, modularized and extended.


The implementation has the following goals:

- Modularization of Software (server connection, data model, configuration, monitoring)
- Configuration in XML for various adapter-settings; versioning of config files.
- html based GUI for monitoring and simulation, also providing some documentation on the current configuration.
- dynamic mapping of broadcast names and variable names to the scratch world
- internal GPIO-Numbering is BCM style. Configuration allows for BCM, board or other names.
- Till 2015-01-02, there was a feature to use different GPIO-libraries. This was removed, as RPIO did no longer support Pi2-hardware, and as software was too complex by this feature. A local patch to RPIO, named 'RPIO2', is used instead.

Performance was not a primary goal. If you need to squeeze out a few cpu-cycles, then head for a C++ based implementation.

The scratchClient is designed to run on Raspberry Pi, raspbian. Scratch will in general run on the same machine, although it could run on other platforms too.

## Chapter 3. Architecture



Building blocks of scratchClient

**Configuration manager.** Reads config file, instantiates adapters and populates the logic to internal names conversion tables.

**Logic names to internal names.** Scratch is working with 'logic' or business related names. Examples are 'light on', 'distance Y' or 'red button pressed'. These are mapped to internal technical names.

**Connect/reconnect logic.** Connecting to scratch, reconnecting if needed.

**Web app server.** Provides view of configuration; monitoring, controlling the adapters.

**Event distribution.** Scratch signals, signals from/to web app and signals from the adapters need to be distributed between the objects inside the scratchClient.

**SpiManager, i2cManager, gpiomanager.** These modules manage the access to the Rpi resources; 'device handlers' to handle popular devices.

**And adapters.** These are the main building blocks, encapsulating the business logic. An adapter is a module, which performs a dedicated operation like a button-adapter, a relais adapter or a stepper.

Scratch applications typically will not use a large number of adapters. My typical applications use up to 10 GPIO pins and one or two adc channels. This yields to 10, possibly 20 adapters involved.

Basically, adapters have a high level command input interface like 'on' or 'off' for a relais, or value inputs like 'direction left/right' or 'speed 2.32' for a stepper control. Adapters can provide value output, as a switch-adapter (state=on/off) does or an AD-Converter. An adapter can use multiple inputs, values and outputs.

Configuration parameters are inputs only used during initialization by the ConfigurationManager. These values are immutable during runtime.

TODO: image of adapter with data flow, life cycle.

The adapters are designed with reuse in mind. If you reuse an adapter, you need to map the inputs or outputs to different commands or variables in scratch. This mapping is done by configuration.

The names in the broadcasts from scratch and the names in the sensor-updates are mapped to the names the adapters are using. These mappings are defined by configuration.

GPIO are assigned to the adapters by configuration. One GPIO pin can only be assigned to one adapter. The configuration checks for correct assignment of GPIO, which means that pins are not double used or not existing pin numbers are assigned.

Adapters do not directly control the GPIO, there is a GPIOManager which controls GPIO. This construction was chosen to allow for different GPIO implementing libraries, which imposes the need of modularization.

Adapters are not limited to GPIO input or output. Serial line or SPI, network connections, file access and others are possible. Aside from this, gpio-in/output will be the primary purpose for most projects.



### 3.1. Architectural Decisions

Programming language is python. Although the complexity would require programming techniques as static types, interfaces, enumerations and private fields, python is easy to learn and is widely adopted in the Raspberry-Community.

GUI is web based. As the client could be run in background, web based access is quite easy to use. Cherrypy with mako templates are used to implement the server side. On the fly graphics are svg-based. Event notifications are used to update the web client. This technique is supported by midori, epiphany and most browsers (not IE).

Configuration files are XML Widely adopted in industry, easy to read, can be automatically formatted. Allows inline comments.

Configuration files are versioned. Versioning allows to implement backward compatibility through releases.

GPIO names are BCM internal GPIO-scheme. External names are mapped to internal numbers, allowing for flexibility. This mapping is configurable.

---

## Chapter 4. Scratch remote sensor protocol

When 'remote sensor connections' in scratch are enabled, scratch opens a port 42001 and waits for clients to connect. Connections are made by tcp-sockets. Communication packets start with 4 byte binary length information (MSB first) and then plain data string. Length is length of data string only.

Scratch sends:

- broadcast [name] whenever scratch issues a broadcast [name] or broadcast [name] and wait
- sensor-update "[name]" [value] sensor-update "[name]" "[value]" on communication startup once for each 'global variable' (defined for all sprites); whenever a 'global variable' is changing. Numeric values are transmitted without the double quotes around the value. String values are quoted. Names or values containing quotes result in two consecutive quotes.

Scratch receives

- broadcast [name] in scratch, you can react on this with 'when I receive [name]'
- sensor-update "[name]" [value] this is accessible from the sensor values in 'sensing'

List variables in scratch are not sent to client. Values are 'text encoded', so integers, floats are transmitted not in binary, but in their string format. String values are double quoted and in utf-8 charset.

---

## Chapter 5. Configuration

Configuration for the adapter definitions is provided by xml-Files. Default config file is 'config.xml', but name of the file can be set by command line. Online configuration change is NOT possible. Usual procedure is to stop the client, do some wiring on the hardware and restart client.

### 5.1. Config file Syntax

Basic frame for all configurations is the xml-preamble and the config tag.

```
<?xml version='1.0' encoding='utf-8' ?>
<config version='1.0'>
  <description>Basic empty configuration</description>
</config>
```

The config-tag is the 'frame' for more content. The description-tag contains some information about the project, purpose or whatever else might be needed to clearly identify the target system purpose of configuration.

In the samples in ./config, there are schema references for validation purposes. When the data are read by scratchClient, no validation is used (but they need to be xml-compliant).



Feel free to add xml-comments `<!-- comment -->` wherever you want to have more information.

### 5.2. GPIO Output

```
<?xml version='1.0' encoding='utf-8' ?>
<config version='1.0'>
  <description>Sample configuration</description>

  <adapter class='adapter.gpio.GpioOutput' name='relais'>
    <description>Sample GPIO, here assumed to be a relais output</description>

    <gpio port='GPIO25'>
      <default dir='OUT' pull='PUD_OFF' default='low' />
      <active dir='OUT' pull='PUD_OFF' default='low' />
    </gpio>

    <input name='low'>
      <broadcast name='pin25low' />
      <broadcast name='pin10off' />
    </input>
    <input name='high'>
      <broadcast name='pin25high' />
      <broadcast name='relaisOn' />
    </input>
  </adapter>
</config>
```

The `<adapter/>` tag has the attributes

@class: python class name of the implementing code, mandatory

@name: a short name, identifying this adapter. Name is mandatory, needs to be unique in the configuration.

The `<adapter/>` tag has the child elements `<description/>` a description for the adapter, purpose, technical details or alike. `<gpio/>` each port pin adapter is using is listed here. Here, GPIO10 (this numbering is always BCM-related) is used, configured as an output. More on this later. `<input/>` Each input of an adapter needs a separate `<input/>` tag (when used, not used inputs do not need to be listed). The @name-Attribute is mandatory and corresponds to the method name of the adapter code.

`<gpio/>` uses elements `<active/>` and `<default/>`.

Active is the initial state the code sets the pin when initiated. Default is the state the code leaves the pin when the code is gracefully shut down. This is done by pressing ctrl-C in console, or sending SIGINT in linux.

### 5.3. Inputs, outputs and scratch names.

The inputs an adapter exposes are mapped to broadcast events from scratch. These mappings are provided by `<broadcast@name/>` -Tags inside the input. The @name of the `<broadcast/>` is used as 'text' in the scratch broadcast blocks. In most cases, there will be only one command element, as the purpose is pretty clear.

The `<broadcast@name/>` can occur multiple times in one `<config/>` file, triggering multiple adapters by one broadcast from scratch. This feature can be used for a 'startAll' or 'stopAll'-feature for some adapters.

The broadcast names will be in most projects logical names, like 'relaisOn', 'led\_green\_off'.

The names are case sensitive, so 'relaisOn' and 'RelaisOn' are different. Be sure to use exactly the same spelling on scratch and adapter side, otherwise commands are discarded. At runtime, information on mapping of scratch broadcasts to adapters is printed to the console when the '-v', the verbose switch in the command line is applied.

The configuration class in the system checks for errors in the configuration and will provide (hopefully) meaningful hints on how to correct problems.

The following 'stepper' example shows some advanced features.

```
<adapter class='adapter.stepper.Stepper' name='x-direction' >

  <description>Stepper class uses w0 for coil 0,
    w1 for coil 1 etc</description>

  <gpio port = 'GPIO14' alias='w0' >
    <default dir='OUT' pull='PUD_OFF' default='low' />
    <active dir='OUT' pull='PUD_OFF' default='high' />
  </gpio>
  <gpio port = 'GPIO15' alias='w1' >
    <default dir='OUT' pull='PUD_OFF' default='low' />
    <active dir='OUT' pull='PUD_OFF' default='high' />
  </gpio>
  <gpio port = 'GPIO17' alias='w2' >
    <default dir='OUT' pull='PUD_OFF' default='low' />
    <active dir='OUT' pull='PUD_OFF' default='high' />
  </gpio>
  <gpio port = 'GPIO18' alias='w3' >
    <default dir='OUT' pull='PUD_OFF' default='low' />
    <active dir='OUT' pull='PUD_OFF' default='high' />
  </gpio>

  <input name='start'>
    <broadcast name='startA' />
  </input>
  <input name='stop'>
    <broadcast name='stopA' />
  </input>
  <input_value name='speed'>
    <variable name='speedA' />
    <variable name='speed' />
  </value>
</adapter>
```

As the adapter uses four GPIO Pins, these `<gpio/>` -tags get an @alias-attribute to assign these pins to functionality inside the adapter.stepper.Stepper-class.

The `<input/>` tags are pretty clear, the `<value/>` -tag is providing configuration for values beeing sent from scratch to the adapter. In scratch 1.4, global variables are sent to the adapters. These names are defined with `<variable />` tags similiar to inputs.

Adapters with output values (which should be transmitted to scratch) are using the `<output_value/>` -tag. A button sample is:

```
<adapter class='adapter.gpio.GpioInput' name='button 22'>
  <!-- no description, urgg -->
  <gpio port = 'GPIO22'>
    <default dir='IN' pull='PUD_OFF' />
    <active dir='IN' pull='PUD_OFF' />
  </gpio>
  <output_value name='button'>
    <sensor name='button22' />
  </output>

  <parameter name='poll.interval' value='0.5' />

</adapter>
```

The `<output/>` tag maps a logical name to a scratch sensor-update-name, here 'button22'. Here a 1-1 relation between output and command is assumed, as it is not useful to send one value to different variables in scratch.

## 5.4. Other features: parameters

Adapter can have parameter-tags, specifying constant config values. These are adapter specific, see adapter docs on which ones are needed and what default values are.

```
<parameter name='poll.interval' value='0.5' />
```

## 5.5. Other features: webserver websocket plugin, html plugin

For one of the adapters (websocket), there was the need to have the embedded webserver to support custom websocket code and html pages.

To make this flexible, a plugin mechanism was implemented.

```
<webserver>
  <!-- implement a web page -->
  <route name='pendel' route='/adapter/pendel' />
  <html name='pendel'
    path='websocket/pendel.html'
    comment='positional sensor from a smartphone' />
</webserver>
```

Tag `<webserver/>` groups the entries.

Tag `<route/>` defines the absolute path for the webapplication server to the websocket.

Tag `route/@name` a descriptive name

Tag `route/@route` an absolute path for the entry point of the websocket

The websocket protocol class is provided by the adapter and does not need configuration.

Tag `<html/>` defines the location of additional web pages. Links to these pages are added to main page.

Tag `html/@name` a descriptive name

Tag `html/@path` a relative path for the page. Place these pages to `htdocs/static/html/..`

Tag `html/@comment` a descriptive comment. May be empty.

The needed html pages are to be placed in `htdocs/static/html/[html@path]`.



This is the 'injected' web link to the main page.

## 5.6. Adapter lifecycle

Adapters get created (instantiated) by the configuration manager when reading the xml-file. When no errors occur, the configManager keeps the instance in a list of adapters for later reference.

Then parameters are set.

Adapters are started one after the other by `setActive (True)`. There is no particular order within the adapters to get this event.



If your application needs adapter 'A' to be started after 'B', then most possibly you need a special implementation 'AB' which combines the two.

When set to active, adapters should start regular work. This means to setup the GPIO, starting threads and whatever else might be needed. Setting the GPIO can be done by using the base adapter class' methods.

Adapters stop operation by `setActive(False)`. Then threads should be stopped in a timely manner (less than 0.1 sec), and GPIO should be reset to default state. The adapters base class provides mechanisms to setup GPIO. These can be overwritten to achieve other behaviour.

There is no live after `setActive(False)`. The adapters will be destroyed later and the code stops to work.

CPU load Adapters should not poll and send values too often. Faster than some 20 to 50 updates per second are a challenge for the system, as the socket connection and also scratch on the receiving end needs cpu-cycles to perform work. Currently, each sensor-update is send separately.

---

## Chapter 6. Adapter Types

### 6.1. GPIO Adapter

For the GPIO-Types, different libraries can be used: RPi.GPIO (default) or RPIO. RPIO has the ability to PWM drive the GPIO with DMA, producing stable pulses.

GPIO Pins are named in BCM-Notation (e.g. GPIOnn), Pin headers (e.g. P1-13V2 for Version2) or other (for a specific adapter, IKG.IO.3 is used). The naming configuration is in `/scratchClient/config/portMapping.xml`

#### 6.1.1. GPIO Adapter, input

Input type adapters read Buttons, switches and other type of binary signals.

- `adapter.gpio.GpioInput` (sends value 0 for low, 1 for high input levels)
- `adapter.gpio.GpioValueInput` (sends configurable values for low, high input levels)

On startup or whenever a value change is detected, the adapter sends configurable values. The level assignments can be changed.

- `adapter.gpio.GpioButtonInput` (deprecated, use `GpioEventInput`; sends events on button pressed, button released)
- `adapter.gpio.GpioEventInput` (sends events on button pressed, button released)


A nice application is the marshmallow button: two wires through a marshmallow form a contact: when squeezed, the button is pressed. See `config/marshmallow.xml` .

#### 6.1.2. GPIO Adapter, output

- `adapter.gpio.GpioOutput`, uses events to control outputs.
- `adapter.gpio.GpioValueOutput`, uses variable settings to control output.
- `adapter.gpio.GpioOutputPWM`, pwm is 0 to 100%

#### 6.1.3. GPIO Adapter, output for PWM controlled Motor

- hbridge motor driver driver (e.g. L293, two half bridges separately controlled) `adapter.gpio.GpioMotorPWM` sample configuration is `config/config_hbridge_motor.xml`



DC Motor with L293D-Chip


#### 6.1.4. GPIO Adapter, output for Servo motors

- `adapter.gpio.GpioOutputPWMServo`, pwm is 1ms (0 input value) to 2ms(100 input value), period length 20ms. The PWM adapter uses `rpi.gpio` library with `soft-pwm`. This causes jitter for the signals.

The output of this adapter can be inverted by configuration. This is needed if a simple (inverting) transistor level shifter is used.

#### 6.1.5. GPIO Adapter, output for Stepper motors

- bipolar stepper driver `adapter stepper.BipolarStepper`



Bipolar Stepper with L293D-Chip

- unipolar stepper driver `adapter stepper.UnipolarStepperStep` `adapter stepper.UnipolarStepperModule`

#### 6.1.6. GPIO Adapter, various Adapters using multiple GPIO



- rotary encoder, using two photointerrupters `adapter.encoder.GPIOEncoder`
- seven segment driver `adapter.encoder.Gpio7segment`


An adapter designed to monitor the connection state with scratch is `adapter.gpio.GpioStateOutput`. When the `scratchClient` is started, the output is set to 'high'. When connection to scratch is established, the output blinks at 0.6 sec cycle time. Please note the naming of the port: these names are configurable as described in Section 10.2, "GPIO Names" .

```
<adapter class='adapter.gpio.GpioStateOutput' name='state'>
  <description>State display on IKG.IO.9</description>

  <gpio port='IKG.IO.9' alias='state'>
    <default dir='OUT' default='low' />
    <active dir='OUT' default='low' />
  </gpio>
</adapter>
```

SHT015 humidity Sensor is using a 'wire' protocol, driven by GPIO. The protocol is not time critical. Adapter is `adapter.wire_gpio.Wire_SHTx`

### 6.1.7. Telephone Dial Plate Adapter




A dialplate as seen here has two switches.

- Contact 'nsi' is delivering pulses.
- Contact 'nsa' is closed when the plate is turned.

The adapter `adapter.encoder.GPIODialPlateEncoder` is handling the plate. It needs two GPIO pins. Polling interval is changing for this adapter. When not used (contact 'nsa'), the polling interval is 0.2 sec. When active the polling interval is 5ms.

### 6.1.8. GPIO HCSR04 connected with one wire

The adapter uses polling and is not very accurate. The advantage is that only one GPIO pin is used.



In the python environment used there are threading, garbage collection and of course influences from the operating system. From time to time there are situations where the polling detects timeouts. These situations are reported in the log file like

```
adapter.gpio - WARNING - HCSR04: error code 2
```

## 6.2. SPI based Adapter

SPI is a communication protocol for various devices. A concept of 'device handlers' is used to generalize the usage. When in a device multiple similar data points are used, this is called 'channels'; used in e.g. ADC-devices.

### 6.2.1. MAX31855 Thermocouple

The adapter `adapter.spiAdapter.MAX31855_Adapter` provides three output values: `temp_intern`, float value, scaled to °C `temp_wire`, float value, scaled to °C the error bits of the device are converted to a string value. `temp_error`, string value,

- " empty string, no error
- 'SCV: short to Vcc'
- 'SCG: short to GND'
- 'OC: open circuit'


start scratchClient

```
cd ~/scratchClient
sudo python3 src/scratchClient.py -config config/config_max31855.xml
```

### 6.2.2. MCP23S17 16-Bit IO Expander; PIFACE board

The MCP23S17 is a SPI connected port expander with 16 GPIO pins. The adapter `adapter.mcp23s17.MCP23S17_Adapter` controls this device.

#### 6.2.2.1. Setup on a breadboard



### 6.2.2.2. PiFace board

The MCP23S17 is used on the PiFace board. The sample configuration `config/config_mcp23s17.xml` can be used to drive this board. When using piFace, then do NOT use GPIO25 (this is INTB in MCP23S17)

In scratch, create variables 'out\_0', 'out\_1' .. 'out\_7' to drive the outputs. Values are '0', '1', 'true', 'false'. For the relays, the variables 'relais\_0', 'relais\_1' can be used. The variable 'all' sets all outputs in parallel.

scratchClient sends sensor values 'inp\_0', 'inp\_1', .. 'inp\_7'; the values are '0' and '1'.

In the configuration file, the scratch names can be changed to be more useful. If for example a 'forwardMotor' is attached to relais\_0, just rename 'relais\_0' to 'forwardMotor'.

### 6.2.2.3. Configuration details

The device 23s17 allows to have up to 8 devices 'in parallel' on one SPI chip select. These devices have hardwired distinct slave addresses. In the configuration, this slave address must be given by the parameter '23s17.addr'.

```
<parameter name='spi.bus' value='0' />
<parameter name='spi.device' value='0' />

<!-- slave address must match the hard wired slave address
      on the device [0..7] -->

<parameter name='23s17.addr' value='0' />
```

The IO direction for the port pins is defined by `<io/>`-tags.

```
<io id='GPA0' dir='out' />
<io id='GPA1' dir='out' />
<io id='GPA2' dir='out' />
<io id='GPA3' dir='out' />

<io id='GPA4' dir='out' />
<io id='GPA5' dir='out' />
<io id='GPA6' dir='out' />
<io id='GPA7' dir='out' />

<io id='GPB0' dir='in' pullup='weak' />
<io id='GPB1' dir='in' pullup='weak' />
<io id='GPB2' dir='in' pullup='weak' />
<io id='GPB3' dir='in' pullup='weak' />

<io id='GPB4' dir='in' pullup='weak' />
<io id='GPB5' dir='in' pullup='weak' />
<io id='GPB6' dir='in' pullup='weak' />
<io id='GPB7' dir='in' pullup='weak' />
```

It is generally a good idea to define all of the port pins. Technically it is needed to define those which are used in the application. The id-values are predefined and must be used as seen here.

For ports defined as `dir='out'` outputs, the corresponding adapter input methods can be used:

```
<input_value name='inputGPA4'>
  <!-- variable name is the name of the scratch variable
        which is send out to the adapter. -->
  <variable name='input_4' />
</input_value>
```

For ports defined as dir='in' inputs, the corresponding adapter output methods can be used:

```
<output_value name='outputGPB2'>
  <sensor name='output_2' />
</output_value>
```

The variables send out from scratch are '0', '1' to set the output pin of the 23s17 to low, high.

The sensor values received from scratch are '0', '1' for the input pin of the 23s17 receiving low, high.

#### 6.2.2.4. Start scratchClient

scratchClient startup does not need special considerations.

```
cd ~/scratchClient
sudo python3 src/scratchClient.py -C config/config_mcp23s17.xml
```

The file config/config\_mcp23s17.xml is an example of a full functional configuration.

#### 6.2.3. ADC MCP3202

- Adapter adapter.adc.ADC\_MCP3202\_10\_Input 10 bit resolution.
- Adapter adapter.adc.ADC\_MCP3202\_12\_Input 12 bit resolution, providing an optional low pass filter

#### 6.2.4. ADC MCP3008

- Adapter adapter.adc.ADC\_MCP3008\_10\_Input 10 bit resolution.
- 8 channel single ended input operation of this device.


#### 6.2.5. WS2801 LED Stripe

SPI can be used to emulate a shift register, as needed by a LED Strip with WS2801-Chip. The adapter is adapter.spiaadapter.WS2801\_Adapter.

In the distribution, there is a sample scratch program for the WS2801-stripe.

Start scratch with command

```
scratch ~/scratchClient/scratch/ws2801/ws2801.sb
```




The program provides some colored fields which can be clicked and add their color name to a list. When the data shall be send to the stripe, press 'send'. The list is converted to a variable 'led' then.

The scratchClient adapter converts color names to RGB-values and sends them out to the SPI-hardware.

start scratchClient

```
cd ~/scratchClient
sudo python3 src/scratchClient.py -config scratch/ws2801/config_spi_ws2801.xml
```



For the hardware connection, see your vendors documentation on the stripe.

## 6.3. I2C-Adapters

### 6.3.1. ADS1015 ADC Converter

The Adapter `adapter.i2cAdapter.ADC_ADS1015_Input` reads values from an ADS1015. The company adafruit sells a breakout board with this chip.

See sample configuration `scratchClient/config/config_adc_ads1015.xml`.

### 6.3.2. BH1750 Luminosity Sensor

The Adapter `adapter.i2cAdapter.Luminosity_BH1750_Input` reads values from a BH1750. Values are luminosity in lux (lx).

See sample configuration `scratchClient/config/config_luminosity_bh1750.xml`.

### 6.3.3. BMP085 barometric pressure sensor

The Adapter `adapter.i2cAdapter.Pressure_BMP085_Input` reads values from a BMP085. Values are pressure and temperature.

See sample configuration `scratchClient/config/config_pressure_bmp085.xml`.

### 6.3.4. MPR121 Touch Controller

The Adapter `adapter.i2cAdapter.Touch_MPR121` provides touch signals. This adapter was developed based on adafruit libraries.

When the chip is connected, check the availability using `i2cdetect`.

```
root@raspberrypi:/home/pi# i2cdetect -y -q 1
    0  1  2  3  4  5  6  7  8  9  a  b  c  d  e  f
00:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
10:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
```

```

20:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
30:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
40:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
50:  --  --  --  --  --  --  --  --  --  5a  --  --  --  --  --  --
60:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
70:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --

```

The sample configuration `config_touch_pr121` provides level signals. These are '0' when not touched and '1' when touched'.

Touch events are provided too. When level changes from 0 --> 1, then a broadcast event is produced.

Start scratchClient with sample configuration for this adapter:

```


cd ~/scratchClient
sudo python3 src/scratchClient.py -c touch_mpr121.xml

```

A sample scratch 2 snippet shows how the level signals and events can be used.

The 'hat events' provide the broadcast events.

The names of the signals, events can be changed in the config file.



### 6.3.5. PCF8591 4 channel ADC and DAC

This adc converter is used in pi2go, a small two wheel robot.

### 6.3.6. PCA9685 16-channel, 12-bit PWM LED controller

The Adapter `adapter.i2cAdapter.PWM_PCA9685` controls this device.

See sample configuration `scratchClient/config/config_PCA9685.xml`

In scratch, create variables 'channel\_0', 'channel\_1', .. 'channel\_11'. The values are 0..100. Value 0 is no signal; 100 is full cycle filled.

In scratch, create variables 'servo\_0', 'servo\_1', .. 'servo\_11'. The values are 0..100. Value 0 is 1ms; 100 is 2ms in a 20ms period.

The PCA9865 has 12 bit resolution, which is not challenged with values from scratch in range 0..100. This value is chosen for consistency with other adapters.

### 6.3.7. SN3218 LED controller, piGlow board

The Adapter adapter.i2cAdapter.PWM\_SN3218 controls the SN3218-chip. This chip is used on piGlow board.

The usual i2cdetect-command does not report this chip. Use the -q-switch for this device.

```
root@raspberrypi:/home/pi# i2cdetect -y -q 1
    0  1  2  3  4  5  6  7  8  9  a  b  c  d  e  f
00:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
10:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
20:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
30:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
40:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
50:  --  --  --  --  54  --  --  --  --  --  --  --  --  --  --  --
60:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
70:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
root@raspberrypi:/home/pi#
```

The sample configuration uses some 'common variables. 'all' is used for all LED in sync. The 'branch\_0', 'branch\_1', 'branch\_2' are for the three branches for the piGlow board. The individual LED are addressed with hex numbers, like 'channel\_0A' or 'channel\_11'. These names are case sensitive.

```
cd ~/scratchClient
sudo python3 src/scratchClient.py -c config/config_SN3218.xml
```

See scratchClient/scratch/SN3218/piglow.sb for a sample scratch program.

## 6.4. GPIO Wire adapter, w1-gpio

### 6.4.1. GPIO Wire adapter, DS1820

Temperature sensor DS1820 needs one gpio pin for the connection. The timing is quite strict, but a kernel driver is available.

Adapter adapter.w1\_gpio.W1\_DS1820 uses 'w1-gpio' kernel driver.

Connect ds1820 signal line to GPIO4, pullup needed 4k7 Ohm to 3.3V.

The adapter configuration sample is config/config\_temperature\_ds1820.xml . In this file, you need to configure the address of your ds1820.

- Connect DS1820 to raspberry pi, dataline is (usually) GPIO4. Add a resistor 4k7 from data to 3.3V.
- Start kernel driver: For PI2, add a line to /boot/config.txt

```
dtoverlay=w1-gpio,gpiopin=4
```

Needs a reboot to take effect.

- The driver creates a directory in /sys/bus/w1/devices , which contains subfolders for each DS1820 connected. The name of the folder is composed of a family code and the unique device id. DS1820 und DS18S20 have familycode 10, DS18B20 use 28 and DS1822 use 22. check the directory name and configure in config/config\_temperature\_ds1820.xml . Example:

```
<parameter name='w1.device' value='10-0008023b57b9'
```

The sample configurations contain a config file for this device. Start scratchClient with

```
cd ~/scratchClient
python src/scratchClient.py -c config/config_temperature_ds1820.xml
```

For this special purpose, no root permission is needed. The file written by the kernel driver is public for reading.

## 6.5. Remote Communications

Scratch installations can cooperate between different computers. This requires some planning for the network infrastructure and of course at least two computer to demonstrate the basics.

scratchClient offers adapters for this purpose

- scratchCommunicationServer with CommunicationAdapter. This is a simple solution for a 'data distribution', but allows to limit communication channels to specific computers and so keeps control for the admin.
- MQTT can be used with MQTT\_Adapter. This is a standard protocol for Internet of Things IoT and widely used in industry.

### 6.5.1. MQTT-Adapter

Message Queue Telemetry Transport, MQTT is widely used in IoT applications. The protocol allows to publish values or subscribe to values based on 'topic' strings, e.g. 'scratch/data/sensorA'.

For scratchClient, there is an adapter which provides simple access to this protocol. Although advanced features as e.g. encryption are not used, it allows simple experiments with this toolset.

The adapter provides the client side. The server needs to be installed on one machine, clients need network connection to this machine.

Installation for server. The server can be installed on any machine having a fixed ip address.

```
sudo apt-get update
sudo apt-get install mosquitto mosquitto-clients python-mosquitto
```

To validate server installation, run in a terminal

```
ps -ef | grep mosquitto
```

The response should be something like `mosquit+ 30805 1 0 12:09 ? 00:00:06 /usr/sbin/mosquitto -c /etc/mosquitto/mosquitto.conf`

Installation for client side.

```
sudo pip install paho-mqtt
```

Please note that client configuration xml files need to be edited with the correct ip address of server.

Limitations: to make experiments with this setup, best case two computers are needed. Scratch may only run once on each machine, so the smallest usable setup are two machines. When e.g. python mqtt clients are used, there is no limitation on the number of additional clients on one machine.

Configuration of the data transmitted are done in config.xml files. A sample is provided in `config/config_mqtt.xml`. The config files for the `adapter.iotAdapter.MQTT_Adapter` differ from others in the way the scratch variables are defined.

```
<adapter class='adapter.iotAdapter.MQTT_Adapter' name='mqtt'>
  <description>interface to a mqtt-server</description>

  <!--
    this adapter does implicit input_value and output_value-configuration based on the
    content of mqtt-Tag.
    mqtt/publish/@variable definitions are used as scratch variable names.
    mqtt/subscribe/@variable definitions are used as scratch sensor names.
  -->

  <extension>
    <mqtt>
      <publish topic="scratch/sample/a_value" variable="a_value" />
      <publish topic="scratch/sample/b_value" variable="b_value" />
      <publish topic="scratch/sample/c_value" variable="c_value" />

      <subscribe topic="scratch/sample/d_value" variable="d_value" />
    </mqtt>
  </extension>

  <parameter name="mqtt.server" value="192.168.2.160" />
  <parameter name="mqtt.port" value="1883" />
</adapter>
```

The `input_value`- and `output_value` tags are omitted and the variable definitions are taken from the variable names in the `mqtt`-section.


The related adapter web page displays this adapter as follows:



## ScratchClient, Adapters

Konfigurationsdatei: C:\python\workspace\scratchClient\config\config\_mqtt.xml

Publish / subscribe to a mqtt-Server.  
The server must be started separately as a service.



The adapter can be combined with other adapters to read values, write actors or alike.

A typical usage scenario could be that one computer collects some sensor data, e.g. temperature values and provides those with a topic `scratch/sensor/temp`.

Other groups could subscribe to this value and do different things:

- Display the value for information purpose. Or print a chart based on the values.
- Switch a heater based on the values. Most possibly a simulated heater when in a school environment.
- When temperature trend is falling, send a twitter message to the user to buy winter clothes.

Configuration remarks.

Data published by a specific topic are 'send' to all. Anybody can subscribe to the topics to 'receive' these.

Using mqtt in a school lesson needs some preparation for topic definition. Which could be an opportunity to talk about hierarchical organization of topic names.

Data published by a specific topic should be received by someone. These subscribe to the topic.

The data send are not events. Scratch does not send out same data multiple times and mqtt just provides values. And the protocol does not care too much about lost communications.

### 6.5.1.1. MQTT-Adapter Sample

In the distribution, there is a sample for two devices. First device is assumed to be a raspberry pi with a button connected from GPIO17 to GND. Second device is a general purpose computer (or another raspberry pi).

On device\_0, when the button is pressed or released, then scratch places an appropriate value into variable 'button' which is published to mqtt, topic 'scratch/sample/button'.

On device\_1, the value of topic 'scratch/sample/button' is received and displayed on stage.

Ensure a mqtt server is running and the config files for the sample have the correct ip-address included.

#### 6.5.1.1.1. MQTT-Adapter Sample, Device 0

Start scratchClient with

```
cd ~/scratchClient
python src/scratchClient.py -c scratch/mqtt/dev_0/device_0.xml
```

Start scratch application

```
scratch scratchClient/scratch/mqtt/dev_0/device_0.sb
```

#### 6.5.1.1.2. MQTT-Adapter Sample, Device 1

Start scratchClient with

```
cd ~/scratchClient
python src/scratchClient.py -c scratch/mqtt/dev_1/device_1.xml
```

Start scratch application

```
scratch scratchClient/scratch/mqtt/dev_1/device_1.sb
```

## 6.5.2. Remote Communications Adapter with scratchCommunicationsServer

The adapter class `adapter.remote.CommunicationAdapter` provides scratch to scratch communication. There is a server process needed on the network [host, port=42002].

```
python src/scratchCommunicationServer.py
```

It is recommended to install scratchCommunicationServer on a machine with a fixed ip address. It can run in parallel to scratchClient on a machine.

The adapters are assigned to groups, so within one network the communication server keeps different groups separate from each other. Sample configuration is /scratchClient/config/config\_remote\_0.xml or config\_remote\_1.xml


Groups are useful when in a classroom environment where pairs of two exercise a communication sample, but only one scratchCommunicationServer is running. Then each group gets its own name, and interferences are avoided.

Broadcast signals defined as inputs to the adapter are propagated to all other registered adapters (except the one it came from). Outputs of the adapter are propagated towards local scratch.

### 6.5.2.1. How to setup configuration files.

A simple szenario is used for the explanation: In a school class, three computers with scratch should perform a chain reaction. 'computer\_0' lights a LED and sends 'command\_A' to 'computer\_1'. When 'computer\_1' receives this event, it lights a LED and sends 'command\_B' to 'computer\_2', which lights a LED.

With an UML sequence diagram, the process gets clear.



Good planning is needed for a successful setup.

For 'computer\_0', there is only one outgoing event.

```

<remote type='forward'>
  <broadcast name='command_A' />
</remote>
  
```

For 'computer\_1', there is one incoming event and one outgoing event.

```

<remote type='forward'>
  <broadcast name='command_B' />
</remote>
<remote type='receive'>
  <broadcast name='command_A' />
</remote>
  
```

Finally for 'computer\_2', there is one incoming event.

```

<remote type='receive'>
  <broadcast name='command_B' />
</remote>
  
```

For each computer, prepare the appropriate config file and start scratchClient with it.

### 6.5.2.2. Sample Application 'railway control'

There is a sample implementation of a remote controllable railway track available. To operate this, you need two computers A and B on a network. It is not possible to have this running on one system only, as two scratch instances are needed and the server ports 42001 can't be adjusted. A screencast of this sample is available on youtube [http://youtu.be/o-A9yyL5ugE]


Adjust hostaddress in scratch/remote/config\_lokomotive\_remote.xml and scratch/remote/config\_lokomotive\_remote\_control.xml, it should contain IP-address or hostname of Computer A.

```

<parameter name="server" value="192.168.2.102" />
  
```

Distribute this file to Computer A and Computer B.

#### 6.5.2.2.1. Context Diagram



#### 6.5.2.2.2. Computer A


start scratch

```
scratch ~/scratchClient/scratch/remote/lokomotive_remote.sb
```

start scratchClient, in a terminal window.

```
cd ~/scratchClient
```

```
sudo python3 src/scratchClient.py -c scratch/remote/config_lokomotive.xml
```



start server process in a terminal window:


```
cd ~/scratchClient
```

```
python src/scratchCommunicationServer.py
```

#### 6.5.2.2.3. Computer B

start scratch

```
scratch ~/scratchClient/scratch/remote/lokomotive_remote_control.sb
```



Clicking on the arrows should set the corresponding track directions. But scratchClient needs to be started first. start scratchClient in a terminal window:

```
cd ~/scratchClient
sudo python3 src/scratchClient.py -config scratch/remote/config_lokomotive_control.xml
```

Commands from control panel on computer B scratch instance are transferred to computer A.

### 6.5.3. Sonic Pi-Adapter

Sonic Pi is a sound producing software and programming environment with an excellent sound quality.

The software provides an Open Sound Control OSC-API through an UDP socket. This feature is not documented, so it might be removed silently. In the Release 2.11.1 this feature is available.

This API allows to play sounds like

```
play 50
```

or more complex things like

```
use_synth :chiptlead ; play 80,release: 0.08 ; sleep 0.1 ; play 83, release: 0.08
```

In sonic pi, there is a protocol log which displays commands received and indicates possible errors in syntax.

There are additional installs needed for this adapter.

```
sudo pip3 install python-osc
```

The main purpose of this adapter is to have better sound quality from scratch on pi. It is not intended to replace the programming inside sonic pi by scratch, especially as timing can't be as precise from scratch.

When the connection to scratch is enabled or disabled, a small tune is played.

There is a sample config file in config/config\_sonicpi.xml.

Usage: start sonic pi on same computer as scratchClient.



The adapter can be combined with other adapters to read values, write actors or alike.

The adapter runs on raspberry pi and windows; it needs python3 for scratchClient.

## 6.6. Scratch related Adapters

### 6.6.1. Broadcast Adapter

Sending broadcast events from adapter to scratch when remote communications is established. Use this to start a script automatically.

adapter.broadcast.ScratchStartclickedAdapter

```
<adapter class='adapter.broadcast.ScratchStartclickedAdapter' name='startClick'>
  <output name='command'>
    <broadcast name='scratch-startclicked' />
  </output>
  <description>Send startclicked</description>
</adapter>
```

sends scratch-startclicked when remote communication is established. This is a 'green flag' event for scratch 1.4.

## 6.7. Operation System Adapters

### 6.7.1. Text To Speech Adapter

Adapters are not limited to GPIO or SPI based devices, but can control applications on the computer as well. Ad hoc speech synthesis is available with 'festival' or 'pico2wave' text to speech applications. There are audio outputs available in scratch, but only prerecorded snippets. Text to speech allows arbitrary text to be produced. You need to have the tools installed.

Sample configuration is config/config\_texttospeech\_festival.xml

Sample configuration is config/config\_texttospeech\_pico2wave.xml

Speech output is quite slow. The adapter queues the incoming data up to a length given by the parameter 'queue.max'. When queue size is exceeded, new entries are discarded and a warning log message is issued.

Comment

Keep in mind that scratch sends values only on changes. Repeating the same text multiple times works only if the text is (silently) modified, e.g. by appending blanks and removing blanks in turn. Festival is well suited for english language. German text will sound a little bit strange. pico2wave has better quality output.

### 6.7.2. System Time Adapter

Scratch 1.4 has no system time available. This adapter provides current system time to scratch.

adapter.broadcast.TimeAdapter

See configuration file config/config\_time.xml for a sample.

### 6.7.3. Operating system commands

Control applications on the computer with this adapter. It will execute a os-command configured.

Sample configuration is config/config\_linux.xml

```
<adapter class='adapter.linux.Linux_Adapter' name='sample'>
  <description>linux os command execution</description>

  <input name='trigger'>
    <!-- scratch event name -->
    <broadcast name='execute' />
  </input>

  <parameter name="os.command" value="ls -l" />
  <parameter name="queue.max" value="5" />
</adapter>
```

Start sample configuration

```
cd ~/scratchClient
python src/scratchClient.py -c config/config_linux.xml
```

Sample scratch code



Programs executed should not run long time.

The adapter queues the incoming data up to a length given by the parameter 'queue.max'. When queue size is exceeded, new entries are discarded and a warning log message is issued.

The commands executed are configured in configuration file. These commands are executed in the context of the user who started scratchClient. Avoid starting scratchClient as root when in doubt.

### 6.7.4. Linux 'aplay' adapter

Play wav-files using linux aplay command. This adapter allows some more flexibility than the scratch build in audio replay, as the ALSA-device can be defined. On USB-adapters, higher quality can be achieved.

The linux command used is 'aplay -D device dir/file'.

Place the files to play in file system directory. Or use the already available files in e.g. /opt/sonic-pi/etc/samples. These files are NOT included in the scratch code. So when you move your scratch application to another computer, you need to move your files too.



The code snippet shows how to play one sound repeatedly. As scratch only transmits variables when the value changes, the file name is set to 'blank' in between.

### 6.7.5. Linux 'arecord' adapter

Record wav-files using linux arecord command. This adapter allows some more flexibility than the scratch build in recording, and is run time controllable by scripts

The linux command used is 'arecord -D device dir/file'.

Set file name first.

Start recording with an event, and stop with an event. There is a timeout provided in case scratch misses to send the stop event. This timeout feature limits space consumption in file system.

These files are NOT included in the scratch code. So when you move your scratch application to another computer, you need to move your files too.

Protect privacy: do not record personal communication without permission.



### 6.7.6. Linux speech recognition adapter


There are speech recognition systems available which run on raspberry pi. Pocketsphinx is an example.

Pocketsphinx needs a quite complicated installation procedure. It is described in installation instruction [<https://wolfpaulus.com/journal/embedded/raspberrypi2-sr/>].

Running pocketsphinx in continuous mode needs quite a lot of CPU power. So I decided to run it in batch mode. This is convenient for short sequences of speech. Use the arecord-adapter to record sound snippets, and process these by the recognition adapter.

For sending text from scratchClient to scratch a protocol is implemented. ScratchClient sets the 'text'-variable, and then sends an event 'textAvailable' (or whatever is configured in the adapter xml). When data are processed in scratch, then scratch sends an acknowledge 'textAcknowledge' to scratch client.

See a scratch sample code in `scratch/linux/speechRecognition.sb`



The data received from scratchClient are added to a list. Another script takes these data from the list and displays them with a 'think'-action. Perhaps there are more useful things which could be controlled.

Adjust the command line given in the adapter config file according to your needs and check this first in a terminal window.

```
<parameter name = 'command.line'
  value = 'pocketsphinx_continuous -hmm /usr/local/share/pocketsphinx/model/en-us/en-us \
    -lm 0609.lm -dict 0609.dic -samprate 16000/8000/48000 \
    -logfn /dev/null \
    -infile ${sound.dir}/${sound.file}' />
```


Please note that this command line is from a development system. The dictionary '0609' was set up for some numbers and commands. This needs adjustment for each environment.

Start this sample with scratchClient

```
python src/scratchClient.py -c config/config_linux_a_ASR.xml
```

pocketsphinx prints recognized text line by line; fast spoken words are in one line. Silence breaks cause new lines to be produced.

An UML sequence diagram best explains the sequence of commands and the protocol.



(1,2) The processing is started by an 'execute' event. The linux process is created.

(3..7) A line of text from the process is read into scratchclient and written to a sensor variable 'text'. Then a textAvailable Event is issued and scratch should process the data. When processing is complete, a textAcknowledge event to scratchClient is sent.

(8..12) Just another example of a text sent.

(13,14) If the process terminates, a 'complete'-Event is sent towards scratch.

This adapter is not limited to speech recognition; it can be used with any process which outputs lines of text to stdin.

## 6.7.7. Linux lirc Adapter

Linux lirc allows to receive IR control signals. The adapter allows to receive key events and to forward these to scratch. The adapter does not send commands.


lirc needs to be installed and configured. The installation described here is not a comprehensive tutorial on lirc, but a short summary on what needs to be done.

### 6.7.7.1. Connect IR Receiver chip

There are many IR receiver devices. The test device used was a VISHAY TSOP34838; be sure the device is 3.3V compatible

lirc is using BCM port numbering, for this sample the input pin is connected to GPIO17





The resistor is 330 Ohm and protects the gpio pin when accidentally switched to output mode.

### 6.7.7.2. Installation

lirc needs to be installed and configured.

The installation sequence is based on [raspberry-pi-fernbedienung-infrarot-steuerung-lirc](https://tutorials-raspberrypi.de/raspberrypi-fernbedienung-infrarot-steuerung-lirc/) [https://tutorials-raspberrypi.de/raspberrypi-fernbedienung-infrarot-steuerung-lirc/]

The operating system used is Raspbian 2017-04-10; the procedure might change in future releases.

#### 6.7.7.2.1. Install lirc

##### Enable lirc in device tree.

Edit /boot/config.txt

```
sudo nano /boot/config.txt
```

From:

```
# Uncomment this to enable the lirc-rpi module
#dtoverlay=lirc-rpi
```

To:

```
# Uncomment this to enable the lirc-rpi module
dtoverlay=lirc-rpi

# Uncomment this to override the defaults for the lirc-rpi module
#dtparam=gpio_out_pin=16
#dtparam=gpio_in_pin=17
#dtparam=gpio_in_pull=down
```

##### Install lirc

```
sudo apt-get update
sudo apt-get install lirc -y
```

#### 6.7.7.2.2. Configure lirc

Edit /etc/lirc/hardware.conf `sudo nano /etc/lirc/hardware.conf`

```
# /etc/lirc/hardware.conf
#
# Arguments which will be used when launching lircd
LIRCD_ARGS="--uinput"

#Don't start lircmd even if there seems to be a good config file
```

```
#START_LIRCMD=false

#Don't start irexec, even if a good config file seems to exist.
#START_IEXEC=false

#Try to load appropriate kernel modules
LOAD_MODULES=true

# Run "lircd --driver=help" for a list of supported drivers.
DRIVER="default"
# usually /dev/lirc0 is the correct setting for systems using udev
DEVICE="/dev/lirc0"
MODULES="lirc_rpi"

# Default configuration files for your hardware if any
LIRCD_CONF=""
LIRCMD_CONF=""
```

## Verification

Stop lirc

```
sudo /etc/init.d/lirc stop
```

Check receiver with `mode2 -d /dev/lirc0`, press buttons on remote control, you should get something like

```
space 958099
pulse 896
space 890
pulse 892
space 897
pulse 1795
space 890
pulse 902
```

### 6.7.7.2.3. Configure remote control

Stop lirc `sudo /etc/init.d/lirc stop`

List available commands for the key events `irrecord --list-namespace | grep 'KEY'`. Use only names out from the listed commands for your remote control.

Register remote control key presses by `irrecord -d /dev/lirc0 ~/lircd-remote.conf`

Read the `irrecord` printouts and confirm with enter twice. Press different remote buttons for each prox a second until you get message `Please enter the name for the next button (press to finish recording)`

Use only codes you recorded earlier, e.g. `'KEY_0'`

When finished, terminate program and edit new conf file to change name of remote control. `nano ~/lircd-remote.conf`

Copy new conf file to `/etc/lirc/lircd.conf` `sudo cp ~/lircd-remote.conf /etc/lirc/lircd.conf`

### 6.7.7.2.4. Verification of lirc events

Start lirc

```
sudo /etc/init.d/lirc start
```

check commands using `'irw'` this tool displays actions provided by lirc

```
pi@raspberrypi:~ $ irw
0000000000001005 00 KEY_5 /home/pi/lircd-fernbedienung.conf
0000000000001005 01 KEY_5 /home/pi/lircd-fernbedienung.conf
0000000000001002 00 KEY_2 /home/pi/lircd-fernbedienung.conf
```

### 6.7.7.2.5. Install python libraries for scratchClient

```
sudo pip install evdev
```

```
sudo pip3 install evdev
```

Adapter maps KEY events to signals for scratch. Signal names are build by 'output\_' + KEY-name + '\_up' or 'output\_' + KEY-name + '\_down'. Examples are "output\_KEY\_6\_down" or "output\_KEY\_9\_up".

The key names are read from lircd config file, usually in /etc/lirc/lircd.conf

In the web monitor, the adapter is displayed with the events retrieved from config file.

## ScratchClient, Adapters

Konfigurationsdatei: /home/pi/scratchClient/config/config\_lirc.xml

LIRCD interface

lircd.conf= /etc/lircd.conf	<b>lirc</b>	output_KEY_1_down	output_KEY_1_down
	adapter	output_KEY_2_down	output_KEY_2_down
	uinputAdapter	output_KEY_3_down	output_KEY_3_down
	LIRC_Adapter	output_KEY_4_down	output_KEY_4_down
		output_KEY_5_down	output_KEY_5_down
		output_KEY_6_down	output_KEY_6_down
		output_KEY_7_down	output_KEY_7_down
		output_KEY_8_down	output_KEY_8_down
		output_KEY_9_down	output_KEY_9_down
		output_KEY_0_down	output_KEY_0_down
		output_KEY_1_up	output_KEY_1_up
		output_KEY_2_up	output_KEY_2_up
		output_KEY_3_up	output_KEY_3_up
		output_KEY_4_up	output_KEY_4_up
		output_KEY_5_up	output_KEY_5_up
		output_KEY_6_up	output_KEY_6_up
		output_KEY_7_up	output_KEY_7_up
		output_KEY_8_up	output_KEY_8_up
		output_KEY_9_up	output_KEY_9_up
		output_KEY_0_up	output_KEY_0_up

### 6.7.7.3. Sample config file

A sample config file is in config/config\_lirc.xml

To start scratchClient, use

```
cd ~/scratchClient
python src/scratchClient.py -c config_lirc
```

## 6.8. Adapters for special purpose Devices

### 6.8.1. Atmel atmega328 with custom firmware as ADC

When looking for inexpensive, breadboard-friendly AD-Converters the popular Atmel atmega328 can be used. This device has an 8-channel AD-Converter. The controller needs a custom firmware, is interfaced by SPI and provides a switchable LED. A description is available on my website heppg.de, "Atmel 328-Prozessor als AD-Wandler". The SPI communication is choosen, as it is used to flash the chip and wiring is available. Interfacing this device to scratchClient needs SPI communication and the RESET-Line for the processor. The adapter adapter.atmel328\_adapter.Atmel328\_ADC\_Adapter provides functionality for this setup. It is not generic, but a proof of concept for a SPI/GPIO based setup. Sample configuration is in config\_adc\_atmel328.xml.

### 6.8.2. Atmel atmega328 with custom firmware as frequency counter

The firmware in the atmega328 allows for frequency measurement. See 'steckbrett\_328\_en.pdf' for reference.

Sample configuration is in config\_adc\_atmel328.xml

The remote coprocessor is connected by SPI.

### 6.8.3. Atmel atmega328 with custom firmware for DHT22, DHT11

There is a firmware for the DHT22, DHT11 device.

The temperature, humidity sensor DHT22 is a quite inexpensive sensor, well suited for microcontroller applications. It uses same protocol as DHT11. It is connected by a single wire, needs 5ms for a read cycle, but a quite challenging protocol where the pulse width gives '0' or '1' bit values.

This is a typical application for a coprocessor for raspberrypi. For an atmel328, it is not a challenge to handle this protocol.

See documentation for DHT22 [[http://heppg.de/ikg/wordpress/?page\\_id=6](http://heppg.de/ikg/wordpress/?page_id=6)]

Sample configuration is in config/config\_dht22\_atmel328.xml

The remote coprocessor is connected by SPI.

## 6.8.4. Test Adapter

For testing purposes, there is the need for looking into details of the communication protocol, and sending values to scratch without the need for attached hardware.

`adapter.test.TestAdapter` sends values towards scratch, changing each cycle.

When only this adapter is configured, then scratchClient does run also on windows or other hardware than raspberry pi.

Values send every second.

- iValue, integer values, incremented
- sValues, string values with 'umlaut' utf-8 chars [ 'apfel', 'apfeläöü', 'äöü' ]
- fValues, different decimal places, including 19.0 [18.8, 18.9, 19.000, 19.123, 19.2]

Values send only once at startup

- test22, integer value 1; use the web interface at localhost:8080 to edit and send values as needed.

Events

- event 'testEvent'

Start of scratchClient:

```
cd ~/scratchClient
python src/scratchClient.py -c config/config_test.xml -d
```

No superuser rights are needed for this setup, as no hardware specific drivers are connected. When running scratch on a different host, use command line switch `-host [ip]` to connect to a remote scratch instance.

## 6.8.5. Servoblaster

Servoblaster is software to DMA-control servo units with pulses from 1 to 2ms, frequency 50 Hz.

It can also be used to full scale pwm control signals to drive LED or alike, but current implementation of the adapter only supports servo signals.

See servoblaster at github [<https://github.com/richardghirst/PiBits/tree/master/ServoBlaster>]

The software is controlled by writing commands to `/dev/servoblaster`; example is

```
echo '5=1200us' > /dev/servoblaster
```

The adapter `adapter.servoblaster.ServoBlaster` is controlling 8 channels, see config file `config/config_servoblaster.xml` for a sample configuration.

Please note that the integration into the GPIO-system of other adapters is not available, so duplicate use of GPIO will not be detected.

Scratch can send values from 0..100, which corresponds with 1ms to 2ms servo signals.

The adapter writes to `/dev/servoblaster`, there are checks whether this pipe exists. A reconnect logic handles restarts of servoblaster daemon.

```
#
# start servoblaster daemon separately, it is not started by scratchClient !
#
cd ~/scratchClient
```

```
python src/scratchClient.py -c servoblaster
```

The config file sample is `config/config_servoblaster.xml`.

## 6.8.6. Raspberry Pi DMA Adapter RPIO2

Precise PWM signals can be achieved by using DMA on raspberry pi. Such signals are used to control servo or to dim LED.

In the scratchClient distribution, there is a library RPIO2, derived from RPIO package. The PWM part of this lib is ported to work on RPI3 too.

See chapter on installing RPIO2 and there is an adapter to use it.

### 6.8.6.1. Sample config file

A sample config file is in `config/config_ikg_servo2.xml`


## 6.8.7. Raspberry Pi SenseHat

Sense Hat provides many different sensors and a LED matrix.

This board needs special installation procedure, see [pythonhosted.org/sense-hat](https://pythonhosted.org/sense-hat) [<https://pythonhosted.org/sense-hat/>]

LED matrix single pixel, sensors and orientation is supported.

Sample code is in `scratchClient/scratch/senseHat`



With cursor keys, move the selector border to a led. With blank key toggle the LED to a color or dark.

Scratch sample code: `scratchClient/scratch/senseHat/sense_hat_led.sb`

scratchClient config file: `scratchClient/scratch/senseHat/config_senseHat.xml`

In order to keep the scratch code simple, this special adapter uses a special pattern for parameter passing to sense-hat function call: variables sent are stored in adapter and used for function events later.



The advantage of this pattern is that code is clear, but this pattern can only be applied when setting the parameter values is not done in multiple places.

To set single pixel values it is needed to set `x_pos`, `y_pos` and `color` first before broadcast `setPixel_xy`.

To clear single pixel values it is needed to set `x_pos`, `y_pos` first before broadcast `clearPixel_xy`.

Alternative way would be to use 'composite broadcasts', where command and parameters are joined to one event.

### 6.8.8. Pimoroni PianoHat

PianoHat is a capacitive button board.

This board needs special installation procedure, see [Getting started with Piano HAT](http://learn.pimoroni.com/tutorial/piano-hat/getting-started-with-piano-hat) [<http://learn.pimoroni.com/tutorial/piano-hat/getting-started-with-piano-hat>]

Sample configuration is `scratch/pianoHat/config_pianohat.xml`

Scratch sample code: `scratch/pianoHat/piano.sb`

### 6.8.9. Smartphone positional sensor for scratch

#### 6.8.9.1. Overview

In a quite popular computer magazine, c't 2015-03-07 (heise verlag), there is a nice article about how to connect a smartphone's positional sensors to a remote server by using a web page, some javascript and websockets.

Starting from this, there was the idea to connect this to scratch (what else ?).

The basic roadmap was

- add a html-page to my scratchClient's web server, with javascript

```
var addr = "ws://" + window.location.hostname + ":" + window.location.port +
    "/pendel";
var websocket = new WebSocket( addr );

function handleOrientation(event) {
    var x = event.beta%90;
    var y = event.gamma;
    x += 90;
    y += 90;
    try {
        websocket.send(JSON.stringify( { x:x, y:y }));
    }
    catch(err) {
        // console.log( err.message );
    }
}
window.addEventListener('deviceorientation', handleOrientation);
```

- in scratchClient, there is cherrypy used to serve the web pages. WebSocket was a new feature to be added there.
- an adapter needed to be written `adapter.websocket.WebsocketXY_Adapter`, receiving the messages and converting them to scratch variable updates.

Installation of scratchClient now needs 'ws4py' in addition to cherrypy. See the installation description.

#### 6.8.9.2. Start scratchClient

```
cd ~/scratchClient
sudo python3 src/scratchClient.py -c config/config_websocket_pendel.xml -guiRemote
```

The `guiRemote`-switch is needed to allow remote browsers connecting to scratchClient.

#### 6.8.9.3. Smartphone

In a smartphone browser, navigate to your pi's address. Of course you need a (wireless) network connection between smartphone and raspberry. In my network, the RaspberryPi's address is 192.168.2.90, most possibly different for your PI. Use 'ifconfig' to look it up.


`http://192.168.2.90:8080`

Navigate to "Smartphone as Sensor" browser

You should see rectangle with a red/green dot moving around. This is as proposed by the c't-article.

#### 6.8.9.4. Scratch

In scratch, enable remote sensor connections and provide the following script. `gotoX` and `gotoY` are sensor values provided by the scratchClient. The `x1` and `y1`-Variables are local variables in scratch.



The x and y-values are getting exchanged and the y-value gets inverted to match the coordinates of the smartphone to scratch stage.

### 6.8.10. USB barcode scanner



Barcode scanners are USB-connected devices.

These scanners typically can send codes by emulating HID-class devices. This makes usage from programs quite easy, but you loose input when the program goes to background and other programs get the focus.

Connecting these devices can be done using pyusb library. This library allows access to usb devices and, very important, can grab devices to be used exclusively by one program.

#### 6.8.10.1. Install pyusb

Here I found a problem. The usual install did not work with „pip install pyusb“. This resulted in a 'backend not found' exception and „undefined symbol: libusb\_strerror“

When I tried to download walac-pyusb-50b1490 from <https://github.com/walac/pyusb>, this worked, but I had to uninstall the pip-installed code first „sudo pip uninstall pyusb“.

The needed backend packages are already available in raspbian, you can check this with

```
apt-cache pkgnames | grep libusb
```

You should find libusb-1.0-0 in the list.

#### 6.8.10.2. Setup Scanner for USB and CR-suffix

A few preparations are needed with the scanner to enable HID mode. With my scanner I got a handbook with a huge amount of programming codes. You start programming with a 'start programming' code, scan the appropriate setup code and exit programming with an 'end programming' code.

For my sample, I have setup HID mode, and added exit code/suffix CR. This is needed to detect complete sequences. The adapter in scratchClient relies on this.

#### 6.8.10.3. Configure idVendor and idProduct

Another preparation is the configuration of idVendor and idProduct in the adapter's config file. Use the utility enum.py to list the devices available

```
cd ~/scratchClient
python tools/usb/enum.py
```

Here the output for my scanner

```
DEVICE ID 0c2e:0200 on Bus 001 Address 007 =====
bLength : 0x12 (18 bytes)
bDescriptorType : 0x1 Device
bcdUSB : 0x110 USB 1.1
bDeviceClass : 0x0 Specified at interface
bDeviceSubClass : 0x0
bDeviceProtocol : 0x0
```

```
bMaxPacketSize0 : 0x8 (8 bytes)
idVendor : 0x0c2e
idProduct : 0x0200
bcdDevice : 0x5881 Device 88.81
iManufacturer : 0x1 Honeywell Scanning and Mobility
iProduct : 0x2 Honeywell Scanning and Mobility Scanner
iSerialNumber : 0x0
bNumConfigurations : 0x1
CONFIGURATION 1: 300 mA=====
bLength : 0x9 (9 bytes)
bDescriptorType : 0x2 Configuration
wTotalLength : 0x22 (34 bytes)
bNumInterfaces : 0x1
bConfigurationValue : 0x1
iConfiguration : 0x3 HID Keyboard
bmAttributes : 0x80 Bus Powered
bMaxPower : 0x96 (300 mA)
INTERFACE 0: Human Interface Device =====
bLength : 0x9 (9 bytes)
bDescriptorType : 0x4 Interface
bInterfaceNumber : 0x0
bAlternateSetting : 0x0
bNumEndpoints : 0x1
bInterfaceClass : 0x3 Human Interface Device
bInterfaceSubClass : 0x1
bInterfaceProtocol : 0x1
iInterface : 0x0
ENDPOINT 0x81: Interrupt IN =====
bLength : 0x7 (7 bytes)
bDescriptorType : 0x5 Endpoint
bEndpointAddress : 0x81 IN
bmAttributes : 0x3 Interrupt
wMaxPacketSize : 0x8 (8 bytes)
bInterval : 0xa
```

What you also should check is the `iConfiguration` to be a HID Keyboard.

For verification open a text editor like leafpad: when scanning a code, this should be entered into the editor as a text string.

Edit `config/config_barcode.xml` and adjust the vendor/product id there.


In my environment, I use a powered USB hub to connect the scanner.

#### 6.8.10.4. Start scratchClient

```
cd ~/scratchClient
sudo python3 src/scratchClient.py -c config_barcode
```

The file `config/config_barcode.xml` is a starting point for a project. Add other adapters as needed. When scanning barcodes, these are sent to scratch. Do not forget to enable remote sensor connections.

#### 6.8.11. USB blink(1)



Blink is a small, USB based device with two RGB-LED.

Connecting this devices can be done using `pyusb` library. This library allows access to usb devices and, very important, can grab devices to be used exclusively by one program.

See chapter 'install pyusb' in barcode scanner chapter' for installation .

##### 6.8.11.1. Start scratchClient



```
cd ~/scratchClient
sudo python3 src/scratchClient.py -c config_blink
```

In scratch, create variables led\_1, led\_2 and led\_all. Set values to 'red', 'green' or other color names, or rgb-values like #2A2A2A.

### 6.8.12. Adapter for SIM800 GSM Modem, SMS support

Receiving and sending SMS text messages is possible with the adapter `adapter.serialAdapter.SIM800_Adapter`. The hardware is the adafruit fona SIM800 breakout board. Connection is made from rx, tx to the tx, rx of the RaspberryPi. Follow the instructions from adafruit to setup the module.

For this board, you need

- a SIM card
- Lipoly Battery, 500mA or larger
- micro USB charger for the board in addition to this needed for Raspberry Pi
- antenna

Basic hardware setup, cited from adafruit webpage. Vio - THIS IS THE MOST IMPORTANT PIN! This is the pin that you MUST drive with an external voltage from 3V-5V to set the logic level converter. The converter also buffers the indicator LEDs so NOTHING will appear to work unless this pin is powered! You should set the voltage to whatever voltage your microcontroller uses for logic. A 5V micro (like Arduino) should have it be 5V, a 3V logic micro should set it to 3V. For SMS, I did not use the other connectors. For automated startup, the 'Key' would be nice to use. Rx,Tx are connected to the Raspberry. If you are not sure on wiring, use serial 1kOhm to protect the Pi.

Software installation hints: The `/dev/ttyAMA0` must be removed from the `/boot/cmdline.txt` and `/etc/inittab`. For python, install pyserial

```
sudo pip install pyserial
```

Edit the configuration file `~/scratchClient/config/config_sim800.xml` :

- provide the phone number to send sms to
- and provide the pin for the sim card.

```
<parameter name='sim.pin' value='NNNN' />
<parameter name='remote.number' value='NNNNNNNNNNNN' />
```

Start the scratchClient with

```
cd ~/scratchClient
sudo python src/scratchClient -c config/config_sim800.xml -d
```

The debug switch is highly recommended, as error output is available only in the log file.

Manually start the modem by pressing the button on the breakout board. This is by purpose not automated, in order to have control on cost by sending sms. In scratch, the variable `sim_out` is used to transmit the sms send request. Empty (blank) strings will not be transmitted. The sensor value `sim_in` receives the values from the modem.



Please be aware that sending sms causes cost. Sending rate with programs can be quite high, so carefully check the logic. For this reason, no automatic startup of the modem is provided, which allows some control on when the modem is available.

### 6.8.13. RFID Adapter

The adapter is `adapter.serialAdapter.RFID_Reader_Adapter`, a sample config file is in `config/config_ID12LA.xml`.

RFID-Readers are available for 125kHz and 13.56MHz. For the 125kHz there are reader modules available from Innovations which contain also the antenna.


Connect the device to 3.3V and set format to ASCII. The data output goes to Rx-Input of Raspberry Pi.

The adapter sends an event when data are received from RFID-reader. This allows to trigger scripts in scratch when the same card or tag is used twice.

### 6.8.14. ScratchBoard, PicoBoard Adapter

The adapter is `adapter.serialAdapter.PicoBoard_Adapter`, a sample is available in `/config/config_picoBoard.xml`.

Picoboard, available from sparkfun, is a USB/serial connected device which contains some sensors and a slider.



The serial protocol is using polling. Scratch or the adapter in `scratchClient` sends out a `0x01` to start data acquisition and transfer. The board responds by 9 datapackets.

- channel 15, softwareversion `0x04`
- channel 0, sensorD
- channel 1, sensorC
- channel 2, sensorB
- channel 3, button, open = 1023, 0 pressed
- channel 4, sensorA
- channel 5, light sensor, bright 0, dark 1023
- channel 6, sound sensor, loud 1023, silent 0
- channel 7, slider sensor, 0..1023

As polling is used, the tx and rx-LED should flicker frequently.

**Table 6.1. datapacket structure**

Byte	Bit	Content
byte 0	7	'1'
byte 0	6..3	channel
byte 0	2..0	high 3 bytes of value
byte 1	7	'0'
byte 1	6..0	low 7 bytes of value

This board is supported by scratch, so usually there is no need to use `scratchClient`.

There are situations where support by `scratchClient` is useful:

- When you need more than one board.
- You want to see the native values delivered by `picoBoard`.

The sample configuration file `config/config_picoBoard.xml` uses the scratch names used from `ScratchBoard`.

If you need more than one picoboard, then

- duplicate the `<adapter/>` section in `config/config_picoBoard.xml`.
- rename `adapter/@name` from 'picoboard' to 'picoboard\_0', 'picoboard\_1' (or to any unique name you like)
- rename the `adapter/output_value/sensor/@name` values to unique names to make these separate for each adapter.

e.g. `adapter/output_value/sensor[@name='slider'] [1] /@name` to 'slider\_0'; `adapter/output_value/sensor[@name='slider'] [2] /@name` to 'slider\_1'

- rename parameter `[@name='serial.device']` to match each picoboard, most probably `/dev/ttyUSB0`, `/dev/ttyUSB1`


### 6.8.15. GPS Adapter GY-GPS6MV2

This adapter was provided by SFYRAKIS.

The GPS adapter provides time, location and speed.

There is some preparation needed to run this adapter.

Disable serial console in raspi-config.



```
sudo apt-get install gpsd
sudo pip3 install gps3
```

Edit the configuration file /etc/default/gpsd

```
sudo nano /etc/default/gpsd
```

Change the settings to

```
# Start the gpsd daemon automatically at boot time
START_DAEMON="true"

# Use USB hotplugging to add new USB devices automatically to the daemon
USB AUTO="false"

# Devices gpsd should collect to at boot time.
# They need to be read/writeable, either by user gpsd or the group dialout.
DEVICES="/dev/ttyS0"

# Other options you want to pass to gpsd
GPSD_OPTIONS="-n -G"
```


Start the service

```
sudo /etc/init.d/gpsd start
```

Check the system with a command line tool

```
cgps -s
```

The output is like



A sample config file is in config/config\_gps.xml.

### 6.8.16. Arduino UNO Adapter

Arduino UNO has an USB connection, which supports serial connection to a host computer. The arduino can be used as a IO expander, connecting digital io lines, pwm, or adc-inputs directly to scratchClient. It also supports servo signals (pwm 50Hz, 1 to 2ms pulses) by the Servo library.

The arduino sketch provided allows to use counters on inputs. The low to high-edge of signals will be counted, there is a 4ms debounce time and max frequency is prox 80Hz.

The adapter and arduino sketch will work with arduino nano, atmel328 processor, 16MHz.

With the USB-connection, the UNO provides 5V-compatible inputs/outputs. This is an advantage in some constellations. But do not connect these outputs back to Raspberry Pi inputs directly.

The functionality presented here is not a bridge to mesh network, propagating events and sensor updates into the arduino. There is a custom arduino sketch needed which only exposes the IO resources, but does not allow for additional logic in arduino.

Configuration of the io-pins (direction, pullup, pwm, servo, counter) and adc-pins (analog, input or output) is controlled by scratchClient through configuration. There is no need to adjust the arduino firmware for config changes.

The scratch names used are configurable in configuration too. This is common functionality of the framework.

The code for the arduino, a sample configuration and a sample scratch project are contained in the scratchClient distribution.


#### 6.8.16.1. Step 1, program the firmware to arduino UNO

Start arduino software, load `arduino/arduinoUno/arduinoUno.ino` and program it into the UNO.

The LED13 on the arduino should blink at 5Hz, quite fast. This indicates that the firmware did not yet receive configuration.

#### 6.8.16.2. Step 2, Sample hardware setup.

This setup is a sample for what is possible with this setup. The configuration file allows for almost all the flexibility the atmel controller allows.



The hardware uses a potentiometer (2k to 10k are ok) on AD0. On D3, there is a button connected. The other side is having a 1k-Resistor to GND (just in case the output is configured as an output, this prevents damage to the IO).

Two LED are for output. The green LED is on a PWM-Output D5, so it can be dimmed.

This setup is a sample. The functionality of all the inputs and outputs are defined by configuration in scratchClient.

#### 6.8.16.3. Step 3, connect arduino with USB-Line to RaspberryPi or windows computer.

On raspberry, lookup `/dev /tty*` connections and configure the UNO serial device in `config/config_arduino_uno.xml`-File.

For windows, you see the COMn-Device used in deviceManager.


#### 6.8.16.4. Step 4, start scratchClient with configuration

```
cd ~/scratchClient
python src/scratchClient -c config/config_arduino_uno.xml
```

After a short while, the LED13 should start blinking at 1Hz, quite slow. This indicates that configuration was downloaded and operation is ready to be used.

### 6.8.16.5. Step 5, start scratch with sample program

There is a sample program in `scratch/arduinoUno/arduino.sb`



The program takes the button input and controls the red LED with it.

The value from the potentiometer is used to set the pwm-rate and dim the green LED.


### 6.8.16.6. Configuration Tool

The setup of a xml config file for this adapter is not easy. There is a configuration tool available for this adapter.

The tool is written in java.

Start with

```
cd ~/scratchClient
cd tools
java -jar scratchClientConfig.jar
```



### Limitations

The tool only allows to handle config files with one adapter of type 'adapter.arduino.UNO\_Adapter'.

### 6.8.16.7. Constraints

The adc-channel needs to be limited to 10Hz updates. There is averaging for three samples per value transmitted. Without a limit to 10Hz, a noisy input could flood the communication line with data and cause excessive cpu usage on a raspberry pi.

The adc-channels on Port A allow for analog inputs, digital inputs or for digital output.

PWM pulses are created with `analog_write` on the digital pins. According to the arduino reference, `analogWrite()` works on pins 3, 5, 6, 9, 10, and 11. Input values for pwm are 0..255.

Servo pulses are created with Servo-library. See limitations of this library in Arduino Servo [<https://www.arduino.cc/en/reference/servo>] . Input values for servo are 0..180.

Digital inputs can be used with counter functionality. Low to high edges are counted, there is a 4ms debounce time on the edges. Max frequency is prox 80Hz. Values are 32 bit, the values will overflow (which rarely will happen).

Configuration is not persisted in the arduino.

Configuration is requested to be sent from RaspberryPi or windows to arduino on reset of arduino. If scratchClient configuration is changing, then a reset on arduino is needed to make this active. As in most cases a hardware change is made with arduino disconnected from power (either USB cable or power plug), this is only a small limitation.

One of the advantages is that e.g. windows scratch 1.4 with scratchClient on windows allows for IO connections.

## 6.8.16.8. Advanced Features

### 6.8.16.8.1. Serial Protocol

The communication between arduino and host computer on the serial file is in a human readable protocol.

Configure arduino IDE serial console to 115200Bd, 8N1, newline (LF, 0x0a) to use the low level interface for the arduino.

On reset, the arduino starts to request for configuration

```
arduino sending@115200 Bd
arduinoUno, version 2016-11-13
config?
config?
config?
```

Available commands are reported by sending 'help' to the arduino.

arduino requests configuration with 'config?' on reset

Configuration commands

cdebug:<data>	debug settings, data are hex (0,1,2,3)
cr:	dummy request, just get a newline and clean buffer
cversion?	request version string
cerr?	request error count for parser
cident?	request idcode
cident:<char16>	write idcode
cident:	reset idcode

char16 = [A-Za-z][A-Za-z0-9-\_.]{1,15}

cdin:<data>	digital inputs, data are hex
cdinp:<data>	digital inputs, pullup enabled
cdcnt:<data>	digital inputs for a counter
cdcntp:<data>	digital inputs for a counter, pullup enabled
cdout:<data>	digital outputs
cdpwm:<data>	digital pwm
cdservo:<data>	digital servo
caain:<data>	analog line, analog input [a0..a5]
cadin:<data>	analog line, digital input [a0..a5]
cadinp:<data>	analog line, digital input, pullup [a0..a5]
cadout:<data>	analog line, digital output

data give bit patterns for IO pins, hex coded

Commands to set values in arduino

o<port>,<value>	write output
oa<port>,<value>	write output analog line
p<port>,<value>	write pwm
s<port>,<value>	write servo

Values reported from arduino

v:<version>	report version
ident:<char16>	report ident from EEPROM
e:<errors>	report number of errors (decimal)
a<port>,<value>	report analog input
i<port>,<value>	report digital input
c<port>,<hex>	report counter value
ai<port>,<value>	report digital input on analog line

Disconnect

disconnect	stop processing, start request configuration
------------	--

### 6.8.16.8.2. Programmable ID code

It is possible to flash an ident code to the arduino's eeprom. This ident code can be requested from host; this allows to provide dedicated configuration for special devices. E.g. in a school setup, some arduino could be attached to special equipment and the host computer could provide only the matching configuration. This reduces the risk of configuration errors.

In serial console, use command `cident?` to request id code.

To program an id code, use `cident:<char16>`, for a code like 'NANO\_000' type `cident:NANO_000`.

ID code need to start by letters and allow letters, digits and special chars '-\_.'. In regular expression, the syntax is `char16 = [A-Za-z][A-Za-z0-9-_.]{1,15}`

The adapter allows to check ident code on startup. When checked, then in case of NOTmatching ident code the arduino does not receive configuration commands. The optional parameters are `ident.check` and `ident.pattern`.


### 6.8.16.8.3. Debug Settings

The debug settings are not for productive use. If set, then reset the processor for a clean restart.

### 6.8.16.9. Configuration Remarks

The input/output relations of the various components involved need some explanation.

When scratch writes to an output of arduino, the data flow is



From scratch point of view, data are send to an output.

For scratchClient adapters, the data are received on an input. The arduinoUNO adapter sends these data to arduino.

For the arduino, the data are then written to an output (digital io, pwm, servo).

A config file for this scenario is (reduced to the bare minimum)

```

<!-- an output on arduino is an input on adapter ! -->

<adapter class='adapter.arduino.UNO_Adapter' name='UNO'>


  <input_value name='inputD4'>
    <variable name='redLED' />
  </input_value>

  <io id='D4' dir='out' />

</adapter>

```

When arduino transmits an input value from a digital line or adc value, the data flow is



For the arduino, the data are read from an input (digital io, adc).

The scratchClient adapter gets a notification through the USB serial line and sends these data through one of its outputs.

From scratch point of view, data are an input value, either a sensor value or a broadcast.

A config file for this scenario is (reduced to the bare minimum)

```

<!-- an input on arduino is an output on adapter ! -->
<adapter class='adapter.arduino.UNO_Adapter' name='UNO'>

  <output_value name='outputA0'>
    <sensor name='potentiometer_0' />
  </output_value>

  <analog id='A0' dir='analog_in' />

</adapter>

```

### 6.8.17. Arduino UNO Adapter for Neopixel

Neopixel use WS2812-chip which contain driver logic and RGB LED. There is only one wire needed to control the chip. As timing is critical, there is no possibility to control this directly by raspberry pi. With the help of an arduino (328, uno, nano or alike) and 'adafruit neopixel' library, it is possible to control these.

Arduino UNO has an USB connection, which supports serial connection to a host computer. There is a sketch needed for these microcontrollers, see `scratchClient/arduino/arduinoNeopixel/arduinoNeopixel.ino`

With the USB-connection, the UNO provides 5V-compatible inputs/outputs. This is an advantage in some constellations. But do not connect these outputs to Raspberry Pi inputs directly.

In the sketch, adjust the RGB alignment, speed and number of chips and recompile.

```

// -----
// Adjust for your neopixel array

#define PIN 7
#define NUM_LEDS 144
#define BRIGHTNESS 50

Adafruit_NeoPixel strip = Adafruit_NeoPixel(NUM_LEDS, PIN, NEO_GRB + NEO_KHZ800);
// -----

```



Communication from arduino to host is done by using USB serial with 115200bd.

Commands are ascii readable. Type 'help' in serial console to see options.

```
all red : red
all green: green
all blue : blue
set pixel: s,NNN,RRR,GGG,BBB in dezimals e.g. s,029,000,000,255
show : show

clear : clear
help : help
echo : echo
```

The 'all red', 'all green', 'all blue' commands set all LED to respective values. This is used to check RGB alignment.

Set pixel sets a single pixel. A 'show'-command is needed to activate the settings.

Show 'show' displays pixel values.

Clear immediately clears all pixels.

Echo is used to validate connection to arduino.


All commands are terminated by \n (LF). When a command is executed, the command string is echoed back. Commands can be max 64 chars, extra trailing chars are silently ignored.

#### 6.8.17.1. start scratchClient with configuration

```
cd ~/scratchClient
python src/scratchClient -c scratch/neopixel/neopixel.xml
```

#### 6.8.17.2. start scratch with sample program

There is a sample program in scratchClient/scratch/neopixel/neopixel.sb



The scratch program maintains an array with color values. 'new' clears the list, 'send' sends to arduino. The colored rectangles add descriptive names to the list (or hex rgb values like #ff00ff).

The red\_all etc commands and the clear button are used to debug the connection and arduino code.

#### 6.8.18. Arduino UNO\_POWERFUNCTIONS\_Adapter


LEGO powerfunctions provide an infrared controlled receiver with the possibility to connect to motors, lights and others. With an IR-LED connected to an arduino which is connected to a RPi which is connected (or hosting) scratch, it is possible to control these receivers with scratch.

Arduino UNO has an USB connection, which supports serial connection to a host computer.

The adapter and arduino sketch will also work with arduino nano, atmel328 processor.

With the USB-connection, the UNO provides 5V-compatible inputs/outputs. This is an advantage in some constellations. But do not connect these outputs to Raspberry Pi inputs directly.

An IR-LED (940nm wavelength) is needed, a resistor 220 Ohm limits current. This allows for short distance connections.



With a transistor like 2n2222 and a base resistor of 680Ohm, the power on the LED can be increased.

The scratch names used are configurable in configuration files. See the config file config/config\_arduino\_powerfunctions.xml

The arduino code for arduino IDE and configuration needed for scratchClient is in the scratchClient distribution.

#### 6.8.18.1. Step 1, program the firmware to arduino UNO

Start arduino software, load arduino/power\_functions/power\_functions.ino and program it into the UNO.

#### 6.8.18.2. Step 2, Hardware setup.

Connect LED to Arduino

See the plan included above. This connection allows for currents up to 20mA. Most IR-LED support higher currents, but then a transistor is needed to drive the LED.

#### 6.8.18.3. Step 3, connect arduino with USB-Line to RaspberryPi or windows computer.

On raspberry, lookup /dev/tty\* connections and configure the UNO serial device in config/config\_arduino\_powerfunctions.xml-File.

For windows, you see the COMn-Device used in deviceManager.

#### 6.8.18.4. Step 4, start scratchClient with configuration

```
cd ~/scratchClient
python src/scratchClient -c config/config_arduino_powerfunctions.xml
```

#### 6.8.18.5. Step 5, start scratch and create scratch Program

There is a sample program in scratch/arduinoUno/lego\_powerfunctions.sb

The variables are connected to different channels, A and B are the two channels available on the LEGO receiver

The program takes the button input and controls the red LED with it.

The value from the potentiometer is used to set the pwm-rate and dim the green LED.

### 6.8.18.6. Constraints

The software can send signals for Channel1 to Channel 4. You need to adjust the receiver to the channel used.

### 6.8.19. Twitter\_Adapter

Twitter has an API which can be used by scratchClient. The adapter browses twitter for direct messages or by a hashtag and forwards these results to scratch.

Install python-twitter in python environment "sudo pip install python-twitter".

You need to obtain 'key' and 'secret' from twitter to access the API. Edit config/config\_twitter.xml and insert values there.

Polling rate for twitter can be adjusted, but twitter.com imposes a rate limit. 60 sec are a good starting point.

It is configurable whether the adapter retrieves user message or searches messages for a term or both.


A properties file written by the adapter allows to retrieve only new messages. The messageId of last message read is persisted in this file. The file is in data folder, filename is configurable in config file.

Start scratchClient

```
cd ~/scratchClient
python src/scratchClient -c config/config_twitter.xml
```

A scratch sample is in scratch/twitter/twitter.sb

Messages from twitter can arrive at a faster rate than scratch can process, or messages can be identical, which makes them indistinguishable for scratch. To handle this situation a protocol is implemented between the twitter adapter and scratch: all messages are queued inside the adapter. For each message, the text is places in a sensor variable 'text' and a 'textAvailable' event is published. When scratch receives this event, it processes the data and answers with a 'textAcknowledge' event.



### 6.8.20. Openweathermap\_Adapter

Openweathermap has an API which can be used by scratchClient. The adapter browses the api for weather data.

Install python module 'pyowm' in python environment

```
sudo pip install pyowm
sudo pip3 install pyowm
```

You need to obtain an API 'key' from <http://openweathermap.org/appid> to access the API. Edit the file `config/config_openweathermapapi.xml` and insert values there.

In the configuration file, there is a default setting for the location. Adjust if needed.

Polling rate for openweathermap can be adjusted, but depending on key type there is a rate limit. 600 sec are a good starting point.

Start `scratchClient`

```
cd ~/scratchClient
python src/scratchClient -c config/config_openweathermapapi.xml
```

Location can be set with a variable 'location' in `scratch`.

## 6.8.21. LEGO WeDo 2.0 Adapter


LEGO education offers a concept for primary schools which consists of hardware, software and educational patterns. The electronics part are

- 'Wedo 2.0 Smarthub', connected by Bluetooth Low Energy to a computer. Will be named 'hub' in this chapter.
- 'Wedo 2.0 Tilt Sensor', will be named 'tilt sensor' here.
- 'Wedo 2.0 Motion Sensor', will be named 'motion sensor' here.
- 'Wedo 2.0 Medium Motor', will be named 'motor' here.

It is important to name the devices with the WeDo 2.0 prefix, as the connector style is different from connectors used for other Lego products.

The hub offers two connectors, where the sensors or motors can be connected.

The hub connections are named as shown. This is important in 'advanced' setup.



Lego wedo2 port names.

The software offered by Lego is an easy to use 'scratch style' IDE. The command set is very limited, appropriate to primary school. There is a 'while' block, but no decisions.

With the software, it is possible to use the sensors in their default mode.

There is a SDK available from Lego, which demonstrates the more advanced features of the hub and the sensors. Based on the SDK, the integration into `scratchClient` was developed.

### 6.8.21.1. Hub features

- Button. Used to start the bluetooth connection sequence.

During operation it acts as a push button which can be used by host software.

- RGB LED. Used as status feedback. White flashing during bluetooth connection, blue when connected. Orange flashing in case of high current when a motor is blocked.

The `scratchClient` software - when connected - initiates a short red-green-blue animation and changes the color then to green.

The colors can be set by host software.

- Piezo. Used as status feedback. Initiates some beeps while connecting.

Piezo can be used to play tones.

- Voltage. Measures battery voltage.

The values in millivolts are available to host. Can not be set, of course.

- Current. Measures current from the battery.

The values in milliamperes are available to host. Usual values are around 80 to 90 mA, some 100 mA higher when a motor is used.

- Low Voltage Alert.
- High Current Alert.

The hub also controls the connect/ disconnect of motors and sensors reports this to the host. The host can set operation mode for the devices. The hub can use notifications to report value changes.

### 6.8.21.2. Motor Features

There can be one or two motors connected to the hub. With WeDo software, these are operated 'in parallel', there is no possibility to address them separately.

The hub internally allows to address the motors based on the port to which these are connected. scratchClient allows to operate two motors separately.

Motor can be powered by values [1..100] forward, [-1..-100] reverse. Value [0] is drift mode. A special value [127] is used for brake mode. The scratchClient adapter uses broadcast events for drift and brake.

### 6.8.21.3. Motion sensor Features

Motion sensor offers two operation modes.

- Mode 0, DETECT: Distance measurement. Values are from 0..9 for very near to very far which is prox 20cm.

The mode 0 is set as default.

- Mode 1, COUNT: Counts the number of 'beam brake events'. Can be used to count parts passing by. Values are from 0..100. Counter can be reset by a broadcast event.

### 6.8.21.4. Tilt Sensor Features

Tilt sensor offers three operation modes.

- Mode 0, ANGLE: Gives two angle measurements in degrees -45.0 to +45.0.
- Mode 1, TILT: Similar to ANGLE, but value is restricted to tilt directions. This provides '0' for no tilt, and '3', '5', '7', '9' for each direction.

The mode 1 is set as default.

- Mode 2, CRASH: Counts the number of crash events. This gives the number of bumps in x, y and z-direction. There is a reset signal available for the counter.

### 6.8.21.5. Installation

The adapter was developed and tested on a Raspberry Pi 3 which provides a bluetooth 4 device. The software to operate is already included in raspbian. No special setup procedures have been needed to configure bluetooth.

The scratchClient adapter needs additional software to run. This is the python module needed for the bluetooth stack.

Install python module 'bluepy' for python environment.

```
sudo pip3 install bluepy
```

I got errors during installation of bluepy fatal error: glib.h: No such file or directory. I could solve this by installing libglib2.0-dev:

```
sudo apt-get update
sudo apt-get install libglib2.0-dev
```

Do not automatically connect the hub with bluetooth. The scratchClient adapter will not be able to connect when other connections are already established.

### 6.8.21.6. Connection Options

The bluetooth connection can be build based on the MAC-address of the hub, or based on the device name.

For the connection based on MAC-address, edit the config file as follows:

```
<!-- discover option by 'address' -->
<parameter name='btle.policy' value='address' />
<parameter name='btle.address' value='a0:e6:f8:6d:0e:67' />
```

Use this setup when there are many hubs around and one dedicated device needs to be connected.

For the connection based on device name, edit the config file as follows:

```
<!-- discover option, by 'name' (needs root permission) -->

<parameter name='btle.policy' value='name' />
<parameter name='btle.name' value='LPF2 Smart Hub 2 I/O' />
```

Use this setup when only one hub is around, or the configuration effort is too high. Root peromission is needed to start scratchClient in this case. With many devices, the scratchClient adapter will connect with the first device found.

### 6.8.21.7. Connection Sequence

Start scratchClient.

Start scratch and establish 'remote sensor connection'.

Press the green button on the wedo2 hub. The LED will blink and there is an audible beep from the device. When connection is established, the LED turns to blue. After prox 3 to 5 seconds, the LED runs a short sequence red,green,blue and finally the LED remains green.

The connection is established.

### 6.8.21.8. Basic setup

With lego wedo2 education software, a subset of the hub's features can be used. It is assumed, that only one motor or only one sensor of a type are connected. It is not important on which connector the devices are plugged in.

Motion-Sensor mode is 'distance'. Values provided are '0.0' for very close and '9.0' for 'very far away.'

Tilt-Sensor mode is 'tilt'.

To operate the hub in this mode, a 'basic' setup configuration is provided `config/config_wedo2_basic.xml`.

This basic configuration is a subset of the available options of the adapter.

In the configuration, the 'strict' parameter is set to 'false'. This ignores the position of a connected sensor/actor.

```
<parameter name='mode.strict' value='false' />
```

Typically, a motor is adressed by 'motor'.

When two motors are connected, these will operate in parallel. But two sensors of one type will produce wrong data.


Start scratchClient in basic mode.

```
cd ~/scratchClient
sudo python3 src/scratchClient.py -c config_wedo2_basic
```

The scratchClient monitoring gives a graphical view of the inputs and outputs of an adapter configuration.

WEDO 2 by bluetooth

This file contains 'not strict'-definitions.



Lego wedo2 adapter connections in basic mode.

The mode set values are removed from this config file. Piezo commands are not used. Voltage, current values are removed. This configuration is close to the scenario used in WeDo software.

### 6.8.21.9. Advanced setup

In advanced operation mode it is possible to handle the connected motor or sensors individually. Two motors can be controlled separately, or two same sensors can be read.

To operate the hub in this mode, an 'advanced' setup configuration is provided `config/config_wedo2_advanced.xml`.

This advanced configuration is a subset of the available options of the adapter.

The motor and sensor values have names with the port indicator '1', '2' included. For example the motion sensor values are named 'motion1\_distance', 'motion2\_distance'.

For the sensors, the values used are depending on the mode set. For the motion sensor, there is a 'motion1\_distance' and a 'motion1\_count' sensor value. When mode is changed, the last value reported in other sensor variables is not reset or changed.

In the configuration, the 'strict' parameter is set to 'true'. This allows to address sensor/actor by port position.

```
<parameter name='mode.strict' value='false' />
```

Typically, a motor is addressed by 'motor1' or 'motor2'.

Start scratchClient in advanced mode.

```
cd ~/scratchClient
sudo python3 src/scratchClient.py -c config_wedo2_advanced
```

The scratchClient monitoring gives a graphical view of the inputs and outputs of an adapter configuration.

WEDO 2 by bluetooth

This file contains 'strict'-definitions.

motor1_run	motor1_run	wedo2	button_pressed	button_pressed
motor1_brake	motor1_brake	adapter	button_released	button_released
motor1_drift	motor1_drift	wedo2Adapter	low_voltage_alert	notify_low_voltage_alert
motor2_run	motor2_run	Wedo2Adapter	high_current_alert	notify_high_current_alert
motor2_brake	motor2_brake		motion1_count	motion1_count
motor2_drift	motor2_drift		motion1_distance	motion1_distance
tilt1_reset	tilt1_reset		motion2_count	motion2_count
tilt2_reset	tilt2_reset		motion2_distance	motion2_distance
motor1	?	motor1	tilt1_tilt	tilt1_tilt
motor2	?	motor2	tilt1_angle_1	tilt1_angle_1
motion1_mode	?	motion1_mode	tilt1_angle_2	tilt1_angle_2
motion2_mode	?	motion2_mode	tilt1_crash_1	tilt1_crash_1
tilt1_mode	?	tilt1_mode	tilt1_crash_2	tilt1_crash_2
tilt2_mode	?	tilt2_mode	tilt1_crash_3	tilt1_crash_3
color	?	color	tilt2_tilt	tilt2_tilt
piezo_frequency	?	piezo_frequency	tilt2_angle_1	tilt2_angle_1
btle.name= LPF2 Smart Hub 2 I/O			tilt2_angle_2	tilt2_angle_2
btle.address= a0:e6:f8:6d:0e:67			tilt2_crash_1	tilt2_crash_1
btle.policy= name			tilt2_crash_2	tilt2_crash_2
mode.strict= true			tilt2_crash_3	tilt2_crash_3
			voltage	voltage
			current	current

Lego wedo2 adapter connections in advanced mode.

### 6.8.21.10. Complete setup

A full blown config file with all options is available. The main purpose is for test and development.

To operate the hub in this mode, an 'complete' setup is provided `config/config_wedo2_complete.xml`.

In the configuration, the 'strict' parameter is set to 'true'. This allows to address sensor/actor by port position.

```
<parameter name='mode.strict' value='true' />
```

Start scratchClient in complete mode.

```
cd ~/scratchClient
sudo python3 src/scratchClient.py -c config_wedo2_complete
```

The scratchClient monitoring gives a graphical view of the inputs and outputs of an adapter configuration.

WEDO 2 by bluetooth

This file contains both 'strict' and 'not strict'-definitions.

motor_brake	motor_run	wedo2	button_pressed	button_pressed
motor_brake	motor_brake	adapter	button_released	button_released
motor_drift	motor_drift	wedo2Adapter	low_voltage_alert	notify_low_voltage_alert
motor1_run	motor1_run	Wedo2Adapter	high_current_alert	notify_high_current_alert
motor1_brake	motor1_brake		motion_count	?
motor1_drift	motor1_drift		motion_distance	?
motor2_run	motor2_run		motion1_count	?
motor2_brake	motor2_brake		motion1_distance	?
motor2_drift	motor2_drift		motion2_count	24
motion_reset	motion_reset		motion2_distance	2.0
motion1_reset	motion1_reset		tilt_tilt	?
motion2_reset	motion2_reset		tilt_angle_1	?
tilt_reset	tilt_reset		tilt_angle_2	?
tilt1_reset	tilt1_reset		tilt_crash_1	?
tilt2_reset	tilt2_reset		tilt_crash_2	?
motor	74	motor	tilt_crash_3	?
motor1	-1	motor1	tilt1_tilt	9
motor2	-39	motor2	tilt1_angle_1	-4.0
motion_mode	0	motion_mode	tilt1_angle_2	15.0
motion1_mode	0	motion1_mode	tilt1_crash_1	17
motion2_mode	0	motion2_mode	tilt1_crash_2	4
tilt_mode	?	tilt_mode	tilt1_crash_3	11
tilt1_mode	2	tilt1_mode	tilt2_tilt	?
tilt2_mode	?	tilt2_mode	tilt2_angle_1	?
color	#5a6ebe	color	tilt2_angle_2	?
btle.name= LPF2 Smart Hub 2 I/O			tilt2_crash_1	?
btle.address= a0:e6:f8:6d:0e:67			tilt2_crash_2	?
btle.policy= name			tilt2_crash_3	?
mode.strict= true			voltage	?
			current	?


Lego wedo2 adapter connections in complete mode.

### 6.8.21.11. Sample scratch Program

A sample scratch program is provided in `scratch/wedo2/wedo2_sample.sb`.

Use the 'green flag' to start the program.

This scratch program can be used with basic, advanced or full configuration files.



Sample scratch program, start screen.




In the status line, the green sprite displays the button press events.


Alerts for voltage or current should be green. When alerts arrive, these turn to red and change to orange 5 secs later.

The current screen name is displayed.


The 'prev'- and 'next'-Buttons are used to navigate to the other screens. When a wedo2-hub is connected, the green button on the hub is scrolling the screen too.



Sample scratch program, device screen.



Sample scratch program, rgb screen.



Sample scratch program, motor screen.

**motion sensor**

	mode	dist	count	
	0	0.0	0.0	reset
	1	0.0	0.0	reset
	0	0.0	0.0	reset

☒ voltage alert
 ☐ current alert
 ☒ motion

Sample scratch program, motion screen.

**tilt sensor**

	mode	angle	tilt	crash	
	2	0.0	0.0	0.0	reset
		0.0		0.0	
				0.0	
	1	0.0	0.0	0.0	reset
		0.0		0.0	
				0.0	
	2	0.0	0.0	0.0	reset
		0.0		0.0	
				0.0	

☒ voltage alert
 ☐ current alert
 ☒ tilt

Sample scratch program, tilt screen.

**piezo frequency player**

p\_1

p\_2

piezo\_frequency 1000; 50

☒ voltage alert
 ☐ current alert
 ☒ piezo

Sample scratch program, piezo screen.

#### 6.8.21.12. Remarks



The scratch motor blocks are NOT related to the WDEO2-Adapter and can't be used to control the wedo2-motor.

There are error messages during startup of the adapter like

```
2017-03-16 23:34:53,987 - adapter.wedo2Adapter - ERROR - notify_data, no service for port 6
```

```
2017-03-17 00:31:03,768 - adapter.wedo2Adapter - ERROR - motion, data not parsed 04 02 00 00 00 40
```

These error messages are only important if they occur after a longer time of operation. Immediately after startup they are caused by a 'race condition' in the adapter code and no problem.

## 6.9. Adapters using pigpiod-Daemon

### 6.9.1. Ultrasonic Distance Sensor HC-SR04 by pigpiod-Daemon

HC-SR04 is a quite inexpensive ultrasonic distance sensor. The pulse output can be measured using pigpio daemon and python library.

The device needs a trigger connection and an echo connection. As the operating voltage for the device is 5V, there is the need for voltage adjustment for the echo line. Use a voltage divider or level shifter.

The GPIO pins used are configured in the config file. Any pins can be used.

Multiple sensors can be configured.

#### Installation

The python library for pigpio access needs to be installed.

```
sudo apt-get install python-pigpio
```

The daemon code is available in raspbian (2016-08-19).

#### Start Daemon

The daemon can be started by raspi-config. Or start by

```
sudo pigpiod
```

A basic configuration is in `config/config_hcsr04_pigpiod.xml`.

Start scratchClient.

```
cd ~/scratchClient
python src/scratchClient.py -c config_hcsr04_pigpiod
```

The values transferred to scratch are 'time' in seconds. To calculate the distance use the formula

$$\text{distance [cm]} = \text{time [s]} * 340 \text{ [m/s]} / 2 * 100 \text{ [cm /m]}$$

The speed of sound in air is assumed to be 340 [m/s], which changes with temperature.

## 6.10. Pimoroni MICRO DOT PHAT board


Pimoroni offers a 6 digit 7\*5 dot display "MICRO DOT PHAT" with 3 IS31FL3730 chips. The adapter was written using code from pimoroni library.

Installation needs extra libraries numpy and smbus

```
sudo pip install numpy
sudo apt-get install python-smbus
sudo pip3 install numpy
sudo apt-get install python3-smbus
```

I2C-Bus needs to be enabled.

Hello-world-display:



The character to font translation does not contain all possible chars. If needed, look into the adapter code which has a 'pixel'-graphics setup capability. Example:

```
font_5_7[ 'ç' ] = ""
      : * :
      :   :
      : * :
      : * :
      : * :
      : * :
      :*  *:
      : ***:
      ""
```

Just add chars as needed.

There is a sample config file in `config/config_microdotphat.xml`.

## 6.11. Pimoroni SCROLL PHAT HD board

Pimoroni offers a 7\*17 LED display "SCROLL PHAT HD" with an IS31FL3731 chip. The adapter code was written using code from pimoroni library.

The adapter is primarily used as pixel output. Text output is possible, but limited to a few characters only.

The command variable can be used to issue various pixel set commands:

- 'clear'
- 'clear;x;y' clear pixel
- 'clear;x;y;bright' set pixel to brightness
- 'pixel;x;y' set pixel to default brightness
- 'pixel;x;y;bright' set pixel to brightness
- 'box;x;y;width;height' set area to default brightness
- 'box;x;y;width;height;bright' set area to brightness

x is pixel position [0..16] y is pixel position [0..6] width is box width [1..17] height is box height [1..7] bright is brightness [0.0..1.0] Separator is ';'.

Wrong commands are silently ignored.

Scratch does not send out a broadcast message to remote sensor network on each variable set commands when in one block. Commands need to be separated by a wait(0) block.



Installation needs extra libraries numpy and smbus

```
sudo pip install numpy
sudo apt-get install python-smbus
sudo pip3 install numpy
sudo apt-get install python3-smbus
```

. I2C-Bus needs to be enabled.

The character to font translation does not contain all possible chars. If needed, look into the adapter code which has a 'pixel'-graphics setup capability. Example:

```
font_5_7[ 'ç' ] = ""
      : * :
      :   :
      : * :
      : * :
      : * :
      : * :
      :*  *:
      : ***:
      ""
```

```
      :*      *:
      : ***  :
" " "
```

Just add chars as needed.

There is a sample config file in `config/config_scrollphatht.xml`.

There is a sample scratch script in `scratch/scrollphathtd/scroll_phat_hd.sb`.

## 6.12. Minecraft on PI adapter

On Raspberry Pi, raspbian, there is minecraft in a local mode-version available. For this edition, a python api exists.

User guide is [www.raspberrypi.org/learning/getting-started-with-minecraft-pi](https://www.raspberrypi.org/learning/getting-started-with-minecraft-pi) [<https://www.raspberrypi.org/learning/getting-started-with-minecraft-pi>]

The API is described in [stuffaboutcode.com/p/minecraft-api-reference](http://www.stuffaboutcode.com/p/minecraft-api-reference) [<http://www.stuffaboutcode.com/p/minecraft-api-reference.html>]

A sample scratch script is in `scratch/minecraft/minecraft.sb`

---

## Chapter 7. Configurations for Devices

scratchClient allows to build configurations from adapters and adjust these to devices. A sample is pi2go, a two wheel robot with sensors, actors of different type.

### 7.1. Two wheel robot 'pi2go'

The small robot car offers LED, sensors, motors and buttons. Combined from various adapters, this robot can be controlled from scratch.

A config file is in `config/config_pi2go.xml`.

A sample scratch script is in `scratch/pi2go/pi2go.sb`.

### 7.2. ExplorerHatPro

ExplorerHatPro from pimoroni offers adc, motor hbridge, 5V tolerant inputs and outputs, four darlington drivers and 8 capacitive pads.

A config file is in `config/config_explorerhat_pro.xml`.

## Chapter 8. GUI, Web Interface for Monitoring

There is a web based user interface for the tool. By default, the scratchClient opens the port only for local connections. When remote access is needed, this needs to be enabled by command line switch 'guiRemote'.

The url in browser is for local access <http://localhost:8080>

For remote access, you need to have the hostname in the network, or the ip-address of the machine. [http://\[hostname\]:8080](http://[hostname]:8080)

### 8.1. GUI Functions

The functionality is

- show config file
- display graphical view of adapters
- monitor events
- trigger events
- set values


#### 8.1.1. Monitoring, Controlling

The adapter view receives updates from scratchClient. When broadcasts arrive, the connectors are highlighted. Values change are displayed. Most current events are listed on screen in a text list.

Broadcasts (input or output) can be stimulated by clicking to the connectors. Input broadcasts are sent to the adapter, output broadcasts are sent to scratch.

Values can be edited and send. Click on the connector, an input box will open and values are sent when enter key is pressed.

Input values are sent to the adapter, output values are sent to scratch. The web interface is build based on configuration.



The sample screen shot shows a servo adapter and two button adapters. 'servo\_A' is a value sent from scratch to the adapter. Double click in this name opens an editor window for the value. 's0\_pressed' is a broadcast sent from the button-adapter to scratch. Double clicking this name sends the broadcast to scratch.

## 8.2. Compatibility

The interface was verified to work with Midori, Firefox and Chrome.



---

## Chapter 9. Installation, Operation

### 9.1. Quick Installation

The following installation procedure is for the impatient people. Open a terminal and execute the following lines.

```
cd ~
wget -O scratchClient.tar.gz http://heppg.de/download/scratchClient/scratchClient.tar.gz
tar xzf scratchClient.tar.gz
chmod +r -R scratchClient/

sudo apt-get update
sudo apt-get install python-pip python-dev python-smbus
sudo apt-get install python3-pip python3-dev python3-smbus
sudo pip install tornado mako==1.0.6 spidev pyserial intelhex
sudo pip3 install tornado mako==1.0.6 spidev pyserial intelhex
```

The install steps are explained in more detail in the following sections.

### 9.2. Step by Step Installation

The following sections guide through the installation steps.

#### 9.2.1. Base Packages Installation

There are a few operating system packages and a few python modules needed.

When installing new packages, it is generally a good idea to have current versions of the packages available. For this, the 'apt-get update' is used.

```
sudo apt-get update
sudo apt-get install python-pip python-dev python-smbus
sudo pip install tornado mako==1.0.6 spidev pyserial intelhex
```

It is recommended to use python3. The following commands are needed

```
sudo apt-get update
sudo apt-get install python3-pip python3-dev python3-smbus
sudo pip3 install tornado mako==1.0.6 spidev pyserial intelhex
```

#### 9.2.2. ScratchClient Software Installation

scratchClient is a python program and requires no special compile step. The files are unpacked to a local directory.

The chmod command ensures that the files are readable also for other users.

On the download page, there are usually some version hints. download page [[http://heppg.de/ikg/wordpress/?page\\_id=6](http://heppg.de/ikg/wordpress/?page_id=6)]

The files are downloaded to user home directory, usually /home/pi.

```
cd ~
wget -O scratchClient.tar.gz http://heppg.de/download/scratchClient/scratchClient.tar.gz
tar xzf scratchClient.tar.gz
chmod +r -R scratchClient/
```

*Verification of installation.*

You should have /home/pi/scratchClient/src/scratchClient.py and other files.

Start scratchClient, preferred with python3

```
cd ~/scratchClient
python3 src/scratchClient.py -h
```

Expected output is a list of command line options.

#### 9.2.3. SPI install

Some devices are connected by SPI. When such devices are needed, SPI drivers are needed.

On raspberryPi, you can enable SPI by using raspi-config.

```
sudo raspi-config
```

To install it manually, edit raspi-blacklist

```
sudo leafpad /etc/modprobe.d/raspi-blacklist.conf
```

The following entry must be available:

```
#blacklist spi-bcm2708
```

Delete all other lines which contain spi-bcm2708

Reboot recommended.

#### *Validation*

Validate installed drivers. 'lsmod' lists installed drivers.

```
lsmod | grep -e spi_bcm2708
```

## 9.2.4. I2C install

For using I2C, additional software needs to be installed.

```
sudo apt-get install python-smbus
```

On raspberryPi, you can enable I2C by using raspi-config.

```
sudo raspi-config
```

In addition to this driver, there is i2c-dev needed. Starting this manually is

```
sudo modprobe i2c-dev
```

To manually enable the I2C-Driver: edit raspi-blacklist

```
sudo leafpad /etc/modprobe.d/raspi-blacklist.conf
```

The following entry must be available, or no entry at all:

```
#blacklist i2c-bcm2708
```

Delete all other lines which contain i2c-bcm2708

In /etc/modules , add a line with i2c-dev. This makes i2c-dev permanent.

Reboot recommended.

*Validation* Validate installed drivers. 'lsmod' lists installed drivers.

```
lsmod | grep -e i2c
```

Result should contain

```
i2c_dev          6709  2
i2c_bcm2708      6200  0
```

In folder /dev, there is a directory /dev/i2c-1 available.

It is recommended to install

```
sudo apt-get install i2c-tools
```

In these tools, i2cdetect helps to find out connected devices with their adress.

## 9.2.5. Text to speech install

When using the text to speech adapter 'festival', the package 'festival' is needed.

```
sudo apt-get install festival
```

When using the text to speech adapter 'pico2wave', the package 'pico2wave' is needed.

```
sudo apt-get install libtts-pico-utils
```

### 9.2.6. DMA library support (RPIO2)

For DMA based adapters, a DMA-library is needed. In scratchClient releases prior to 2016-01-02, the RPIO.PWM-library was used. As this RPIO.PWM-library did not support Raspberry Pi2 or Pi3, a local patch 'RPIO2.PWM' was created.

This RPIO2.PWM library needs additional installation

```
cd ~/scratchClient/RPIO2
sudo sh install.sh
```

## 9.3. Custom config files

Custom config files can be placed on disk where appropriate.

The tool encourages to use the configuser directory ~/scratchClient/configuser.

The install procedures do not wipe this directory. Be sure to backup regularly.

The supplied config files samples are in ~/scratchClient/config.

## 9.4. Start scratchClient

In scratch, enable the 'remote network connection'. This is needed once for a project; this setting is persisted in the project file. Start with (user pi)

```
cd ~/scratchClient
sudo python3 src/scratchClient.py -config [config_file_name.xml]
```

For gpio access, SPI, I2C-adapters, it is usually required to run the program with root permissions. Some adapters run with 'normal' permissions, e.g. the text-to-speech adapter, websocket adapters or alike.

scratch needs to be started separately. Create a shell script if you need both programs scratchClient and scratch to be started with one command.

The code generates a 'scratchClient.pid'-File, which may remain in base directory. There for, start up in a dedicated home directory (~/scratchClient) is recommended.



On one machine, the process may only be started once. If the process starts up, but quits after some 30 to 60 sec, then possibly another instance is running.

Use command line '-h' to see options.

```
cd ~/scratchClient
python src/scratchClient.py -h
```

```
-host <ip>           Scratch Host ip or hostname, default 127.0.0.1
-port <number>       Port number, default 42001

-c <configfile>
-config <configfile> Name of config xml-file, default config/config.xml
                     There is a lookup strategy used: add xml extension when needed,
                     check if file exists literally. Then try to find a matching file
                     in configuser dir, next in config dir. Try to add 'config_' to
                     filename also.

-C <configfile>       Name of config xml-file, default config/config.xml
                     There is NO lookup strategy used, only literal.

-l <logconfigfile>    Name of a log config file. Supersedes -v, -d setting.
                     Relative path or absolute file name.

-gpioLib              set the gpilibrary, default 'RPi_GPIO_GPIOManager'
```

deprecated

-singletonPID	when multiple instances are running, report other instance and terminate
-singletonIPC	when multiple instances are running, terminate other instance used port 42003 (default from 2017-02-14)
-singletonNONE	no singleton policy applied. For debug only

debug and test switches

-validate	Validate config and terminate.
-h	
-help	print command line usage and exit
-v	verbose logging (see also -l option)
-d	debug logging (see also -l option)
-license	print license and exit.
-changes	print changes list and exit.
-version	print version and exit.

Most of the commands are quite self-explaining. If you want to see more information on screen, use verbose switch. Debugging switch shows even more, but then logging uses a lot of CPU.

### config:

For config file lookup, there is a lookup policy available. The first file found wins the game:

add xml extension when not available.

- check file name given literally.
- look in ./userconfig directory, then in ./config/

add prefix 'config\_' to filename if no path is given.

With this policy, file names can be abbreviated.

### host:

if scratch is located on a different computer, then give the target address here.

### port:

generally not needed to use a different port.

### nogui:

does not start the web app server inside scratchClient. Less memory usage.

### guiRemote:

allows remote access to web gui.

### validate:

check the config file for correctness.

### singleton

It is needed that scratchClient is running only once on one computer. Till 2017-02-14, the policy used was a pid-file in installation directory and stop when another instance was already running.

From 2017-02-14, there is another policy 'IPC' which terminates the earlier started instance. This singleton manager uses socket 42003 to connect to an already running instance and requests to terminate.

To use the IPC based policy, add -singletonIPC to the command line or leave empty.

To use the legacy PID based policy, add -singletonPID to the command line.

## 9.5. Application Logging

scratchClient uses python logging package and writes log statements to console.

The log files are json based, but allow to have comments in '# comment' syntax. These comments are removed when reading and parsing the files.

The logging config files are

scratchClient/logging/logging.json for regular output

scratchClient/logging/logging\_verbose.json when -v switch is on command line

scratchClient/logging/logging\_debug.json when -d switch is on command line

If you need to use custom logging, then there is the possibility to define an own log config file and define it on command line with the '-l'-option.

### 9.5.1. Logging into Linux desktop notifications.

Linux provides infrastructure to push notifications to the desktop.

This is enabled by a custom logging handler which interfaces to the DBUS mechanism.

A sample logging config file is in scratchClient/logging/logging\_notification.json.

The file uses helper.notificationHandler.NotificationHandler, based on notify2-package.

```
{  ## This listing only shows differences to regular log config
  "version": 1,
  "disable_existing_loggers": false,

  "loggers": {
    "": {
      "level": "WARN",
      "propagate": true,
      "handlers": [ "default",
                    "notification"  ## add new handler for notifications.
                  ]
    },
    "handlers": {
      "default": { ## shortened
      },
      "notification": { ## Notification Handler
        "formatter": "notification",
        "class": "helper.notificationHandler.NotificationHandler",
        "level": "WARN"
      }
    },
    "formatters": {
      "standard": {
        "format": "%(asctime)s [%(levelname)s] %(name)s - %(lineno)d: %(message)s"
      },
      "notification": {
        "format": "%(message)s"  ## For screen output only provide message.
      }
    }
  }
}
```

This special handler helper.notificationHandler.NotificationHandler needs some preparation on linux level.

```
pip3 install notify2
```

```
apt-get install libnotify-bin
```

Not on all systems the notification-daemon is started

```
/usr/lib/notification-daemon/notification-daemon
```

check system by entering the command into a terminal.

```
notify-send 'notify-system' 'working'
```

The desktop should show a popup with the message.

## 9.6. Stop scratchClient

Stop with ctrl-c in console. Takes a few seconds till all background threads quit.

If for any reason the code refuses to quit, get the processId and kill the process

```
sudo ps -ef | grep python
sudo kill -9 [processId]
```

When scratchClient is the only process running with python3, then you can use

```
killall -9 python3
```

in a terminal window.

## 9.7. Problems running scratchClient

### 9.7.1. Multiple Instances running

Some common problems in running scratchClient are, that no sensor inputs are arriving in scratch. Check the following list for possible problems.

- is scratchClient started? It might stop running due to problems in configuration file. Check console log for details.
- is scratchClient started? It might stop running due to a previous instance leaving a scratchClient.pid-File. Delete this file.
- multiple instances of scratchClient started ? Check with `ps -ef | grep python` and stop other instances with `kill -9 <pid>`
- multiple instances of scratch ? Only one instance of scratch is allowed having the remote sensor protocol started. Stop other instances.

Scratch will read inputs from scratchClient faster than these are processed internally. The effect is that scratch is displaying old data. In this case, decrease update rates of polling sensors and work on performance of scratch code.

### 9.7.2. Installation Problems

```
pi@raspberrypi:~/scratchClient $ python src/scratchClient.py -config config/config_arduino_uno.xml
Traceback (most recent call last):
  File "src/scratchClient.py", line 151, in <module>
    import server.scratchClientServer
  File "/home/pi/scratchClient/src/server/scratchClientServer.py", line 33, in <module>
    import cherrypy
ImportError: No module named cherrypy
pi@raspberrypi:~/scratchClient $
```

The installation of cherrypy is missing. Run `sudo pip install cherrypy routes mako ws4py spidev`

## 9.8. Scratch Autostart

When auto start for scratch is needed, there are things to execute

- start scratch into presentation mode
- enable remote connections (without user interaction)
- issue a 'green flag' event.

Starting scratch and scratchClient can be in any order. Starting does not need to be manual, but can be from init.d or other

### 9.8.1. Start scratch into presentation mode

Starting scratch into presentation mode can be done on RaspberryPi by adding the 'presentation' keyword to the command line.

```
scratch presentation [scriptname]
```

When starting scratch from a background process then add the X display


```
scratch presentation [scriptname] -display :0
```

This will be needed when you 'remote login' to a linux system.

Starting with 'presentation'-flag also issues a green-flag-event.

### 9.8.2. Enable remote connection (without user interaction)

When a project uses remote connection, this is stored in the project file and enabled again when project is reloaded. Unfortunately, there is some user interaction needed to enable it.



In newer scratch releases for raspberry (e.g. 2015-11-11), there is a config file setting which bypasses this dialog.

```
remoteconnectiondialog = 0
```

Look for file `home/pi/.scratch.ini` and add this statement. If this file is not available, just create it.



Files starting with '.' are hidden files in linux.

With filemanager, enable 'show hidden files' in order to see this file.

### 9.8.3. Green Flag Event

When scratch ist started from the command line with the 'presentation'-flag, then there is also a green-flag-event issued.


When a green flag event is needed when scratchClient is started, then use `adapter.broadcast.ScratchStartclickedAdapter`.

## 9.9. scratchClient usage scenario

ScratchClient and scratch usually run on same machine, but other scenario are possible.

### 9.9.1. Local setup

In general, scratchClient and scratch will run on same machine.




No special command line switches are needed to support this scenario.

**Table 9.1. Firewall settings**

Module	Port	computerA
NA	NA	NA

### 9.9.2. Distributed setup A

scratchClient and scratch can run on different machines. I use this scenario, when debugging scratch code on a more performant machine than a raspberry pi.




When starting `scratchClient`, use the `'-host'`-command line parameter and add the ip-address (or hostname) of the machine where `scratch` is located. Of course, these two machines need to be connected by a network.

**Table 9.2. Firewall settings**

Module	Port	computerA	computerB
scratch	42001	out	in

### 9.9.3. Distributed setup B

`scratchClient` and `scratch` can run on different machines. The browser used to look into the monitoring gui of `scratchClient` can be used from a third machine.



When starting `scratchClient`, use the `'-host'`-command line parameter and add the ip-address (or hostname) of the machine where `scratch` is located. Use `'-guiRemote'` to allow remote access for browser. Of course, these machines need to be connected by a network.

**Table 9.3. Firewall settings**

Module	Port	computerA	computerB	computerC
scratch	42001	out	in	
browser	8080	in		out



---

## Chapter 10. Extending Functionality

### 10.1. Hacking the code

When you need a new adapter, not provided in the list. Add a new file to Directory 'adapter' named myadapter.py (choose the name according to the functionality). Place a class there named MyAdapter (again, choose your functional name). Derive it from adapter.Adapter, and place `__init__` and command methods, as well as the output methods. Produce the xml-configuration for this, and give it a try. Testing new Adapters: add your adapter config to an xml-file, start the code in simulation mode with gui. If configurationManager reads the config successfully, you will be able to place commands and values to the input side, and see what happens to the simulated gpio.

Then stop and restart in real live mode. This will attach the gpios and drive whatever is attached there.

Using other gpio-driver as Rpi.GPIO

There are people using Wiring, or other python libraries to access Gpio on the pi. Copy RPiGpio.py, which is a wrapper for the RPI-GPIO, and copy to a 'MyGpio.py'-File. In the new file, modify the imports and the method content to whatever is needed to run your library. On the command line, use `-gpio [yourGpioPath]`, for this example it is „adapter.MyGpio“. Generally, as this is running as a standalone client, with most probably no other code in parallel, this will be rarely needed.

### 10.2. GPIO Names

GPIO names used are configurable in config/portMapping.xml. This file maps the gpioNumbers from BCM numbering to other names, either GPIO-, PIN-numbers or whatever else needed. GPIO08 is GPIO numbering in BCM style.

```
<port gpioNumber='8' name='GPIO08' />
```

IKG.IO.3 is used for a special adapter-board.

```
<port gpioNumber='18' name='IKG.IO.3' />
```

Pin header names. The version-ambiguities are resolved by appending the version number to the port name

```
<port gpioNumber='0' name='P1-03V1' />
<port gpioNumber='2' name='P1-03V2' />
```

The mapped names can be used in config files.

### 10.3. Python Compatibility

The code is developed and tested in python 2.7.3. Recent updates move towards python3. It is recommended to use python3 only.

External needed for basic operation are

- Rpi.GPIO 0.5.3a or 0.5.4a
- RPIO
- tornado for the web gui
- mako

Other libraries are needed dependedent on functionality used.

Scratch is Version 1.4, as there the remote sensor protocol is available. There is an experimental integration to scratchx and scratch2 on raspberry.

### 10.4. License

GNU General Public License

Copyright (C) 2013, 2018 Gerhard Hepp

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin St, Fifth Floor, Boston, MA 02110, USA

---

## Chapter 11. Adapter Documentation

Technical description of adapters, input, output values and events and config snippets.

### 11.1. ADC\_ADS1015\_Input

AD-Interface for ADS1015.

AD-Interface for ADS1015.

#### Class

adapter.i2cAdapter.ADC\_ADS1015\_Input

#### Output Values

adc	intType [131]	ADC value
-----	---------------	-----------

#### Parameter (mandatory)

adc.channel	intType [131]	the adc-channel [0..3]
i2c.address	intOrHexType [131]	address is '0x48' for adafruit ADS1015-breakout
i2c.bus	intType [131]	bus is '1' for RPi Release 2
poll.interval	floatType [131]	poll interval in secs, e.g. 0.05

#### Parameter (optional)

adc.pga	intType [131]	Programmable Gain Amplifier setting, default 4096, [256, 512, 1024, 2048, 4096, 6144]
adc.sps	intType [131]	Sample Per Second, default 250 [ 128, 250 , 490, 920, 1600, 2400, 3300 ]. For scratch, fast rates are not needed.

#### Sample configuration

```
<adapter class='adapter.i2cAdapter.ADC_ADS1015_Input' name='adc_A2'>
  <description>ADC-Value from ADS1015 (single ended)</description>
  <output_value name='adc'>
    <sensor name='adc_A2' />
  </output_value>

  <parameter name='poll.interval' value='0.05' />

  <!-- bus is '1' for RPi Release 2 -->
  <parameter name='i2c.bus' value='1' />

  <!-- address is '0x48' for adafruit ADS1015 -->
  <parameter name='i2c.address' value='0x48' />

  <parameter name='adc.channel' value='2' />
  <!-- optional -->
  <parameter name='adc.sps' value='250' />
  <parameter name='adc.pga' value='6144' />

</adapter>
```

### 11.2. ADC\_DAC\_PCF8591

PCF8591-Adapter, 4 channel ADC and 1 channel DAC.

The adapter can read 4 channels in sequence; the DAC output is optional.

#### Class

adapter.i2cAdapter.ADC\_DAC\_PCF8591

## Output Values

adc_0	intType [131]	0..255
adc_1	intType [131]	0..255
adc_2	intType [131]	0..255
adc_3	intType [131]	0..255

## Parameter (mandatory)

dac.enable	booleanType [131]	dac enabled.
i2c.address	intType [131]	Base address, int or hex.
i2c.bus	intType [131]	Bus snumber, usually 1 on RPi.
poll.interval	floatType [131]	poll rate.

## Parameter (optional)

average.cnt	intType [131]	Number of measurements in an average. 1..10 are good values.
average.enable	booleanType [131]	poll rate.

## Sample configuration

```

<adapter class='adapter.i2cAdapter.ADC_DAC_PCF8591' name='4-channel Light sensor'>
  <description>4 channel light sensor.</description>

  <output_value name="adc_0">
    <sensor name="light_D5"/>
  </output_value>
  <output_value name="adc_1">
    <sensor name="light_D6"/>
  </output_value>
  <output_value name="adc_2">
    <sensor name="light_D8"/>
  </output_value>
  <output_value name="adc_3">
    <sensor name="light_D9"/>
  </output_value>

  <!-- bus is '1' for RPi Release 2 -->
  <parameter name='i2c.bus' value='1' />

  <!-- Depending on address select, the bus address is
        '0x40' for all address lines low.
        -->
  <parameter name='i2c.address' value='0x48' />
  <parameter name='dac.enable' value='false' />
  <parameter name='poll.interval' value='0.1' />

  <parameter name='average.enable' value='true' />
  <parameter name='average.cnt' value='5' />
</adapter>

```

## 11.3. ADC\_MCP3008\_10\_Input

ADC interface MCP3008, 8 channel ADC

Interface to adc MCP3008, 10bit.

### Class

adapter.adc\_zone.ADC\_MCP3008\_10\_Input

## Output Values

adc	intType [131]	value int 0..1023
-----	---------------	-------------------

**Parameter (mandatory)**

adc.channel	intType [131]	adc channel (0,7).
poll.band	intType [131]	deadband zone +- last value, only if new value is outside this band it is reported.
poll.interval	floatType [131]	poll rate in seconds, default 0.05.
spi.bus	intType [131]	bus number, 0, 1
spi.device	intType [131]	spi bus selector, 0, 1

**Sample configuration**

```

<adapter class='adapter.adc.ADC_MCP3008_10_Input' name='adc_A'>

  <description>ADC-Value</description>

  <output_value name='adc'>
    <sensor name='adcA' />
  </output_value>

  <parameter name='poll.interval' value='0.066' />
  <parameter name='poll.band' value='2' />
  <parameter name='spi.bus' value='0' />
  <parameter name='spi.device' value='0' />
  <!-- channel 0..7 -->
  <parameter name='adc.channel' value='7' />
</adapter>

```

**11.4. ADC\_MCP3202\_10\_Input**

ADC interface MCP3202

Interface to adc MCP3202, 10bit.

**Class**

adapter.adc.ADC\_MCP3202\_10\_Input

**Output Values**

adc	intType [131]	value 0..1023
-----	---------------	---------------

**Parameter (mandatory)**

adc.channel	intType [131]	adc channel (0,1).
poll.interval	floatType [131]	poll rate in seconds, default 0.05.
spi.bus	intType [131]	bus number, 0, 1
spi.device	intType [131]	spi bus selector, 0, 1

**Sample configuration**

```

<adapter class='adapter.adc.ADC_MCP3202_10_Input' name='adc_A'>

  <description>ADC-Value</description>

  <output_value name='adc'>
    <sensor name='adcA' />
  </output_value>

  <parameter name='poll.interval' value='0.066' />
  <parameter name='spi.bus' value='0' />
  <parameter name='spi.device' value='0' />
  <parameter name='adc.channel' value='0' />
</adapter>

```

**11.5. ADC\_MCP3202\_10\_Zone\_Input**

ADC interface MCP3202, zone value mapping

Interface to adc MCP3202, 10bit. The input values are mapped to zones.

Zone values can be used for threshold values, e.g. 0..511 to 0, 512..1023 to 1023.

Zone values can be used for value mapping, e.g. 0..99 to 'left', 100..923 to 'middle', 924..1023 to 'right'.

## Class

adapter.adc\_zone.ADC\_MCP3202\_10\_Zone\_Input

## Output Values

adc	stringType [132]	value int values or string
-----	------------------	----------------------------

## Parameter (mandatory)

adc.channel	intType [131]	adc channel (0,1).
poll.interval	floatType [131]	poll rate in seconds, default 0.05.
spi.bus	intType [131]	bus number, 0, 1
spi.device	intType [131]	spi bus selector, 0, 1

## Sample configuration

```
<adapter class='adapter.adc_zone.ADC_MCP3202_10_Zone_Input' name='adc_A_Zone'>

  <description>ADC-Value</description>

  <output_value name='adc'>
    <sensor name='adcA_zone' />
  </output_value>

  <extension>
    <zone from='0' to='99' value='left' />
    <zone from='100' to='923' value='middle' />
    <zone from='924' to='1023' value='right' />
  </extension>

  <parameter name='poll.interval' value='0.066' />
  <parameter name='spi.bus' value='0' />
  <parameter name='spi.device' value='0' />
  <parameter name='adc.channel' value='0' />
</adapter>
```

## 11.6. ADC\_MCP3202\_12\_Input

ADC interface MCP3202

Interface to adc MCP3202, 12bit.

Supports averaging (filter).

## Class

adapter.adc.ADC\_MCP3202\_12\_Input

## Output Values

adc	intType [131]	value 0..4095
-----	---------------	---------------

## Parameter (mandatory)

adc.channel	intType [131]	adc channel (0,1).
-------------	---------------	--------------------

filter.depth	intType [131]	0,1: no filtering; 2..10: filtering
poll.interval	intType [131]	poll rat ein seconds, default 0.05.
spi.bus	intType [131]	bus number, 0, 1
spi.device	intType [131]	spi bus selector, 0, 1

### Sample configuration

```
<adapter class='adapter.adc.ADC_MCP3202_12_Input' name='adc_A'>

  <description>ADC-Value</description>

  <output_value name='adc'>
    <sensor name='adcA' />
  </output_value>

  <parameter name='filter.depth' value='8' />

  <parameter name='poll.interval' value='0.066' />
  <parameter name='spi.bus' value='0' />
  <parameter name='spi.device' value='0' />
  <parameter name='adc.channel' value='0' />
</adapter>
```

## 11.7. BipolarStepper

Drives a bipolar stepper motor.

Bipolar steppers need four half bridge drivers, e.g. LM293

### Class

adapter.stepper.BipolarStepper

### Input Events

startMotor	not used
stopMotor	not used

### Input Values

speed	floatType [131]	time between steps. The smaller, the faster the motor will run.
target	floatType [131]	Target is 'step points' on an absolute scale.

### Sample configuration

```
<adapter class='adapter.stepper.BipolarStepper' name='stepper'>

  <description>stepper control</description>

  <gpio port='GPIO25' alias='br0.0'>
    <default dir='OUT' pull='PUD_OFF' />
    <active dir='OUT' pull='PUD_OFF' />
  </gpio>
  <gpio port='GPIO24' alias='br0.1'>
    <default dir='OUT' pull='PUD_OFF' />
    <active dir='OUT' pull='PUD_OFF' />
  </gpio>

  <gpio port='GPIO23' alias='br1.0'>
    <default dir='OUT' pull='PUD_OFF' />
    <active dir='OUT' pull='PUD_OFF' />
  </gpio>
  <gpio port='GPIO18' alias='br1.1'>
    <default dir='OUT' pull='PUD_OFF' />
    <active dir='OUT' pull='PUD_OFF' />
  </gpio>
```

```
<gpio port='GPIO22' alias='en0'>
  <default dir='OUT' pull='PUD_OFF' />
  <active dir='OUT' pull='PUD_OFF' default='high' />
</gpio>
<gpio port='GPIO27' alias='en1'>
  <default dir='OUT' pull='PUD_OFF' />
  <active dir='OUT' pull='PUD_OFF' default='high' />
</gpio>

<input name='startMotor'>
  <broadcast name='startMotor' />
</input>

<input name='stopMotor'>
  <broadcast name='stopMotor' />
</input>

<input_value name='speed'>
  <variable name='speed' />
</input_value>

<input_value name='target'>
  <variable name='target' />
</input_value>

</adapter>
```

## 11.8. Blink\_Adapter

USB adapter for blink-device.

'blink(1)' is a small USB-device with two LED. See <https://blink1.thingm.com/>

The color commands do not use the device timed fade.

Needs installation of pyusb.

### Class

adapter.usbAdapter.Blink\_Adapter

### Sample configuration

```
<adapter class='adapter.usbAdapter.Blink_Adapter' name='blink_1'>
  <description></description>

  <!-- led_0 is 'all led' -->
  <input_value name='led_0'>
    <variable name='led_all' />
    <variable name='led_0' />
  </input_value>

  <input_value name='led_1'>
    <variable name='led_1' />
  </input_value>

  <input_value name='led_2'>
    <variable name='led_2' />
  </input_value>

</adapter>
```

## 11.9. CAP1208Adapter

Reading capacitive touch from CAP1208.

The code for this adapter was written based on code from pimoroni.

The chip is used in explorer hat pro. The numbering on the pcb is different from the chip internal numbering.



## Class

adapter.cap1xxxAdapter.CAP1208Adapter

## Output Event

s0_pressed	s0 activated
s0_released	s0 released
s1_pressed	s0 activated
s1_released	s1 released
s2_pressed	s0 activated
s2_released	s2 released
s3_pressed	s0 activated
s3_released	s3 released
s4_pressed	s0 activated
s4_released	s4 released
s5_pressed	s0 activated
s5_released	s5 released
s6_pressed	s0 activated
s6_released	s6 released
s7_pressed	s0 activated
s7_released	s7 released

## Parameter (mandatory)

i2c.address	intOrHexType [131]	address is '0x48' for adafruit ADS1015-breakout
i2c.bus	intType [131]	bus is '1' for RPi Release 2
poll.interval	floatType [131]	poll interval in secs, e.g. 0.05

## Sample configuration

```

<adapter class='adapter.cap1xxxAdapter.CAP1208Adapter' name='cap'>
  <description>Capacitive sensors</description>

  <output name='s0_pressed'>
    <broadcast name='cap_5_pressed' />
  </output>
  <output name='s0_released'>
    <broadcast name='cap_5_released' />
  </output>

  <output name='s1_pressed'>
    <broadcast name='cap_6_pressed' />
  </output>
  <output name='s1_released'>
    <broadcast name='cap_6_released' />
  </output>

  <output name='s2_pressed'>
    <broadcast name='cap_7_pressed' />
  </output>
  <output name='s2_released'>
    <broadcast name='cap_7_released' />
  </output>

  <output name='s3_pressed'>
    <broadcast name='cap_8_pressed' />
  </output>
  <output name='s3_released'>
    <broadcast name='cap_8_released' />
  </output>

  <output name='s4_pressed'>

```

```

        <broadcast name='cap_1_pressed' />
    </output>
    <output name='s4_released'>
        <broadcast name='cap_1_released' />
    </output>

    <output name='s5_pressed'>
        <broadcast name='cap_2_pressed' />
    </output>
    <output name='s5_released'>
        <broadcast name='cap_2_released' />
    </output>

    <output name='s6_pressed'>
        <broadcast name='cap_3_pressed' />
    </output>
    <output name='s6_released'>
        <broadcast name='cap_3_released' />
    </output>

    <output name='s7_pressed'>
        <broadcast name='cap_4_pressed' />
    </output>
    <output name='s7_released'>
        <broadcast name='cap_4_released' />
    </output>

    <parameter name='poll.interval' value='0.075' />

    <!-- bus is '1' for RPi Release 2 -->
    <parameter name='i2c.bus' value='1' />
    <parameter name='i2c.address' value='0x28' />
</adapter>

```

## 11.10. CommunicationAdapter

Remote communication adapter.

Needs the scratchCommunicationServer to be started.

For the configuration, an adapter-specific syntax is used.

There is a limit on inputs, max 32 commands are supported.

### Class

adapter.remote.CommunicationAdapter

### Parameter (mandatory)

group	stringType [132]	The scratchCommunicationServer can handle different (isolated) groups. Only scratchClients in same group can communicate.
server	stringType [132]	IP-Address of computer where scratchCommunicationServer is located.

### Sample configuration

```

<adapter class='adapter.remote.CommunicationAdapter' name='communication_adapter'>

    <!-- Adapter uses native Syntax -->
    <description>Remote communication adapter. </description>

    <extension>
        <!-- these commands are received from scratch and forwarded to a remote attached scratchClient -->
        <remote type='forward'>
            <broadcast name='command_B' />
        </remote>

        <!-- these commands are received from a remote attached scratchClient and sent to local scratchClient -->
    </extension>
</adapter>

```

```

    <remote type='receive'>
      <broadcast name='command_A' />
    </remote>
  </extension>
  <parameter name="group" value="groupA" />
  <parameter name="server" value="192.168.2.108" />

</adapter>

```

## 11.11. DMA\_PWM

DMA based PWM adapter.

Needs installation of RPIO2-package.

Supports 0..100% pwm signals.

### Class

adapter.dma\_pwm.DMA\_PWM

### Input Values

rate	floatType [131]	pwm rate [0..100]
------	-----------------	-------------------

### Parameter (mandatory)

frequency	floatType [131]	Frequency in [Hz] for the pwm signal.
rate	floatType [131]	initial pwm rate in [%].

### Sample configuration

```

<adapter class='adapter.dma_pwm.DMA_PWM' name='rgb_B'>
  <description>Sample DMA PWM, needs installation of RPIO2-package.</description>

  <gpio port='IKG.IO.5'>
    <default dir='OUT' default='high' />
    <active dir='RESERVED' />
  </gpio>

  <input_value name='rate'>
    <variable name='rgb_A_B' />
  </input_value>

  <parameter name='frequency' value='50' />
  <parameter name='rate' value='50' />
</adapter>

```

## 11.12. DMA\_PWM\_ON\_OFF

DMA based PWM adapter with two specific pwm values.

Needs installation of RPIO2-package.

### Class

adapter.dma\_pwm.DMA\_PWM\_ON\_OFF

### Input Events

high	set pwm to default rate.
low	set pwm to 0%.

### Parameter (mandatory)

frequency	floatType [131]	Frequency in [Hz] for the pwm signal. Use '50' here.
-----------	-----------------	--

rate	floatType [131]	initial pwm rate in [%].
------	-----------------	--------------------------

### Sample configuration

## 11.13. DMA\_PWMServo

DMA based PWM adapter with input range specific for servo.

Needs installation of RPIO2-package.

Supports 50Hz, 1 to 2ms pwm.

### Class

adapter.dma\_pwm.DMA\_PWMServo

### Input Values

rate	float100Type [131]	pwm rate [0..100] for 1..2ms pwm pulse.
------	--------------------	---

### Parameter (mandatory)

frequency	floatType [131]	Frequency in [Hz] for the pwm signal. Use '50' here.
rate	floatType [131]	initial pwm rate in [%].
value.inverse	booleanType [131]	Output signal inverted (needed if transistor follower is used to boost signal for 5V).

### Parameter (optional)

millisecond.max	floatType [131]	Default 2.0 [ms]. Pulses usually are [1..2]ms. High value can be set up to 2.5 [ms].
millisecond.min	floatType [131]	Default 1.0 [ms]. Pulses usually are [1..2]ms. Low value can be set to down to 0.5 [ms].

### Sample configuration

```
<adapter class='adapter.dma_pwm.DMA_PWMServo' name='servo_pwm'>
  <description>Sample DMA PWM, needs installation of RPIO2-package.</description>

  <gpio port='GPIO23'>
    <default dir='OUT' default='high' />
    <active dir='RESERVED' />
  </gpio>

  <input_value name='rate'>
    <variable name='servo_A' />
  </input_value>

  <parameter name='frequency' value='50' />
  <parameter name='rate' value='50' />
  <parameter name='value.inverse' value='true' />

  <!-- optional parameter -->

  <!-- millisecond min is 0.5 [ms] minimum, default = 1 [ms] -->
  <!-- millisecond max is 1.5 [ms] minimum, default = 2 [ms] -->
  <parameter name="millisecond.min" value="1.0" />
  <parameter name="millisecond.max" value="2.0" />
</adapter>
```

## 11.14. Festival\_Adapter

Interface to 'festival'

festival is a text to speech package. It allows to dynamically 'speak out' text.

**Class**

adapter.textToSpeech.Festival\_Adapter

**Input Values**

value	restrictedStringType [132]	value contains the text for the conversion. For stability reasons, some characters which could mess up the system are removed [!\$V<>&~*]
-------	----------------------------	---

**Parameter (mandatory)**

queue.max	intType [131]	Commands are queued up when triggers arrive faster than scripts terminate.
-----------	---------------	--

**Sample configuration**

```
<adapter class='adapter.textToSpeech.Festival_Adapter' name='festival'>
  <description>text output</description>

  <input_value name='speech'>
    <variable name='speak' />
  </input_value>

  <parameter name="queue.max" value="5" />

</adapter>
```

**11.15. Gpio\_HCSR04\_OnePin\_Input**

Adapter for HCSR04 Ultrasonic adapter, connected with only one pin.

trigger and pin connected to one pin(by a resistor network.

hrsr04.ping-- [1k ]-- gpio

hrsr04.echo-- [2k2]-- gpio

gnd-----[2k2]-- gpio

This allows to use the 5V device for a 3.3V Pi input.

The polling for level changes is not very accurate. The adapter was implemented to have a solution close to the pi2go-libraries.

**Class**

adapter.gpio.Gpio\_HCSR04\_OnePin\_Input

**Output Values**

distance	floatType [131]	Distance measured in [cm].
----------	-----------------	----------------------------

**Parameter (mandatory)**

poll.interval	floatType [131]	Polling rate for the device.
---------------	-----------------	------------------------------

**Sample configuration**

```
<adapter class='adapter.gpio.Gpio_HCSR04_OnePin_Input' name='HCSR04'>
  <description>Ultrasonic distance sensor</description>

  <gpio port='GPIO14'>
    <default dir="RESERVED" />
    <active dir='RESERVED' />
  </gpio>

  <output_value name='distance'>
    <sensor name='distance' />
  </output_value>
```

```
<parameter name='poll.interval' value='0.2' />
</adapter>
```

## 11.16. Gpio7segment

Interface for a 7-Segment LED

drives 7 GPIO pins for a 7 segment LED.

### Class

adapter.adapters.Gpio7segment

### Input Values

seg_a	booleanType [131]	drives output led according to the logical value given
seg_b	booleanType [131]	drives output led according to the logical value given
seg_c	booleanType [131]	drives output led according to the logical value given
seg_d	booleanType [131]	drives output led according to the logical value given
seg_e	booleanType [131]	drives output led according to the logical value given
seg_f	booleanType [131]	drives output led according to the logical value given
seg_g	booleanType [131]	drives output led according to the logical value given
value	char7segmentType [131]	converts input char to a pattern on the LED; supported chars are [0-9AbCcDEFr-]

### Sample configuration

```
<adapter class='adapter.gpio.Gpio7segment' name='s7'>
  <description>7 Segment driver</description>

  <gpio port='GPIO25' alias='a'>
    <default dir='OUT' default='low' />
    <active dir='OUT' default='low' />
  </gpio>
  <gpio port='GPIO24' alias='b'>
    <default dir='OUT' default='low' />
    <active dir='OUT' default='low' />
  </gpio>
  <gpio port='GPIO23' alias='c'>
    <default dir='OUT' default='low' />
    <active dir='OUT' default='low' />
  </gpio>
  <gpio port='GPIO18' alias='d'>
    <default dir='OUT' default='low' />
    <active dir='OUT' default='low' />
  </gpio>
  <gpio port='GPIO22' alias='e'>
    <default dir='OUT' default='low' />
    <active dir='OUT' default='low' />
  </gpio>
  <gpio port='GPIO27' alias='f'>
    <default dir='OUT' default='low' />
    <active dir='OUT' default='low' />
  </gpio>
  <gpio port='GPIO17' alias='g'>
    <default dir='OUT' default='low' />
    <active dir='OUT' default='high' />
  </gpio>

  <input_value name='value'>
```

```

        <variable name='siebensegment' />
    </input_value>

    <input_value name='seg_a'>
        <variable name='seg_A' />
    </input_value>
    <input_value name='seg_b'>
        <variable name='seg_B' />
    </input_value>
    <input_value name='seg_c'>
        <variable name='seg_C' />
    </input_value>
    <input_value name='seg_d'>
        <variable name='seg_D' />
    </input_value>
    <input_value name='seg_e'>
        <variable name='seg_E' />
    </input_value>
    <input_value name='seg_f'>
        <variable name='seg_F' />
    </input_value>
    <input_value name='seg_g'>
        <variable name='seg_G' />
    </input_value>
</adapter>

```

## 11.17. GpioButtonInput

Reads a GPIO pin

Deprecated, use GpioEventInput instead.

Reads a GPIO pin; sends events. Output can be inverted.

### Class

adapter.gpio.GpioButtonInput

### Output Event

button_pressed	when button press detected
button_released	when button released

### Parameter (mandatory)

poll.interval	floatType [131]	poll rate in seconds, default 0.05.
value.inverse	booleanType [131]	'false', 'true'

### Sample configuration

```

<adapter class='adapter.gpio.GpioButtonInput' name='button_s0'>
    <!-- no description, urgg -->
    <gpio port='GPIO25'>
        <default dir='IN' pull='PUD_UP' />
        <active dir='IN' pull='PUD_UP' />
    </gpio>

    <output name='button_pressed'>
        <broadcast name='s0_pressed' />
    </output>
    <output name='button_released'>
        <broadcast name='s0_released' />
    </output>

    <parameter name='poll.interval' value='0.05' />
    <parameter name='value.inverse' value='true' />

</adapter>

```

## 11.18. GPIODialPlateEncoder

Decodes a legacy rotary telephone dialplate.

the two switches 'nsi', 'nsa' are connected.

The decoding is time dependent.

### Class

adapter.encoder.GPIODialPlateEncoder

### Output Values

number	digitType [131]	The value from the dial plate decoded.
--------	-----------------	--

### Sample configuration

```
<adapter class='adapter.encoder.GPIODialPlateEncoder' name='dial_A'>
  <description>Wählscheibe.
    Anschluss: NSI (Impuls)
              NSA (Drehschalter)
  </description>

  <gpio port='GPIO24' alias='nsi'>
    <default dir='IN' pull='PUD_UP' />
    <active dir='IN' pull='PUD_UP' />
  </gpio>
  <gpio port='GPIO18' alias='nsa'>
    <default dir='IN' pull='PUD_UP' />
    <active dir='IN' pull='PUD_UP' />
  </gpio>

  <output_value name='number'>
    <sensor name='numberA' />
  </output_value>

</adapter>
```

## 11.19. GPIOEncoder

Decodes a rotary encoder.

initial value is 0; is incremented or decremented.

### Class

adapter.encoder.GPIOEncoder

### Output Values

position	intType [131]	
----------	---------------	--

### Sample configuration

```
<adapter class='adapter.encoder.GPIOEncoder' name='encoder_A'>
  <description>Drehencoder</description>

  <gpio port='GPIO22' alias='p0'>
    <default dir='IN' pull='PUD_UP' />
    <active dir='IN' pull='PUD_UP' />
  </gpio>
  <gpio port='GPIO27' alias='p1'>
    <default dir='IN' pull='PUD_UP' />
    <active dir='IN' pull='PUD_UP' />
  </gpio>
```



```
<output_value name='position'>
  <sensor name='positionA' />
</output_value>

<parameter name='poll.interval' value='0.005' />

</adapter>
```

## 11.20. GpioEventInput

Reads a GPIO pin

Reads a GPIO pin; sends events. Output can be inverted.

### Class

adapter.gpio.GpioEventInput

### Output Event

button_pressed	when button press detected
button_released	when button released

### Parameter (mandatory)

poll.interval	floatType [131]	poll rate in seconds, default 0.05.
value.inverse	booleanType [131]	'false', 'true'

### Sample configuration

```
<adapter class='adapter.gpio.GpioButtonInput' name='button_s0'>
  <!-- no description, urgg -->
  <gpio port='GPIO25'>
    <default dir='IN' pull='PUD_UP' />
    <active dir='IN' pull='PUD_UP' />
  </gpio>

  <output name='button_pressed'>
    <broadcast name='s0_pressed' />
  </output>
  <output name='button_released'>
    <broadcast name='s0_released' />
  </output>

  <parameter name='poll.interval' value='0.05' />
  <parameter name='value.inverse' value='true' />

</adapter>
```

## 11.21. GpioInput

Read a GPIO pin

Read a GPIO pin; sends values '0' and '1'. Output can be inverted.

### Class

adapter.gpio.GpioInput

### Output Values

button	binaryType [131]	0, 1 when inverted = false; 1, 0 else.
--------	------------------	--

**Parameter (mandatory)**

poll.interval	floatType [131]	poll rate in seconds, default 0.05.
value.inverse	booleanType [131]	'false', 'true'

**Sample configuration**

```

<adapter class='adapter.gpio.GpioInput' name='schalter_s1'>

  <gpio port='GPIO24'>
    <default dir='IN' pull='PUD_UP' />
    <active dir='IN' pull='PUD_UP' />
  </gpio>
  <output_value name='button'>
    <sensor name='s1' />
  </output_value>

  <parameter name='poll.interval' value='0.05' />
  <parameter name='value.inverse' value='true' />
</adapter>

```

**11.22. GpioMotorPWM**

Controlling a DC motor with 2 half bridges, e.g. L293

outputs a pwm signal to the pins, according to direction.

Input 'speed' : float, -100.0 .. 0.0 .. 100.0 controls direction and speed.

Uses soft-pwm with RPI.GPIO

**Class**

adapter.gpio.GpioMotorPWM

**Input Values**

speed	float100Type [131]	sets direction and speed, -100 .. 0..100
-------	--------------------	--

**Parameter (mandatory)**

frequency	float100Type [131]	frequency in Hz for the pulse generation, 50Hz is a good value.
speed	float100Type [131]	default speed, -100 .. 0..100

**Sample configuration**

```

<adapter class='adapter.gpio.GpioMotorPWM' name='motor_pwm'>
  <description>Sample Motor control</description>

  <gpio port='GPIO23' alias='a'>
    <default dir='OUT' pull='PUD_OFF' default='low' />
    <active dir='RESERVED' />
  </gpio>
  <gpio port='GPIO24' alias='b'>
    <default dir='OUT' pull='PUD_OFF' default='low' />
    <active dir='RESERVED' />
  </gpio>

  <input_value name='speed'>
    <variable name='speed_A' />
  </input_value>

  <parameter name='frequency' value='50' />

```

```
<!-- speed is initial speed -->
<parameter name='speed' value='0' />
</adapter>
```

## 11.23. GpioOutput

Output to a GPIO pin

writes to a GPIO pin.

### Class

adapter.gpio.GpioOutput

### Input Events

high	drives output high
low	drives output low

### Sample configuration

```
<adapter class='adapter.gpio.GpioOutput' name='led0'>
  <description>LED0</description>

  <gpio port='GPIO25'>
    <default dir='OUT' default='low' />
    <active dir='OUT' default='low' />
  </gpio>
  <input name='low'>
    <broadcast name='led0_OFF' />
  </input>
  <input name='high'>
    <broadcast name='led0_ON' />
  </input>
</adapter>
```

## 11.24. GpioOutputPWM

Output to a GPIO pin

outputs a pwm signal to a pin.

Input 'rate': float, 0.0 to 100.0

Configuration 'frequency': float, [Hz]

Uses soft-pwm with RPI.GPIO.

### Class

adapter.gpio.GpioOutputPWM

### Input Values

rate	float100Type [131]	sets PWM rate, 0..100
------	-----------------------	-----------------------

### Parameter (mandatory)

frequency	float100Type [131]	frequency in Hz
rate	float100Type [131]	default rate, 0..100

### Sample configuration

```
<adapter class='adapter.gpio.GpioOutputPWM' name='pwm_25'>
```

```

<description>Sample GPIO PWM</description>
<gpio port='GPIO25'>
  <default dir='OUT' default='low' />
  <active dir='RESERVED' />
</gpio>
<input_value name='rate'>
  <variable name='rate_25' />
</input_value>
<parameter name='frequency' value='30' />
<parameter name='rate' value='15' />
</adapter>

```

## 11.25. GpioOutputPWM\_ON\_OFF

dim an output pin or set it off.

outputs a pwm signal to a pin (rate when high; 0 when low).

Fixed level only.

### Class

adapter.gpio.GpioOutputPWM\_ON\_OFF

### Input Events

high	sets PWM rate to [rate]
low	sets PWM rate to 0.0

### Parameter (mandatory)

frequency	float100Type [131]	frequency in Hz
rate	float100Type [131]	default rate, 0..100

### Sample configuration

```

<adapter class='adapter.gpio.GpioOutputPWM_ON_OFF' name='led0'>
<description>LED0</description>

<gpio port='GPIO.25'>
  <default dir='OUT' default='low' />
  <active dir='OUT' default='low' />
</gpio>
<input name='low'>
  <broadcast name='led0_OFF' />
</input>
<input name='high'>
  <broadcast name='led0_ON' />
</input>
</adapter>

```

## 11.26. GpioOutputPWMServo

Output to a GPIO pin

outputs a pwm signal to a pin.

Input 'rate': float, 0.0 to 100.0

Configuration 'frequency': float, [Hz]

Uses soft-pwm with RPI.GPIO; may produce jitter on signals.

**Class**

adapter.gpio.GpioOutputPWMServo

**Input Values**

rate	float100Type [131]	sets PWM rate, 0..100 0 --> 95% 1ms 100 --> 90% 2ms @ 50Hz
------	-----------------------	--

**Parameter (mandatory)**

frequency	float100Type [131]	frequency in Hz, for a servo set 50Hz
rate	float100Type [131]	default rate, 0..100
value.inverse	booleanType [131]	Output signal inverted (needed if transistor follower is used to boost signal for 5V).

**Parameter (optional)**

millisecond.max	floatType [131]	Default 2.0 [ms]. Pulses usually are [1..2]ms. High value can be set up to 2.5 [ms].
millisecond.min	floatType [131]	Default 1.0 [ms]. Pulses usually are [1..2]ms. Low value can be set to down to 0.5 [ms].

**Sample configuration**

```
<adapter class='adapter.gpio.GpioOutputPWMServo' name='servo_pwm'>
  <description>Sample GPIO PWM</description>

  <gpio port='GPIO23'>
    <default dir='OUT' pull='PUD_OFF' default='low' />
    <active dir='RESERVED' />
  </gpio>

  <input_value name='rate'>
    <variable name='servo_A' />
  </input_value>

  <parameter name='frequency' value='50' />
  <parameter name='rate' value='50' />
</adapter>
```

**11.27. GpioStateOutput**

scratch connection status

displays scratch connection status to a GPIO pin.

scratchclient not started: undefined

scratchclient started: low

no connection: high

connection: blink

**Class**

adapter.gpio.GpioStateOutput

**Sample configuration**

```
<adapter class='adapter.gpio.GpioStateOutput' name='state'>
  <description>State display on GPIO04</description>

  <gpio port='GPIO04' alias='state'>
```

```

        <default dir='OUT' default='low' />
        <active dir='OUT' default='low' />
    </gpio>
</adapter>

```

## 11.28. GpioValueInput

Read a GPIO pin; sends configurable values. Output can be inverted.

Input is polled by 'poll.interval'. When a value change is detected, a value is acquired. The value gets inverted if 'value.inverse'==true. Then the configured definitions for 0 or 1 are applied from 'value.0' or 'value.1'

### Class

adapter.gpio.GpioValueInput

### Output Values

value	anyType [131]	see value.0, value.1 for values.
-------	---------------	----------------------------------

### Parameter (mandatory)

poll.interval	floatType [131]	poll rate in seconds, default 0.05.
value.0	anyType [131]	can be any string like 'on', 'off', 'active', 'disabled' or numeric values. Whatever a meaningful value for scratch is.  do not use same value as value.1
value.1	anyType [131]	can be any string like 'on', 'off', 'active', 'disabled' or numeric values. Whatever a meaningful value for scratch is.  do not use same value as value.0
value.inverse	booleanType [131]	'false', 'true'

### Sample configuration

```

<adapter class='adapter.gpio.GpioValueInput' name='valueGPIO'>

    <gpio port='GPIO25'>
        <default dir='IN' pull='PUD_UP' />
        <active dir='IN' pull='PUD_UP' />
    </gpio>

    <output_value name='value'>
        <sensor name='namedGPIO_A' />
    </output_value>

    <parameter name='poll.interval' value='0.08' />
    <parameter name='value.inverse' value='false' />

    <parameter name='value.0' value='switched_OFF' />
    <parameter name='value.1' value='switched_ON' />

</adapter>

```

## 11.29. GpioValueOutput

Output a GPIO pin based on variable value

writes to a GPIO pin.

### Class

adapter.gpio.GpioValueOutput

## Input Values

value	levelType [132]	also accepts float values in range -0.01..0.01 or 0.99..1.01
-------	-----------------	--

## Sample configuration

```
<adapter class='adapter.gpio.GpioValueOutput' name='led0'>
  <description>LED0</description>

  <gpio port='GPIO25'>
    <default dir='OUT' default='low' />
    <active dir='OUT' default='low' />
  </gpio>
  <input_value name='value'>
    <variable name='led0' />
  </input_value>

</adapter>
```

## 11.30. GY\_GPS6MV2

Adapter for GY\_GPS6MV2.

GPS coordinates, time are provided.

Needs `gpsd` service. See description for details.

## Class

`adapter.gps.GY_GPS6MV2`

## Sample configuration

```
<adapter class='adapter.gps.GY_GPS6MV2' name='GPS-GY-GPS6MV2'>
  <description>GPS module GY-GPS6MV2</description>

  <output_value name='time'>
    <sensor name='Time' />
  </output_value>

  <output_value name='lat'>
    <sensor name='Latitude' />
  </output_value>

  <output_value name='lon'>
    <sensor name='Longitude' />
  </output_value>

  <output_value name='alt'>
    <sensor name='Altitude' />
  </output_value>

  <output_value name='speed'>
    <sensor name='Speed' />
  </output_value>

  <output_value name='track'>
    <sensor name='Course' />
  </output_value>

  <output_value name='epx'>
    <sensor name='Latitude_Error' />
  </output_value>

  <output_value name='epy'>
    <sensor name='Longitude_Error' />
  </output_value>

  <output_value name='epv'>
    <sensor name='Altitude_Error' />
  </output_value>
```

```

    <output_value name='eps'>
      <sensor name='Speed_Error' />
    </output_value>

    <parameter name='poll.interval' value='0.5' />
  </adapter>

```

## 11.31. HC\_SR04\_Adapter

HC-SR04 connection by pigpiod-daemon

Measures time of echo signal.

Provides error value if needed.

### Class

adapter.pigpiodAdapter.HC\_SR04\_Adapter

### Output Values

error	stringType [132]	<p>error information, empty when no error</p> <p>'no connection' when pigpiod daemon can't be reached.</p> <p>'echo pin is high' when at the start of a trigger pulse the echo pin is high, should be low. Typically a connection problem.</p> <p>'no response' when no pos edge and then neg edge on echo pin is found. Typically a connection problem.</p> <p>'time too long &gt; 20ms' when measured time is larger than 20ms.</p>
time	floatType [131]	Pulse width of echo-signal in seconds.

### Sample configuration

```

<adapter class='adapter.pigpiod.HC_SR04_Adapter' name='echo-time'>
  <description>HC-SR04 controller</description>

  <gpio port='GPIO18' alias='trigger'>
    <default dir='RESERVED' />
    <active dir='RESERVED' />
  </gpio>
  <gpio port='GPIO23' alias='echo'>
    <default dir='RESERVED' />
    <active dir='RESERVED' />
  </gpio>

  <output_value name='time'>
    <sensor name='time' />
  </output_value>

  <output_value name='error'>
    <sensor name='error' />
  </output_value>

  <!-- minimal value 0.02 -->
  <parameter name='poll.interval' value='0.5' />
</adapter>

```

## 11.32. HIDScanner\_Adapter

Read an USB HID device.

Provides scan results from a barcode scanner.

### Class

adapter.usbAdapter.HIDScanner\_Adapter



## Output Values

scan	stringType [132]	scan result
------	------------------	-------------

## Parameter (mandatory)

usb.idProduct	stringType [132]	
usb.idVendor	stringType [132]	

## Sample configuration

```
<adapter class='adapter.usbAdapter.HIDScanner_Adapter' name='barcode scanner'>
  <description>Provides scan results from a barcode scanner.</description>
  <output_value name='scan'>
    <sensor name='barcode' />
  </output_value>
  <parameter name="usb.idVendor" value="0x0c2e" />
  <parameter name="usb.idProduct" value="0x0200" />
</adapter>
```

## 11.33. IRDistanceInput

IR Distance sensor

Interface to Sharp GP2Y0A21YK IR Distance sensor on adc MCP3202, 10bit.

Calculates linearization; averaging the last 5 values.

## Class

adapter.adc.IRDistanceInput

## Output Values

distance	floatType [131]	distance in mm; when open max value is 800.
----------	-----------------	---

## Parameter (mandatory)

adc.channel	intType [131]	adc channel (0,1).
filter.use	booleanType [131]	boolean value, 1, 0, true, false, yes, no.
poll.interval	floatType [131]	poll rat ein seconds, default 0.05.
spi.bus	intType [131]	bus number, 0, 1
spi.device	intType [131]	spi bus selector, 0, 1

## Sample configuration

```
<adapter class='adapter.adc.IRDistanceInput' name='irDistanceA'>
  <description>IR-Distance Sensor</description>
  <output_value name='distance'>
    <sensor name='distanceA' />
  </output_value>
  <parameter name='poll.interval' value='0.066' />
  <parameter name='spi.bus' value='0' />
  <parameter name='spi.device' value='0' />
  <parameter name='adc.channel' value='0' />
  <parameter name='filter.use' value='true' />
  <parameter name='filter.depth' value='5' />
</adapter>
```

## 11.34. Linux\_Adapter

Interface to linux operation command line

Allows the usage of linux shell scripts.

### Class

adapter.linux.Linux\_Adapter

### Input Events

trigger	Start the script.
---------	-------------------

### Parameter (mandatory)

os.command	stringType [132]	The operating system command.
queue.max	intType [131]	Commands are queued up when triggers arrive faster than scripts terminate.

### Sample configuration

```
<adapter class='adapter.linux.Linux_Adapter' name='sampleB'>
  <description>linux os command execution</description>

  <input name='trigger'>
    <broadcast name='scrot' />
  </input>

  <parameter name="os.command" value="scrot" />
  <parameter name="queue.max" value="5" />
</adapter>
```

## 11.35. Linux\_APLAY\_Adapter

Play wav files with aplay.

Linux only.

### Class

adapter.linux.Linux\_APLAY\_Adapter

### Input Values

sound	stringType [132]	name of wav file. With or without extension '.wav'
-------	------------------	--

### Parameter (mandatory)

aplay.device	stringType [132]	use a device reported by 'aplay -L'.
queue.max	intType [131]	Max queue depth for commands. 5 is a good value.
sound.dir	stringType [132]	Directory where wave files are looked for, e.g /home/pi/temp.

### Sample configuration

```
<adapter class='adapter.linux.Linux_APLAY_Adapter' name='sampleA'>
  <description>linux aplay execution</description>

  <input_value name='sound'>
    <variable name='wave' />
  </input_value>

  <parameter name="aplay.device" value="sysdefault:CARD=Device" />
  <parameter name="sound.dir" value="/opt/sonic-pi/etc/samples" />
  <parameter name="queue.max" value="5" />
```

&lt;/adapter&gt;

## 11.36. Linux\_ARECORD\_Adapter

record wav files with arecord.

Linux only.

### Class

adapter.linux.Linux\_ARECORD\_Adapter

### Input Events

start_record	start recording.
stop_record	stop recording.

### Input Values

sound	stringType [132]	name of wav file. Extension '.wav' is not needed.
-------	------------------	---

### Parameter (mandatory)

aplay.device	stringType [132]	use a device reported by 'aplay -L'.
aplay.rate	intType [131]	Sampling rate in Hertz. The default rate is 8000 Hertz.
sound.dir	stringType [132]	Directory where wave files are looked for, e.g /home/pi/temp.
timeout	intType [131]	timeout for recording, 60 [sec] is recommended.

### Sample configuration

```
<adapter class='adapter.linux.Linux_ARECORD_Adapter' name='sampleA'>
  <description>linux arecord execution</description>

  <input_value name='sound'>
    <variable name='wave' />
  </input_value>

  <input name='start_record'>
    <broadcast name='start' />
  </input>

  <input name='stop_record'>
    <broadcast name='stop' />
  </input>

  <parameter name="aplay.device" value="sysdefault:CARD=Device" />
  <parameter name="aplay.rate" value="16000" />
  <parameter name='sound.dir' value='/home/pi/temp' />
  <parameter name='timeout' value='60' />
</adapter>
```

## 11.37. Linux\_ASR\_Adapter

Interface for a speech recognition process.

Linux only. Needs installation of a speech recognition system, e.g. pocketsphinx. This system is writing text to stdout.

The design is to use pocketsphinx in batch mode.

### Class

adapter.linux.Linux\_ASR\_Adapter

### Input Events

execute	start process.
---------	----------------

textAcknowledge	when a text variable is processed, send acknowledge to receive next text.
-----------------	---

### Output Event

complete	Process terminated.
textAvailable	A text variable is available in scratch and can be processed.

### Output Values

status	stringType [132]	Status information from adapter.
text	stringType [132]	A line from process' stdout is sent.

### Parameter (mandatory)

command.line	stringType [132]	process and parameter for linux process. \${sound.dir}/\${sound.file} can be used to insert dir/file name of wave file.
sound.dir	stringType [132]	Directory where wave files are looked for, e.g /home/pi/temp.
sound.file	stringType [132]	name of wave file to process
timeout	intType [131]	timeout.

### Sample configuration

```
<adapter class='adapter.linux.Linux_ASR_Adapter' name='sampleA'>
  <description>linux speech recognition with pocketsphinx</description>

  <input name='execute'>
    <broadcast name='execute' />
  </input>

  <output name='complete'>
    <broadcast name='finished' />
  </output>

  <input name='textAcknowledge'>
    <broadcast name='ack' />
  </input>

  <output name='textAvailable'>
    <broadcast name='listen' />
  </output>

  <output_value name='text'>
    <sensor name='text' />
  </output_value>

  <output_value name='status'>
    <sensor name='status' />
  </output_value>

  <!-- ${sound.dir} is filled from 'sound.dir'; ${sound.file} is filled from 'sound.file' -->
  <parameter
    name='command.line'
    value='pocketsphinx_continuous -hmm /usr/local/share/pocketsphinx/model/en-us/en-us -lm

  <parameter name='sound.dir' value='/home/pi' />
  <parameter name='sound.file' value='sample.wav' />
  <!--
    Text received is internally queued. When queue data are getting too old, these are disc
    Timeout is configured here in sec.
    The timeout is used for scenario, where the acknowledge protocol is not yet implemented
    data are accumulated in internal queue.
  -->
  <parameter name='timeout' value='60' />
</adapter>
```

## 11.38. LIRC\_Adapter

Adapter for Linux lirc receiver.

Allows remote control with a IR remote control.

The event configuration is based on current lircd configuration file.

## Class

adapter.uinputAdapter.LIRC\_Adapter

## Parameter (mandatory)

lircd.conf	stringType [132]	/etc/lirc/lircd.conf
------------	------------------	----------------------

## Sample configuration

```
<adapter class='adapter.uinputAdapter.LIRC_Adapter' name='lirc'>
  <description>interface to a lirc-daemon</description>

  <!--
    this adapter does implicit input_value and output_value-configuration based on the
    content of lircd config file.
    output_KEY_<V>_down
    output_KEY_<V>_up
  -->

  <extension>
  <lirc>
    <!-- leave empty -->
  </lirc>
  </extension>

  <!-- location for lircd config file -->
  <parameter name='lircd.conf' value="/etc/lirc/lircd.conf" />

</adapter>
```

## 11.39. Luminosity\_BH1750\_Input

Interface for Luminosity sensor BH1750

Interface for Luminosity sensor BH1750

Values are in lx (lux)

## Class

adapter.i2cAdapter.Luminosity\_BH1750\_Input

## Output Values

luminosity	floatType [131]	brightness in lx
------------	-----------------	------------------

## Parameter (mandatory)

i2c.address	intOrHexType [131]	'0x23' for BH1750 '0x5c' for BH1750
i2c.bus	intOrHexType [131]	bus is '1' for RPi Release 2
poll.interval	floatType [131]	poll interval in secs, e.g. 0.05

## Sample configuration

```
<adapter class='adapter.i2cAdapter.Luminosity_BH1750_Input' name='luminosity'>
  <description>Luminosity-Value from BH1750</description>

  <output_value name='luminosity'>
    <sensor name='luminosity' />
  </output_value>
</adapter>
```

```

</output_value>

<parameter name='poll.interval' value='0.5' />

<!-- bus is '1' for RPi Release 2 -->
<parameter name='i2c.bus' value='1' />

<!-- Depending on address select, the bus address is
      '0x23' for BH1750
      '0x5c' for BH1750
-->
<parameter name='i2c.address' value='0x23' />
</adapter>

```

## 11.40. MAX31855\_Adapter

Thermoelement processor MAX31855

### Class

adapter.spiAdapter.MAX31855\_Adapter

### Output Values

temp_error	stringType [132]	error code, empty when no error
temp_intern	floatType [131]	internal temperature in °C
temp_wire	floatType [131]	wire temperature in °C

### Parameter (mandatory)

poll.interval	floatType [131]	polling time, e.g. 0.5 seconds
spi.bus	intType [131]	
spi.device	intType [131]	

### Sample configuration

```

<adapter class='adapter.spiAdapter.MAX31855_Adapter' name='thermoelement'>

  <description>Temperatures
  SPI-connected.
  </description>

  <output_value name='temp_wire'>
    <sensor name='temp_ext' />
  </output_value>

  <output_value name='temp_intern'>
    <sensor name='temp_int' />
  </output_value>

  <output_value name='temp_error'>
    <sensor name='temp_error' />
  </output_value>

  <!-- polling time for external device -->
  <parameter name='poll.interval' value='0.5' />

  <parameter name='spi.bus' value='0' />
  <parameter name='spi.device' value='0' />
</adapter>

```

## 11.41. MCP23S17\_Adapter

MCP23S17 Port Expander

Controls MCP23S17 Port expander, as used on piFace-Board.

input\_value methods in python are dynamically generated like inputGPA4 for io@dir=out

output\_value methods in python are dynamically generated like outputGPB2 for io@dir=in

see the config/config\_mcp23s17.xml example for namespace usage in xml.

## Class

adapter.mcp23s17.MCP23S17\_Adapter

## Parameter (mandatory)

23s17.addr	intType [131]	slave address must match the hard wired slave address on the device
poll.interval	floatType [131]	polling interval in seconds, 0.05 sec is a good value.
spi.bus	intType [131]	
spi.device	intType [131]	

## Sample configuration

```
<adapter class='adapter.mcp23s17.MCP23S17_Adapter' name='MCP23S17'>

  <!-- this is the setup for piface -->
  <!-- input_value methods in python are dynamically generated like inputGPA4 for io@dir=out

  <input_value name='inputGPA0'>
    <variable name='out_0' />
    <variable name='relais_0' />
    <variable name='all' />
  </input_value>

  <input_value name='inputGPA1'>
    <variable name='out_1' />
    <variable name='relais_1' />
    <variable name='all' />
  </input_value>

  <input_value name='inputGPA2'>
    <variable name='out_2' />
    <variable name='all' />
  </input_value>

  <input_value name='inputGPA3'>
    <variable name='out_3' />
    <variable name='all' />
  </input_value>

  <input_value name='inputGPA4'>
    <variable name='out_4' />
    <variable name='all' />
  </input_value>

  <input_value name='inputGPA5'>
    <variable name='out_5' />
    <variable name='all' />
  </input_value>

  <input_value name='inputGPA6'>
    <variable name='out_6' />
    <variable name='all' />
  </input_value>

  <input_value name='inputGPA7'>
    <variable name='out_7' />
    <variable name='all' />
  </input_value>

  <!-- output_value methods in python are dynamically generated like outputGPB2 for io@dir=in
```

```
<output_value name='outputGPB0'>
  <sensor name='in_0' />
</output_value>

<output_value name='outputGPB1'>
  <sensor name='in_1' />
</output_value>

<output_value name='outputGPB2'>
  <sensor name='in_2' />
</output_value>

<output_value name='outputGPB3'>
  <sensor name='in_3' />
</output_value>

<output_value name='outputGPB4'>
  <sensor name='in_4' />
</output_value>

<output_value name='outputGPB5'>
  <sensor name='in_5' />
</output_value>

<output_value name='outputGPB6'>
  <sensor name='in_6' />
</output_value>

<output_value name='outputGPB7'>
  <sensor name='in_7' />
</output_value>

<parameter name='poll.interval' value='0.05' />

<parameter name='spi.bus' value='0' />
<parameter name='spi.device' value='0' />
<!-- slave address must match the hard wired slave address on the device -->
<parameter name='23s17.addr' value='0' />

<extension>
  <!-- this is the setup for piface -->

  <io id='GPA0' dir='out' />
  <io id='GPA1' dir='out' />
  <io id='GPA2' dir='out' />
  <io id='GPA3' dir='out' />

  <io id='GPA4' dir='out' />
  <io id='GPA5' dir='out' />
  <io id='GPA6' dir='out' />
  <io id='GPA7' dir='out' />

  <io id='GPB0' dir='in' pullup='weak' />
  <io id='GPB1' dir='in' pullup='weak' />
  <io id='GPB2' dir='in' pullup='weak' />
  <io id='GPB3' dir='in' pullup='weak' />

  <io id='GPB4' dir='in' pullup='weak' />
  <io id='GPB5' dir='in' pullup='weak' />
  <io id='GPB6' dir='in' pullup='weak' />
  <io id='GPB7' dir='in' pullup='weak' />
</extension>
</adapter>
```

## 11.42. Microdot\_Adapter

Text output to a Pimoroni MICRO DOT PHAT board.

The board uses three I2C IS31FL3730 LED matrix driver chips.

Allows text output only.



**Class**

adapter.microdotAdapter.Microdot\_Adapter

**Input Events**

clear	Clear display
-------	---------------

**Input Values**

brightness	floatType [131]	Sets brightness, range [0..1]
text	stringType [132]	Set text to display. Only first 6 chars are displayed. Not for each char a display pattern is available; missing chars are displayed as '#'

**Parameter (mandatory)**

microdot.mirror	booleanType [131]	mirror left-right
microdot.rotate180	booleanType [131]	rotate display by 180 degree

**Sample configuration**

```

<adapter class='adapter.microdotAdapter.Microdot_Adapter' name='mda'>
  <description>Text output</description>
  <input_value name='text'>
    <variable name='mdaText' />
  </input_value>
  <input_value name='brightness'>
    <variable name='bright' />
  </input_value>
  <parameter name='microdot.rotate180' value='false' />
  <parameter name='microdot.mirror' value='false' />
</adapter>

```

**11.43. MinecraftAdapter**

Adapter for Minecraft on Pi.

Allows client connection to a running minecraft on Raspberry Pi.

Based on mcpi-Library as described in <http://www.stuffaboutcode.com/p/minecraft-api-reference.html>.

**Class**

adapter.minecraftAdapter.MinecraftAdapter

**Sample configuration**

```

<adapter class='adapter.minecraftAdapter.MinecraftAdapter' name='minecraft'>
  <description>interface to a minecraft-10-server on pi</description>
  <input_value name='playerX'> <variable name="playerX"/></input_value>
  <input_value name="playerY"> <variable name="playerY"/></input_value>
  <input_value name="playerZ"> <variable name="playerZ"/></input_value>
  <input_value name='cameraX'> <variable name="cameraX"/></input_value>
  <input_value name="cameraY"> <variable name="cameraY"/></input_value>
  <input_value name="cameraZ"> <variable name="cameraZ"/></input_value>
  <input_value name="mcpiX"> <variable name="mcpiX"/></input_value>
  <input_value name="mcpiY"> <variable name="mcpiY"/></input_value>
  <input_value name="mcpiZ"> <variable name="mcpiZ"/></input_value>

```

```
<input_value name="mcpiX0"> <variable name="mcpiX0"/></input_value>
<input_value name="mcpiY0"> <variable name="mcpiY0"/></input_value>
<input_value name="mcpiZ0"> <variable name="mcpiZ0"/></input_value>

<input_value name="blockTypeId"> <variable name="blockTypeId"/></input_value>
<input_value name="blockData"> <variable name="blockData"/></input_value>

<output_value name="posY">
  <sensor name="posY" />
</output_value>

<output_value name="blockFound_id">
  <sensor name="blockFound.id"/>
</output_value>

<output_value name="blockFound_data">
  <sensor name="blockFound.data"/>
</output_value>

<input name="hello_minecraft"> <broadcast name="hello_minecraft" /></input>
<input name="setPos"> <broadcast name="setPos" /></input>
<input name="setBlock"> <broadcast name="setBlock" /></input>
<input name="setBlocks"> <broadcast name="setBlocks" /></input>
<input name="getHeight"> <broadcast name="getHeight" /></input>
<input name="getBlockWithData"> <broadcast name="getBlock" /></input>
<input name="reset"> <broadcast name="reset" /></input>

<input name="cameraSetFixed"> <broadcast name="camera.setFixed" /></input>
<input name="cameraSetNormal"> <broadcast name="camera.setNormal" /></input>
<input name="cameraSetFollow"> <broadcast name="camera.setFollow" /></input>
<input name="cameraSetPos"> <broadcast name="camera.setPos" /></input>

<parameter name="minecraft.server" value="localhost" />
<parameter name="minecraft.port" value="4711" />
</adapter>
```

## 11.44. MQTT\_Adapter

MQTT client connection to a mqtt server

Allows client connection to a mqtt server.

The input- and output configuration is done implicit by the mqtt-section in the config file. The sample given uses the variables a\_value, b\_value and c\_value to publish; and receives a sensor value d\_value.

### Class

adapter.iotAdapter.MQTT\_Adapter

### Sample configuration

```
<adapter class='adapter.iotAdapter.MQTT_Adapter' name='mqtt'>
  <description>interface to a mqtt-server</description>

  <!--
    this adapter does implicit input_value and output_value-configuration based on the
    content of mqtt-Tag.
    mqtt/publish/@variable definitions are used as scratch variable names.
    mqtt/subscribe/@variable definitions are used as scratch sensor names.
  -->

  <extension>
    <mqtt>

    <!-- when @variable is omitted, the topic is taken as variable name -->
    <publish topic="scratch/sample/a_value" />

    <publish topic="scratch/sample/b_value" variable="b_value" />
    <publish topic="scratch/sample/c_value" variable="c_value" />

    <subscribe topic="scratch/sample/d_value" variable="d_value" />
```

```

</mqtt>
</extension>

<parameter name="mqtt.server" value="192.168.2.160" />
<parameter name="mqtt.port" value="1883" />

<!-- optional parameter,
      set only when server supports password authentication -->
<!--
      <parameter name="mqtt.username" value="test" />
      <parameter name="mqtt.password" value="test" />
-->

</adapter>

```

## 11.45. NEOPIXEL\_Adapter

Interface to ArduinoUNO by USB-connection for WS2812 (neopixel)

Needs an arduino sketch.

### Class

adapter.arduino.NEOPIXEL\_Adapter

### Input Values

led	colorType [131]	blank separated array of color values.
-----	-----------------	--

### Parameter (mandatory)

led.length	intType [131]	Number of chips connected to arduino.
led.shadow	booleanType [131]	shadow keeps a duplicate of led values in memory and only sends set-led if values have changed. This reduces communication effort to arduino and improves speed.
serial.baud	intType [131]	Default is 115200. This value is used in firmware.
serial.device	stringType [132]	on windows, use COMn, e.g. COM6 on raspberry, use /dev/tty, e.g. /dev/ttyUSB0

### Sample configuration

```

<adapter class='adapter.arduino.NEOPIXEL_Adapter' name='UNO_NEOPIXEL'>
  <!-- Sample arduino communication. Needs arduino sketch programmed in arduino. -->

  <input_value name='led'>
    <variable name='led' />
  </input_value>

  <input name='clear'>
    <broadcast name='clear' />
  </input>

  <input name='red'>
    <broadcast name='red_all' />
  </input>
  <input name='green'>
    <broadcast name='green_all' />
  </input>
  <input name='blue'>
    <broadcast name='blue_all' />
  </input>

  <!-- ===== -->
  <!-- on windows, use COMn, e.g. COM6 -->
  <!-- on raspberry, use /dev/tty, e.g. /dev/ttyAMA0 -->

```

```

<!-- <parameter name='serial.device' value='/dev/ttyUSB0' />
-->

<parameter name='led.length' value='144' />

<!-- shadow keeps a duplicate of led values in memory and only sends set-led if values
have changed. This reduces communication effort to arduino and improves
speed. -->
<parameter name='led.shadow' value='true' />

<parameter name='serial.device' value='COM19' />
<parameter name='serial.baud' value='115200' />

<!-- ===== -->

</adapter>

```

## 11.46. Openweathermap\_Adapter

Reading openweathermap data.

Read openweathermap data. Needs credentials from <http://openweathermap.org> to work.

Needs installation of 'pyowm'.

### Class

adapter.openweathermapAdapter.Openweathermap\_Adapter

### Parameter (mandatory)

location	stringType [132]	Default location name to get weather for.
openweather.api_key	stringType [132]	Get these from openweathermap for your account
pollrate	intType [131]	pollrate in seconds. The api allows pollrate depending on license status. The free API allows pollrates of 10min == 600

### Sample configuration

```

<adapter class='adapter.openweathermapAdapter.Openweathermap_Adapter' name='openweathermap'>
  <description>Retrieve openweathermap data</description>

  <input_value name='location'>
    <variable name='location' />
  </input_value>

  <output_value name='owm_location'>
    <sensor name='owm.location' />
  </output_value>

  <output_value name='owm_weather_clouds'>
    <sensor name='owm.clouds' />
  </output_value>

  <output_value name='owm_weather_rainfall'>
    <sensor name='owm.rainfall' />
  </output_value>

  <output_value name='owm_weather_snowfall'>
    <sensor name='owm.snowfall' />
  </output_value>

  <output_value name='owm_weather_temperature'>
    <sensor name='owm.temperature' />
  </output_value>

  <output_value name='owm_weather_humidity'>
    <sensor name='owm.humidity' />
  </output_value>
</adapter>

```

```
</output_value>

<output_value name='owm_weather_pressure'>
  <sensor name='owm.pressure' />
</output_value>

<output_value name='owm_weather_wind_speed'>
  <sensor name='owm.wind_speed' />
</output_value>

<output_value name='owm_weather_wind_direction'>
  <sensor name='owm.wind_direction' />
</output_value>

<output_value name='owm_coord_lon'>
  <sensor name='owm.lon' />
</output_value>

<output_value name='owm_coord_lat'>
  <sensor name='owm.lat' />
</output_value>

<output_value name='owm_coord_country'>
  <sensor name='owm.country' />
</output_value>

<output_value name='owm_time'>
  <sensor name='owm.time' />
</output_value>

<parameter name='openweather.api_key' value='b0d148b511b1b9548af40e69561c1050' />

<!-- pollrate in seconds
      The api allows pollrate depending on license status.
      The free API allows pollrates of 10min == 600 -->

<parameter name='pollrate' value='600' />

<!-- default for 'location' -->
<parameter name='location' value='Leinfelden-Echterdingen' />

</adapter>
```

## 11.47. PianoHat\_CAP1188\_Adapter

PianoHat Adapter.

Installation procedures for pianohat required.

Supports button presses and releases.

### Class

adapter.Cap1188Adapter.PianoHat\_CAP1188\_Adapter

### Output Event

broadcast_00_off	button 00, C
broadcast_00_on	button 00, C
broadcast_01_off	button 01, C#
broadcast_01_on	button 01, C#
broadcast_02_off	button 02, D
broadcast_02_on	button 02, D
broadcast_03_off	button 03, D#
broadcast_03_on	button 03, D#
broadcast_04_off	button 04, E

broadcast_04_on	button 04, E
broadcast_05_off	button 05, F
broadcast_05_on	button 05, F
broadcast_06_off	button 06, F#
broadcast_06_on	button 06, F#
broadcast_07_off	button 07, G
broadcast_07_on	button 07, G
broadcast_08_off	button 08, G#
broadcast_08_on	button 08, G#
broadcast_09_off	button 09, A
broadcast_09_on	button 09, A
broadcast_10_off	button 10, A#
broadcast_10_on	button 10, A#
broadcast_11_off	button 11, B
broadcast_11_on	button 11, B
broadcast_12_off	button 12, c
broadcast_12_on	button 12, c
broadcast_13_off	button 13, octave down
broadcast_13_on	button 13, octave down
broadcast_14_off	button 14, octave up
broadcast_14_on	button 14, octave up
broadcast_15_off	button 15, instrument
broadcast_15_on	button 15, instrument

### Parameter (mandatory)

auto_leds	booleanType [131]	Controls the autoled behaviour.
-----------	----------------------	---------------------------------

### Sample configuration

```
<adapter class='adapter.Cap1188Adapter.PianoHat_CAP1188_Adapter' name='piano_adapter'>

  <description>pimoroni piano hat</description>

  <output name='broadcast_00_on'><broadcast name='button_00' /></output>
  <output name='broadcast_01_on'><broadcast name='button_01' /></output>
  <output name='broadcast_02_on'><broadcast name='button_02' /></output>
  <output name='broadcast_03_on'><broadcast name='button_03' /></output>
  <output name='broadcast_04_on'><broadcast name='button_04' /></output>
  <output name='broadcast_05_on'><broadcast name='button_05' /></output>
  <output name='broadcast_06_on'><broadcast name='button_06' /></output>
  <output name='broadcast_07_on'><broadcast name='button_07' /></output>
  <output name='broadcast_08_on'><broadcast name='button_08' /></output>
  <output name='broadcast_09_on'><broadcast name='button_09' /></output>
  <output name='broadcast_10_on'><broadcast name='button_10' /></output>
  <output name='broadcast_11_on'><broadcast name='button_11' /></output>
  <output name='broadcast_12_on'><broadcast name='button_12' /></output>
  <output name='broadcast_13_on'><broadcast name='button_13' /></output>
  <output name='broadcast_14_on'><broadcast name='button_14' /></output>
  <output name='broadcast_15_on'><broadcast name='button_15' /></output>

  <output name='broadcast_00_off'><broadcast name='button_00_off' /></output>
  <output name='broadcast_01_off'><broadcast name='button_01_off' /></output>
  <output name='broadcast_02_off'><broadcast name='button_02_off' /></output>
  <output name='broadcast_03_off'><broadcast name='button_03_off' /></output>
  <output name='broadcast_04_off'><broadcast name='button_04_off' /></output>
  <output name='broadcast_05_off'><broadcast name='button_05_off' /></output>
  <output name='broadcast_06_off'><broadcast name='button_06_off' /></output>
  <output name='broadcast_07_off'><broadcast name='button_07_off' /></output>
  <output name='broadcast_08_off'><broadcast name='button_08_off' /></output>
```

```

<output name='broadcast_09_off'><broadcast name='button_09_off' /></output>
<output name='broadcast_10_off'><broadcast name='button_10_off' /></output>
<output name='broadcast_11_off'><broadcast name='button_11_off' /></output>
<output name='broadcast_12_off'><broadcast name='button_12_off' /></output>
<output name='broadcast_13_off'><broadcast name='button_13_off' /></output>
<output name='broadcast_14_off'><broadcast name='button_14_off' /></output>
<output name='broadcast_15_off'><broadcast name='button_15_off' /></output>

```

```

<parameter name="auto_leds" value="true" />

```

```

</adapter>

```

## 11.48. Pico2Wave\_Adapter

Interface to 'pico2wave'

pico2wave is a text to speech package. It allows to dynamically 'speak out' text.

Install: `sudo apt-get install libtts-pico-utils`

Validate: `pico2wave -w lookdave.wav "Look Dave, I can see you're really upset about this." && aplay lookdave.wav`

### Class

`adapter.textToSpeech.Pico2Wave_Adapter`

### Input Values

value	restrictedStringType [132]	value contains the text for the conversion. For stability reasons, some characters which could mess up the system are removed ['\$V<>&~*']
-------	----------------------------	--

### Parameter (mandatory)

queue.max	intType [131]	Commands are queued up when triggers arrive faster than scripts terminate.
tts.lang	stringType [132]	Language 'en-US', 'en-GB', 'de-DE', 'es-ES', 'fr-FR', 'it-IT'.

### Sample configuration

```

<adapter class='adapter.textToSpeech.Pico2Wave_Adapter' name='pico2wave'>
  <description>text output</description>

  <input_value name='speech'>
    <variable name='speak' />
  </input_value>

  <parameter name="queue.max" value="5" />
  <parameter name="tts.lang" value="de-DE" />

</adapter>

```

## 11.49. PicoBoard\_Adapter

Interface to PicoBoard by USB-connection

PicoBoard is an USB-connected interface board, serial style. It provides a slider, button, sound sensor, light sensor and resistor-measuring inputs.

This board is fairly well supported by scratch directly. Use this adapter, if you need two of them, or need to have a look to raw values.

### Class

`adapter.serialAdapter.PicoBoard_Adapter`

## Output Values

button	stringType [132]	button value, in raw, 0 when pressed, 1023 else. "true" when pressed, "false" else.
light	floatType [131]	light value, in raw 0..1023 (bright to dark), else 100..0 (bright to dark).
sensorA	floatType [131]	sensorA value, in raw 0..1023, else 0..100.
sensorB	floatType [131]	sensorB value, in raw 0..1023, else 0..100.
sensorC	floatType [131]	sensorC value, in raw 0..1023, else 0..100.
sensorD	floatType [131]	sensorD value, in raw 0..1023, else 0..100.
slider	floatType [131]	slider value, in raw 0..1023, else 0..100.
sound	floatType [131]	sound value, in raw 0..1023 (quiet to loud), else 0..100.

## Parameter (mandatory)

picoBoard.raw	booleanType [131]	If true, the values are transmitted to scratch as send by the board. If false, the values are scaled as for the ScratchBoard.
serial.baud	intType [131]	Default is 38400. This value is used in firmware.
serial.device	stringType [132]	on windows, use COMn, e.g. COM6 on raspberry, use /dev/tty, e.g. /dev/ttyUSB0

## Sample configuration

```

<adapter class='adapter.serialAdapter.PicoBoard_Adapter' name='picoboard'>
  <description>Send receive text messages</description>

  <output_value name='slider'>
    <sensor name='slider' />
  </output_value>

  <output_value name='light'>
    <sensor name='light' />
  </output_value>

  <output_value name='sound'>
    <sensor name='sound' />
  </output_value>

  <output_value name='button'>
    <sensor name='button' />
  </output_value>

  <output_value name='sensorA'>
    <sensor name='resistance-A' />
  </output_value>

  <output_value name='sensorB'>
    <sensor name='resistance-B' />
  </output_value>

  <output_value name='sensorC'>
    <sensor name='resistance-C' />
  </output_value>

  <output_value name='sensorD'>
    <sensor name='resistance-D' />
  </output_value>

  <parameter name='serial.device' value='/dev/ttyUSB0' />
  <parameter name='serial.baud' value='38400' />

  <parameter name='picoBoard.raw' value='false' />

</adapter>

```



## 11.50. Pigpiod\_DHT11\_Adapter

HC-SR04 connection by pigpiod-daemon

DHT11 or DHT22 sensor, using pigpiod daemon. The daemon must be started.

Values are measured prox each 3 sec.

### Class

adapter.pigpiodAdapter.Pigpiod\_DHT11\_Adapter

### Output Values

humidity	floatType [131]	humidity value measured from sensor.
temperature	floatType [131]	temperature value measured from sensor.

### Sample configuration

```
<adapter class='adapter.pigpiodAdapter.Pigpiod_DHT11_Adapter' name='dht11'>
  <description>Sample DHT11, DHT22</description>

  <gpio port='GPIO23'>
    <default dir='IN' pull='PUD_OFF' />
    <active dir='RESERVED' />
  </gpio>

  <output_value name='temperature'>
    <sensor name='temperature' />
  </output_value>
  <output_value name='humidity'>
    <sensor name='humidity' />
  </output_value>

</adapter>
```

## 11.51. Pigpiod\_PWM\_Adapter

PWM control by pigpiod-daemon

Control PWM signals.

pigpiod must be started. If connection is not available, then reconnect is retried each 30 sec.

pigpiod is started with scratch1.4 start script.

### Class

adapter.pigpiodAdapter.Pigpiod\_PWM\_Adapter

### Input Values

rate	floatType [131]	Pulse width, range [0.0 .. 100.0].
------	-----------------	------------------------------------

### Parameter (mandatory)

frequency	float100Type [131]	frequency in Hz
rate	float100Type [131]	default rate, 0..100

### Sample configuration

```
<adapter class='adapter.pigpiodAdapter.Pigpiod_PWM_Adapter' name='rgb_A_B'>
  <description>RGB_A, Blau</description>
```

```

    <gpio port='IKG.IO.2'>
      <default dir='OUT' default='high' />
      <active dir='OUT' default='low' />
    </gpio>

    <input_value name='rate'>
      <variable name='rgb_A_B' />
    </input_value>

    <parameter name='frequency' value='50' />
    <parameter name='rate' value='90' />

  </adapter>

```

## 11.52. Pressure\_BMP085\_Input

Interface for air pressure sensor BMP085

Environmental sensor air pressure and temperature

### Class

adapter.i2cAdapter.Pressure\_BMP085\_Input

### Output Values

pressure	floatType [131]	pressure in pa
temperature	floatType [131]	temperature in °C

### Parameter (mandatory)

i2c.address	intOrHexType [131]	Depending on address select, the bus address is '0x77' for BMP085
i2c.bus	intOrHexType [131]	bus is '1' for RPi Release 2
poll.interval	floatType [131]	poll interval in secs, e.g. 0.05

### Sample configuration

```

<adapter class='adapter.i2cAdapter.Pressure_BMP085_Input' name='pressure'>
  <description>Pressure-Value from BMP085
  Connected to I2C-Bus.
</description>

  <output_value name='pressure'>
    <sensor name='pressure' />
  </output_value>

  <output_value name='temperature'>
    <sensor name='temperature' />
  </output_value>

  <parameter name='poll.interval' value='2.5' />

  <!-- bus is '1' for RPi Release 2 -->
  <parameter name='i2c.bus' value='1' />

  <!-- Depending on address select, the bus address is '0x77' for BMP085 -->
  <parameter name='i2c.address' value='0x77' />
</adapter>

```

## 11.53. PWM\_PCA9685

Interface for Luminosity sensor BH1750

16-channel, 12-bit PWM Fm+ I2C-bus LED controller

**Class**

adapter.i2cAdapter.PWM\_PCA9685

**Input Values**

channel_0	float100Type [131]	input from scratch to adapter, value = 0..100
channel_1	float100Type [131]	input from scratch to adapter, value = 0..100
channel_10	float100Type [131]	input from scratch to adapter, value = 0..100
channel_11	float100Type [131]	input from scratch to adapter, value = 0..100
channel_12	float100Type [131]	input from scratch to adapter, value = 0..100
channel_13	float100Type [131]	input from scratch to adapter, value = 0..100
channel_14	float100Type [131]	input from scratch to adapter, value = 0..100
channel_15	float100Type [131]	input from scratch to adapter, value = 0..100
channel_2	float100Type [131]	input from scratch to adapter, value = 0..100
channel_3	float100Type [131]	input from scratch to adapter, value = 0..100
channel_4	float100Type [131]	input from scratch to adapter, value = 0..100
channel_5	float100Type [131]	input from scratch to adapter, value = 0..100
channel_6	float100Type [131]	input from scratch to adapter, value = 0..100
channel_7	float100Type [131]	input from scratch to adapter, value = 0..100
channel_8	float100Type [131]	input from scratch to adapter, value = 0..100
channel_9	float100Type [131]	input from scratch to adapter, value = 0..100
servo_0	float100Type [131]	input from scratch to adapter, value = 0..100,1 to 2ms pulse with at 50Hz
servo_1	float100Type [131]	input from scratch to adapter, value = 0..100,1 to 2ms pulse with at 50Hz
servo_10	float100Type [131]	input from scratch to adapter, value = 0..100,1 to 2ms pulse with at 50Hz
servo_11	float100Type [131]	input from scratch to adapter, value = 0..100,1 to 2ms pulse with at 50Hz
servo_12	float100Type [131]	input from scratch to adapter, value = 0..100,1 to 2ms pulse with at 50Hz
servo_13	float100Type [131]	input from scratch to adapter, value = 0..100,1 to 2ms pulse with at 50Hz
servo_14	float100Type [131]	input from scratch to adapter, value = 0..100,1 to 2ms pulse with at 50Hz
servo_15	float100Type [131]	input from scratch to adapter, value = 0..100,1 to 2ms pulse with at 50Hz
servo_2	float100Type [131]	input from scratch to adapter, value = 0..100,1 to 2ms pulse with at 50Hz
servo_3	float100Type [131]	input from scratch to adapter, value = 0..100,1 to 2ms pulse with at 50Hz
servo_4	float100Type [131]	input from scratch to adapter, value = 0..100,1 to 2ms pulse with at 50Hz

servo_5	float100Type [131]	input from scratch to adapter, value = 0..100,1 to 2ms pulse with at 50Hz
servo_6	float100Type [131]	input from scratch to adapter, value = 0..100,1 to 2ms pulse with at 50Hz
servo_7	float100Type [131]	input from scratch to adapter, value = 0..100,1 to 2ms pulse with at 50Hz
servo_8	float100Type [131]	input from scratch to adapter, value = 0..100,1 to 2ms pulse with at 50Hz
servo_9	float100Type [131]	input from scratch to adapter, value = 0..100,1 to 2ms pulse with at 50Hz

**Parameter (mandatory)**

frequency	floatType [131]	frequency in Hz, 50Hz for Servo are recommended
i2c.address	intOrHexType [131]	Depending on address select, the bus address is '0x40' for device
i2c.bus	intOrHexType [131]	bus is '1' for RPi Release 2

**Sample configuration**

```
<adapter class='adapter.i2cAdapter.PWM_PCA9685' name='16-channel PWM'>
  <description>DEMO for the PCA adapter.</description>
```

```

  <!-- the scratch variable names are simply the method names here. Could be more useful... -->
  <input_value name='channel_0'>
    <variable name='channel_0' />
  </input_value>

  <input_value name='channel_1'>
    <variable name='channel_1' />
  </input_value>

  <input_value name='channel_2'>
    <variable name='channel_2' />
  </input_value>

  <input_value name='channel_3'>
    <variable name='channel_3' />
  </input_value>

  <input_value name='channel_4'>
    <variable name='channel_4' />
  </input_value>

  <input_value name='channel_5'>
    <variable name='channel_5' />
  </input_value>

  <input_value name='channel_6'>
    <variable name='channel_6' />
  </input_value>

  <input_value name='channel_7'>
    <variable name='channel_7' />
  </input_value>

  <input_value name='channel_8'>
    <variable name='channel_8' />
  </input_value>

  <input_value name='channel_9'>
    <variable name='channel_9' />
  </input_value>

  <input_value name='channel_10'>
    <variable name='channel_10' />
  </input_value>
```

```
<input_value name='servo_0'>
  <variable name='servo_0' />
</input_value>

<input_value name='servo_1'>
  <variable name='servo_1' />
</input_value>

<input_value name='servo_2'>
  <variable name='servo_2' />
</input_value>

<input_value name='servo_3'>
  <variable name='servo_3' />
</input_value>

<input_value name='servo_4'>
  <variable name='servo_4' />
</input_value>

<input_value name='servo_5'>
  <variable name='servo_5' />
</input_value>

<input_value name='servo_6'>
  <variable name='servo_6' />
</input_value>

<input_value name='servo_7'>
  <variable name='servo_7' />
</input_value>

<input_value name='servo_8'>
  <variable name='servo_8' />
</input_value>

<input_value name='servo_9'>
  <variable name='servo_9' />
</input_value>

<input_value name='servo_10'>
  <variable name='servo_10' />
</input_value>

<!-- frequency 50Hz is used for servo -->
<!-- frequency in range 1526 Hz to 24 Hz -->

<parameter name='frequency' value='50' />

<!-- bus is '1' for RPi Release 2 -->
<parameter name='i2c.bus' value='1' />

<!-- Depending on address select, the bus address is
'0x40' for all address lines low.
-->
<parameter name='i2c.address' value='0x40' />

</adapter>
```

## 11.54. PWM\_SN3218

18 channel, 8-bit PWM I2C-bus LED controller

18 channel, 8-bit PWM I2C-bus LED controller PIGLOW board from pimoroni

### Class

adapter.i2cAdapter.PWM\_SN3218

## Input Values

channel_00	float100Type [131]	input from scratch to adapter, value = 0..100
channel_01	float100Type [131]	input from scratch to adapter, value = 0..100
channel_02	float100Type [131]	input from scratch to adapter, value = 0..100
channel_03	float100Type [131]	input from scratch to adapter, value = 0..100
channel_04	float100Type [131]	input from scratch to adapter, value = 0..100
channel_05	float100Type [131]	input from scratch to adapter, value = 0..100
channel_06	float100Type [131]	input from scratch to adapter, value = 0..100
channel_07	float100Type [131]	input from scratch to adapter, value = 0..100
channel_08	float100Type [131]	input from scratch to adapter, value = 0..100
channel_09	float100Type [131]	input from scratch to adapter, value = 0..100
channel_0A	float100Type [131]	input from scratch to adapter, value = 0..100
channel_0B	float100Type [131]	input from scratch to adapter, value = 0..100
channel_0C	float100Type [131]	input from scratch to adapter, value = 0..100
channel_0D	float100Type [131]	input from scratch to adapter, value = 0..100
channel_0E	float100Type [131]	input from scratch to adapter, value = 0..100
channel_0F	float100Type [131]	input from scratch to adapter, value = 0..100
channel_10	float100Type [131]	input from scratch to adapter, value = 0..100
channel_11	float100Type [131]	input from scratch to adapter, value = 0..100

## Parameter (mandatory)

i2c.address	intOrHexType [131]	fixed '0x54' for device
i2c.bus	intOrHexType [131]	bus is '1' for RPi Release 2

## Sample configuration

```

<adapter class='adapter.i2cAdapter.PWM_SN3218' name='18-channel PWM'>
  <description>DEMO for the SN3218 adapter. This is the device used by the piglow-board</description>

  <input_value name='channel_00'>
    <variable name='channel_00' />
    <variable name='all' />
    <variable name='branch_0' />
  </input_value>

  <input_value name='channel_01'>
    <variable name='channel_01' />
    <variable name='all' />
    <variable name='branch_0' />
  </input_value>

```

```
<input_value name='channel_02'>
  <variable name='channel_02' />
  <variable name='all' />
  <variable name='branch_0' />
</input_value>

<input_value name='channel_03'>
  <variable name='channel_03' />
  <variable name='all' />
  <variable name='branch_0' />
</input_value>

<input_value name='channel_04'>
  <variable name='channel_04' />
  <variable name='all' />
  <variable name='branch_1' />
</input_value>

<input_value name='channel_05'>
  <variable name='channel_05' />
  <variable name='all' />
  <variable name='branch_1' />
</input_value>

<input_value name='channel_06'>
  <variable name='channel_06' />
  <variable name='all' />
  <variable name='branch_1' />
</input_value>

<input_value name='channel_07'>
  <variable name='channel_07' />
  <variable name='all' />
  <variable name='branch_1' />
</input_value>

<input_value name='channel_08'>
  <variable name='channel_08' />
  <variable name='all' />
  <variable name='branch_1' />
</input_value>

<input_value name='channel_09'>
  <variable name='channel_09' />
  <variable name='all' />
  <variable name='branch_1' />
</input_value>

<input_value name='channel_0A'>
  <variable name='channel_0A' />
  <variable name='all' />
  <variable name='branch_2' />
</input_value>

<input_value name='channel_0B'>
  <variable name='channel_0B' />
  <variable name='all' />
  <variable name='branch_2' />
</input_value>

<input_value name='channel_0C'>
  <variable name='channel_0C' />
  <variable name='all' />
  <variable name='branch_0' />
</input_value>

<input_value name='channel_0D'>
  <variable name='channel_0D' />
  <variable name='all' />
  <variable name='branch_2' />
</input_value>
```

```

<input_value name='channel_0E'>
  <variable name='channel_0E' />
  <variable name='all' />
  <variable name='branch_0' />
</input_value>

<input_value name='channel_0F'>
  <variable name='channel_0F' />
  <variable name='all' />
  <variable name='branch_2' />
</input_value>

<input_value name='channel_10'>
  <variable name='channel_10' />
  <variable name='all' />
  <variable name='branch_2' />
</input_value>

<input_value name='channel_11'>
  <variable name='channel_11' />
  <variable name='all' />
  <variable name='branch_2' />
</input_value>

<!-- bus is '1' for RPi Release 2 -->
<parameter name='i2c.bus' value='1' />

<!-- address is fixed for this device -->
<parameter name='i2c.address' value='0x54' />

</adapter>

```

## 11.55. RFID\_Reader\_Adapter

Interface to Innovation ID-2LA, ID-12LA, ID-20LA, by Raspberry serial-connection

Set protocol to ASCII !

Power the device by 3.3V, and use Rx-Input of RaspberryPi

After data have been send, an event is send by the adapter.

### Class

adapter.serialAdapter.RFID\_Reader\_Adapter

### Output Event

data_event	when a read event has been performed.
------------	---------------------------------------

### Output Values

data	stringType [132]	10 chars.
------	------------------	-----------

### Parameter (mandatory)

serial.baud	intType [131]	Use 9600.
serial.device	stringType [132]	on raspberry, use /dev/ttyAMA0

### Sample configuration

```

<adapter class='adapter.serialAdapter.RFID_Reader_Adapter' name='rfidReader'>
<description>Read a tag from INNOVATIONS ID-12LA or alike</description>

<output_value name='data'>
  <sensor name='rfid' />
</output_value>
<output name='data_event'>
  <broadcast name='rfid_available' />
</output>

```



```

        <parameter name='serial.device' value='/dev/ttyAMA0' />
        <parameter name='serial.baud' value='9600' />

    </adapter>

```

## 11.56. ScratchStartclickedAdapter

Send start broadcast event at connection start.

Send start broadcast event at connection start

Can be configured to send arbitrary events on connection start.

### Class

adapter.broadcast.ScratchStartclickedAdapter

### Sample configuration

```

<adapter class='adapter.broadcast.ScratchStartclickedAdapter' name='startClick'>
  <output name='command'>
    <broadcast name='scratch-startclicked' />
  </output>
  <description>Send startclicked</description>
</adapter>

```

## 11.57. ScrollPhatHd\_Adapter

Pixel output to a Pimoroni SCROLL PHAT HD board.

The board uses one I2C IS31FL3731 LED matrix driver chip.

Allows pixel output and limited text output.

### Class

adapter.scrollphatHdAdapter.ScrollPhatHd\_Adapter

### Input Events

clear	Clear display
-------	---------------

### Input Values

brightness	floatType [131]	Sets brightness, range [0..1]
command	stringType [132]	<p>Various commands to clear, set pixels, set boxes (rect areas).</p> <ul style="list-style-type: none"> <li>'clear'</li> <li>'clear;x;y' clear pixel</li> <li>'clear;x;y;bright' set pixel to brightness</li> <li>'pixel;x;y' set pixel to default brightness</li> <li>'pixel;x;y;bright' set pixel to brightness</li> <li>'box;x;y;width;height' set area to default brightness</li> <li>'box;x;y;width;height;bright' set area to brightness</li> </ul>
text35	stringType [132]	Set text to display. A 3*5-font is used. Five chars can be displayed. Only digits and some extra chars like '+_.,;,' are available. Not for each char a display pattern is available; missing chars are displayed as '#'
text57	stringType [132]	Set text to display. A 5*7-font is used. Three chars can be displayed. Not for each char a display pattern is available; missing chars are displayed as '#'

**Parameter (mandatory)**

scrollphatd.mirror	booleanType [131]	mirror left-right
scrollphatd.rotate180	booleanType [131]	rotate display by 180 degree

**Sample configuration**

```

<adapter class='adapter.scrollphatdAdapter.ScrollPhatHd_Adapter' name='mda'>

  <description>Text output</description>

  <!-- use a 5*7 font -->
  <input_value name='text_5_7'>
    <variable name='text57' />
  </input_value>

  <!-- use a 3*5 font, only digits and some extra as '+-_.:',' ! -->
  <input_value name='text_3_5'>
    <variable name='text35' />
  </input_value>

  <input_value name='brightness'>
    <variable name='bright' />
  </input_value>

  <input_value name='command'>
    <variable name='sph_command' />
  </input_value>

  <input name='clear'>
    <broadcast name='clearDisplay' />
  </input>

  <parameter name='scrollphatd.rotate180' value='false' />
  <parameter name='scrollphatd.mirror' value='false' />
</adapter>

```

**11.58. SenseHat\_Adapter**

Sense-Hat Adapter.

Installation procedures for senseHat required.

Supports LED, sensors and orientation.

setPixel\_xy: depends on setting x\_pos, y\_pos and color values.

clearPixel\_xy: depends on setting x\_pos, y\_pos.

**Class**

adapter.senseHat\_adapter.SenseHat\_Adapter

**Input Events**

clear	calls sense.clear(); clears the LED matrix
clearPixel_xy	shuts off LED pixel on x,y position.
setPixel_xy	sets pixel on x,y position to color. Depends on setting x_pos, y_pos and color first.

**Input Values**

color	colorType [131]	color for pixel to set.
x_pos	intType [131]	x-pos to address the LED-matrix, [0..7].
y_pos	intType [131]	y-pos to address the LED-matrix, [0..7].

**Output Values**

humidity	floatType [131]	humidity, rounded to one decimal digit.
----------	-----------------	---

orientation_pitch	floatType	[131]	orientation_pitch, rounded to one decimal digit.
orientation_roll	floatType	[131]	orientation_roll, rounded to one decimal digit.
orientation_yaw	floatType	[131]	orientation_yaw, rounded to one decimal digit.
pressure	floatType	[131]	pressure, rounded to one decimal digit.
temperature	floatType	[131]	temperature, rounded to one decimal digit.

**Parameter (mandatory)**

poll.interval	floatType	[131]	poll rate in seconds, default 0.1 sec.
---------------	-----------	-------	--

**Sample configuration**

```

<adapter class='adapter.senseHat_adapter.SenseHat_Adapter' name='astro-pi'>

  <!-- -->

  <description>SenseHat. LED environmental sensors, orientation</description>

  <input name= 'clear'>
    <broadcast name='sense_led_clear' />
  </input>

  <input name= 'setPixel_xy'>
    <broadcast name='sense_led_xy_on' />
  </input>

  <input name= 'clearPixel_xy'>
    <broadcast name='sense_led_xy_off' />
    <!-- there is a flaw in the sample scratch code which
           has partial misspelling of one event, so add this wrong name too -->
    <broadcast name='semse_led_xy_off' />
  </input>

  <!-- variables for setting pixels -->

  <input_value name='pixelX'>
    <variable name='x_pos' />
  </input_value>

  <input_value name='pixelY'>
    <variable name='y_pos' />
  </input_value>

  <input_value name='color'>
    <variable name='color' />
  </input_value>

  <!-- environmental sensors from adapter to scratch -->

  <output_value name='temperature'>
    <sensor name='temperature' />
  </output_value>

  <output_value name='pressure'>
    <sensor name='pressure' />
  </output_value>

  <output_value name='humidity'>
    <sensor name='humidity' />
  </output_value>

  <!-- IMU sensors from adapter to scratch -->

  <output_value name='orientation_pitch'>
    <sensor name='orientation_pitch' />
  </output_value>

  <output_value name='orientation_roll'>
    <sensor name='orientation_roll' />
  </output_value>

```

```

        <output_value name='orientation_yaw'>
            <sensor name='orientation_yaw' />
        </output_value>

        <!-- polling time for external device -->
        <parameter name='poll.interval' value='0.1' />

    </adapter>

```

## 11.59. ServoBlaster

ServoBlaster driver

Servoblaster runs as daemon servod in the background and needs to be started manually.

See servoblaster doku for assignment of channel index numbers to GPIO pins.

### Class

adapter.servoblaster.ServoBlaster

### Input Values

servo_0	float100Type [131]	values 0..100
servo_1	float100Type [131]	values 0..100
servo_2	float100Type [131]	values 0..100
servo_3	float100Type [131]	values 0..100
servo_4	float100Type [131]	values 0..100
servo_5	float100Type [131]	values 0..100
servo_6	float100Type [131]	values 0..100
servo_7	float100Type [131]	values 0..100

### Parameter (optional)

millisecond.0.max	floatType [131]	default 2 [ms]. Optional max value in range 1.1..2.5 [ms]
millisecond.0.min	floatType [131]	default 1 [ms]. Optional min value in range 0.5..1.9 [ms]
millisecond.1.max	floatType [131]	default 2 [ms]. Optional max value in range 1.1..2.5 [ms]
millisecond.1.min	floatType [131]	default 1 [ms]. Optional min value in range 0.5..1.9 [ms]
millisecond.2.max	floatType [131]	default 2 [ms]. Optional max value in range 1.1..2.5 [ms]
millisecond.2.min	floatType [131]	default 1 [ms]. Optional min value in range 0.5..1.9 [ms]
millisecond.3.max	floatType [131]	default 2 [ms]. Optional max value in range 1.1..2.5 [ms]
millisecond.3.min	floatType [131]	default 1 [ms]. Optional min value in range 0.5..1.9 [ms]
millisecond.4.max	floatType [131]	default 2 [ms]. Optional max value in range 1.1..2.5 [ms]
millisecond.4.min	floatType [131]	default 1 [ms]. Optional min value in range 0.5..1.9 [ms]
millisecond.5.max	floatType [131]	default 2 [ms]. Optional max value in range 1.1..2.5 [ms]
millisecond.5.min	floatType [131]	default 1 [ms]. Optional min value in range 0.5..1.9 [ms]
millisecond.6.max	floatType [131]	default 2 [ms]. Optional max value in range 1.1..2.5 [ms]
millisecond.6.min	floatType [131]	default 1 [ms]. Optional min value in range 0.5..1.9 [ms]
millisecond.7.max	floatType [131]	default 2 [ms]. Optional max value in range 1.1..2.5 [ms]
millisecond.7.min	floatType [131]	default 1 [ms]. Optional min value in range 0.5..1.9 [ms]

## Sample configuration

```
<adapter class='adapter.servoblaster.ServoBlaster' name='servoblaster'>
  <description>servoblaster for 8 channels. See servoblaster doku for
    assignment of channel index numbers to GPIO pins.</description>

  <!-- looks strange, but could do some renaming for scratch variables here -->
  <input_value name= 'servo_0'>
    <variable name='servo_0' />
  </input_value>
  <input_value name= 'servo_1'>
    <variable name='servo_1' />
  </input_value>
  <input_value name= 'servo_2'>
    <variable name='servo_2' />
  </input_value>
  <input_value name= 'servo_3'>
    <variable name='servo_3' />
  </input_value>
  <input_value name= 'servo_4'>
    <variable name='servo_4' />
  </input_value>
  <input_value name= 'servo_5'>
    <variable name='servo_5' />
  </input_value>
  <input_value name= 'servo_6'>
    <variable name='servo_6' />
  </input_value>
  <input_value name= 'servo_7'>
    <variable name='servo_7' />
  </input_value>
</adapter>
```

## 11.60. SonicPi\_Adapter

Sonic Pi OSC API

Allows to use Sonic Pi commands from scratch.

### Class

adapter.sonicpiAdapter.SonicPi\_Adapter

### Input Values

sonicpi	stringType [132]	A sonic pi command like 'play 50'
---------	------------------	-----------------------------------

### Parameter (mandatory)

sonicpi.agent	stringType [132]	SONIC_PI_CLI
sonicpi.port	intType [131]	Port is fixed to 4557
sonicpi.server	stringType [132]	127.0.0.1

### Sample configuration

```
<adapter class='adapter.sonicpiAdapter.SonicPi_Adapter' name='sonicpi'>
  <description>interface to a SONIC PI-server</description>

  <!--
    Sonic Pi must run on same machine.
  -->

  <input_value name="sonicpi">
    <variable name="sonicpi_cmd" />
  </input_value>

  <parameter name="sonicpi.server" value="127.0.0.1" />
  <parameter name="sonicpi.port" value="4557" />
  <parameter name="sonicpi.agent" value="SONIC_PI_CLI" />
```

```
</adapter>
```

## 11.61. TimeAdapter

Send current system time values (second, minute, hour, day, month, year) to scratch.

System time is not available in scratch 1.4. The adapter provides current system time.

### Class

adapter.broadcast.TimeAdapter

### Sample configuration

```
<adapter class='adapter.broadcast.TimeAdapter' name='currentTime'>

  <description>System time for Scratch 1.4</description>

  <output_value name='second'>
    <sensor name='time.second' />
  </output_value>

  <output_value name='minute'>
    <sensor name='time.minute' />
  </output_value>

  <output_value name='hour'>
    <sensor name='time.hour' />
  </output_value>

  <output_value name='day'>
    <sensor name='time.day' />
  </output_value>

  <output_value name='month'>
    <sensor name='time.month' />
  </output_value>

  <output_value name='year'>
    <sensor name='time.year' />
  </output_value>

  <parameter name='poll.interval' value='0.2' />

</adapter>
```

## 11.62. Touch\_MPR121

MPR121-Adapter, 12 channel touch controller.

The adapter provides 12 touch channels. The code is based on libraries from [adafruit.com](https://adafruit.com)

The adjustment is performed at connection time. If you change the layout of sensors, then disable/enable connection.

### Class

adapter.i2cAdapter.Touch\_MPR121

### Output Event

touch_evt_00	when button press detected
touch_evt_01	when button press detected
touch_evt_02	when button press detected
touch_evt_03	when button press detected
touch_evt_04	when button press detected
touch_evt_05	when button press detected
touch_evt_06	when button press detected

touch_evt_07	when button press detected
touch_evt_08	when button press detected
touch_evt_09	when button press detected
touch_evt_10	when button press detected
touch_evt_11	when button press detected

## Output Values

touch_00	intType [131]	0..1
touch_01	intType [131]	0..1
touch_02	intType [131]	0..1
touch_03	intType [131]	0..1
touch_04	intType [131]	0..1
touch_05	intType [131]	0..1
touch_06	intType [131]	0..1
touch_07	intType [131]	0..1
touch_08	intType [131]	0..1
touch_09	intType [131]	0..1
touch_10	intType [131]	0..1
touch_11	intType [131]	0..1

## Parameter (mandatory)

i2c.address	intType [131]	Base address, int or hex.
i2c.bus	intType [131]	Bus number, usually 1 on RPi.
poll.interval	floatType [131]	poll rate.

## Sample configuration

```

<adapter class='adapter.i2cAdapter.Touch_MPR121' name='touch'>
  <description>Touch values from a MPR121</description>

  <output_value name='touch_00'> <sensor name='mpr121_00' /> </output_value>
  <output_value name='touch_01'> <sensor name='mpr121_01' /> </output_value>
  <output_value name='touch_02'> <sensor name='mpr121_02' /> </output_value>
  <output_value name='touch_03'> <sensor name='mpr121_03' /> </output_value>
  <output_value name='touch_04'> <sensor name='mpr121_04' /> </output_value>
  <output_value name='touch_05'> <sensor name='mpr121_05' /> </output_value>
  <output_value name='touch_06'> <sensor name='mpr121_06' /> </output_value>
  <output_value name='touch_07'> <sensor name='mpr121_07' /> </output_value>
  <output_value name='touch_08'> <sensor name='mpr121_08' /> </output_value>
  <output_value name='touch_09'> <sensor name='mpr121_09' /> </output_value>
  <output_value name='touch_10'> <sensor name='mpr121_10' /> </output_value>
  <output_value name='touch_11'> <sensor name='mpr121_11' /> </output_value>

  <output name='event_00'> <broadcast name='mpr121_evt_00' /> </output>
  <output name='event_01'> <broadcast name='mpr121_evt_01' /> </output>
  <output name='event_02'> <broadcast name='mpr121_evt_02' /> </output>
  <output name='event_03'> <broadcast name='mpr121_evt_03' /> </output>
  <output name='event_04'> <broadcast name='mpr121_evt_04' /> </output>
  <output name='event_05'> <broadcast name='mpr121_evt_05' /> </output>
  <output name='event_06'> <broadcast name='mpr121_evt_06' /> </output>
  <output name='event_07'> <broadcast name='mpr121_evt_07' /> </output>
  <output name='event_08'> <broadcast name='mpr121_evt_08' /> </output>
  <output name='event_09'> <broadcast name='mpr121_evt_09' /> </output>
  <output name='event_10'> <broadcast name='mpr121_evt_10' /> </output>
  <output name='event_11'> <broadcast name='mpr121_evt_11' /> </output>

  <parameter name='poll.interval' value='0.1' />

  <!-- bus is '1' for RPi Release 2 -->
  <parameter name='i2c.bus' value='1' />

  <!-- address is '0x5a' for adafruit MPR121 -->

```

```
<parameter name='i2c.address' value='0x5a' />

</adapter>
```

## 11.63. Twitter\_Adapter

Reading twitter messages by 'term' or 'hashname'.

Read twitter messages by hashtag name 'term'. Needs credentials from twitter to work.

Needs installation of 'python-twitter'.

### Class

adapter.twitterAdapter.Twitter\_Adapter

### Input Events

textAcknowledge	when a text variable is processed, send acknowledge to receive next text.
-----------------	---

### Output Event

textAvailable	A text variable is available in scratch and can be processed.
---------------	---

### Output Values

status	stringType [132]	Status information from adapter.
text	stringType [132]	A message from twitter.

### Parameter (mandatory)

scratch.timeout	intType [131]	timeout for messages which are aquired by adapter, but not read by scratch.
twitter.access_token	stringType [132]	Get these from twitter for your account
twitter.access_token_secret	stringType [132]	Get these from twitter for your account
twitter.consumer_key	stringType [132]	Get these from twitter for your account
twitter.consumer_secret	stringType [132]	Get these from twitter for your account
twitter.datafile	stringType [132]	Write a data file with last message Id. Path needs to be relative. Example 'data/twitter_data.json'
twitter.pollrate	intType [131]	twitter account has limits on polling rate: 15 requests per 15 minutes are allowed. See twitter.com for details. if you see messages 'Rate limit exceeded', then increase this parameter. 60 sec are a good starting point.
twitter.read.direct	booleanType [131]	Read direct messages. One of 'direct' or 'term' needs to be specified.
twitter.read.term	booleanType [131]	Read search messages with 'term'. One of 'direct' or 'term' needs to be specified.
twitter.term	stringType [132]	Get messages with 'term' from twitter. Example '#raspberrytweet'

### Sample configuration

```
<adapter class='adapter.twitterAdapter.Twitter_Adapter' name='twitter'>
  <description>text output from twitter messages</description>

  <input name='textAcknowledge'>
    <broadcast name='ack' />
  </input>

  <output name='textAvailable'>
    <broadcast name='listen' />
  </output>

  <output_value name='text'>
    <sensor name='text' />
  </output_value>
```



```

<output_value name='status'>
  <sensor name='status' />
</output_value>

<parameter name='twitter.consumer_key' value='' />
<parameter name='twitter.consumer_secret' value='' />
<parameter name='twitter.access_token_key' value='' />
<parameter name='twitter.access_token_secret' value='' />

<parameter name='twitter.term' value = '#raspberrytweet' />
<parameter name='twitter.datafile' value= 'data/twitter_data.json' />

<!-- twitter account has limits on polling rate
      15 requests per 15 minutes are allowed. See twitter.com for details.
      if you see messages 'Rate limit exceeded', then increase this parameter -->
<parameter name='twitter.pollrate' value= '60' />

<parameter name='twitter.read.direct' value= 'true' />
<parameter name='twitter.read.term' value= 'true' />

<!-- scratch will ignore those messages received earlier than 'scratch.timeout' -->
<parameter name='scratch.timeout' value= '60' />

</adapter>

```

## 11.64. UnipolarStepperModule

Drives an unipolar stepper motor.

The adapter does all the low level step pattern management and receives target position and speed values from scratch. This achieves faster steps than controlling single step events from scratch.

When a position is reached, a 'stopped' signal is issued.

### Class

adapter.stepper.UnipolarStepperModule

### Input Events

reset_4	resets position; sets the drive pattern to a '4 step pattern', fast, less smooth
reset_8	resets position; sets the drive pattern to a '8 step pattern', slow, smooth

### Input Values

speed	floatType [131]	float values, time between steps.
target	floatType [131]	Absolute values. integer values, positive or negative.

### Output Event

complete	position reached
----------	------------------

### Sample configuration

```

<adapter class='adapter.stepper.UnipolarStepperModule' name='stepper'>

  <description>stepper control for unipolar stepper
</description>

  <gpio port='GPIO25' alias='br0.0'>
    <default dir='OUT' pull='PUD_OFF' default='low' />
    <active dir='OUT' pull='PUD_OFF' />
  </gpio>
  <gpio port='GPIO24' alias='br0.1'>
    <default dir='OUT' pull='PUD_OFF' default='low' />
    <active dir='OUT' pull='PUD_OFF' />
  </gpio>

  <gpio port='GPIO23' alias='br1.0'>

```

```

        <default dir='OUT' pull='PUD_OFF' default='low' />
        <active dir='OUT' pull='PUD_OFF' />
    </gpio>
    <gpio port='GPIO18' alias='br1.1'>
        <default dir='OUT' pull='PUD_OFF' default='low' />
        <active dir='OUT' pull='PUD_OFF' />
    </gpio>

    <input name='reset_8'>
        <broadcast name='reset_8' />
    </input>

    <input name='reset_4'>
        <broadcast name='reset_4' />
    </input>
    <input_value name='speed'>
        <variable name='speed' />
    </input_value>

    <input_value name='target'>
        <variable name='target' />
    </input_value>

    <!-- signal added 2016-05-08 -->
    <output name='complete'>
        <broadcast name='position_reached' />
    </output>

</adapter>

```

## 11.65. UnipolarStepperStep

Drives an unipolar stepper motor.

Driver for an unipolar stepper, where drive patterns are controlled by scratch. This is quite slow, but allows for teaching the basics.

### Class

adapter.stepper.UnipolarStepperStep

### Input Values

binaryPattern	binary4Type [131]	Binary pattern for all four outputs. Syntax is like "b0000". The digits adress br0.0, br0.1, br1.0, br1.1
br0_0	binaryType [131]	Value '0', '1', switches output br0.0
br0_1	binaryType [131]	Value '0', '1', switches output br0.1
br1_0	binaryType [131]	Value '0', '1', switches output br1.0
br1_1	binaryType [131]	Value '0', '1', switches output br1.1

### Sample configuration

```

<adapter class='adapter.stepper.UnipolarStepperStep' name='stepper'>

    <description>stepper control for unipolar stepper
    Allows for discrete switch signals br0.0, br0.1, br1.0, br1.1
    or binary inputs 'pattern', e.g b0001, b0011, ...
    </description>

    <gpio port='GPIO25' alias='br0.0'>
        <default dir='OUT' pull='PUD_OFF' default='low' />
        <active dir='OUT' pull='PUD_OFF' />
    </gpio>
    <gpio port='GPIO24' alias='br0.1'>
        <default dir='OUT' pull='PUD_OFF' default='low' />
        <active dir='OUT' pull='PUD_OFF' />
    </gpio>

    <gpio port='GPIO23' alias='br1.0'>

```

```

        <default dir='OUT' pull='PUD_OFF' default='low' />
        <active dir='OUT' pull='PUD_OFF' />
    </gpio>
    <gpio port='GPIO18' alias='br1.1'>
        <default dir='OUT' pull='PUD_OFF' default='low' />
        <active dir='OUT' pull='PUD_OFF' />
    </gpio>

    <input_value name='br0_0'>
        <variable name='br0.0' />
    </input_value>
    <input_value name='br0_1'>
        <variable name='br0.1' />
    </input_value>
    <input_value name='br1_0'>
        <variable name='br1.0' />
    </input_value>
    <input_value name='br1_1'>
        <variable name='br1.1' />
    </input_value>

    <input_value name='binaryPattern'>
        <variable name='pattern' />
    </input_value>

</adapter>

```

## 11.66. UNO\_Adapter

Interface to ArduinoUNO by USB-connection

Inputs and outputs depend on configuration. See comments in sample configuration.

### Class

adapter.arduino.UNO\_Adapter

### Parameter (mandatory)

serial.baud	intType [131]	Default is 115200. This value is used in firmware.
serial.device	stringType [132]	on windows, use COMn, e.g. COM6 on raspberry, use /dev/tty, e.g. /dev/ttyAMA0

### Parameter (optional)

ident.check	booleanType [131]	Check ident code programmed in arduino. Default is False.
ident.pattern	stringType [132]	Ident code pattern in arduino. Checked only if ident.check is true.

### Sample configuration

```

<adapter class='adapter.arduino.UNO_Adapter' name='UNO'>

    <!-- input and output methods in python are dynamically generated like
        - inputD4 for io@dir=out [0..1]
        - servoD6 for io@dir=servo [0..180]
        - pwmD6 for io@dir=pwm [0..255]
        - outputD3 for io@dir=in [0..1]
    -->
    <!-- digital input values are inputs for the adapter (but outputs for arduino) -->

    <input_value name='inputD4'>
        <variable name='redLED' />
    </input_value>

    <input_value name='inputD5'>
        <variable name='greenLED' />
    </input_value>

```

```
<output_value name='outputD3'>
  <sensor name='button' />
</output_value>

<!-- output_value methods in python are dynamically generated like outputADA0 for analog@di
<!-- AD-Values are outputs for the adapter (but inputs for arduino) -->

<output_value name='outputADA0'>
  <sensor name='potentiometer_0' />
</output_value>

<!-- on windows, use COMn, e.g. COM6 -->
<!-- on raspberry, use /dev/tty, e.g. /dev/ttyAMA0 -->

<parameter name='serial.device' value='COM6' />
<parameter name='serial.baud' value='115200' />

<!-- optional. When ident.check is true,yes, then only configuration is sent to arduino whe
ident is matching. -->

<parameter name='ident.check' value='yes' />
<parameter name='ident.pattern' value='NANO_000' />

<extension>
  <!-- this is the setup for an UNO arduino -->

  <!-- do not use D0, D1 (serial lines) -->
  <!-- @dir = void, pwm, in, out, servo -->
  <io id='D0' dir='void' />
  <io id='D1' dir='void' />

  <!-- 3,5,6,10,11 may be pwm -->
  <io id='D2' dir='out' />
  <io id='D3' dir='in' pullup='on' />

  <io id='D4' dir='out' />
  <io id='D5' dir='pwm' />

  <io id='D6' dir='out' />
  <io id='D7' dir='out' />

  <io id='D8' dir='in' pullup='on' />
  <io id='D9' dir='in' pullup='on' />
  <io id='D10' dir='in' pullup='on' />
  <io id='D11' dir='in' pullup='on' />

  <io id='D12' dir='in' pullup='on' />

  <!-- do not use D13 (onboard LED) -->

  <io id='D13' dir='void' />

  <analog id='A0' dir='in' />
  <analog id='A1' dir='void' />
  <analog id='A2' dir='void' />
  <analog id='A3' dir='void' />
  <analog id='A4' dir='void' />
  <analog id='A5' dir='void' />
  <!-- on NANO, A6 and A7 are available for analog input -->
  <analog id='A6' dir='void' />
  <analog id='A7' dir='void' />
</extension>
</adapter>
```

## 11.67. UNO\_POWERFUNCTIONS\_Adapter

Interface to ArduinoUNO by USB-connection

Controls LEGO Powerfunctions sending by IR transmitter.

Needs sketch 'arduino/power\_functions' on arduino. An infrared LED needs to be connected from PIN12 by a current limiting diode to 5V. When arduino is not on 5V, look for documentation.

The command choosen for powertools have timeout enabled; refresh is handled in adapter.

Values sent are -7 to 7; BRAKE is a special command.

## Class

adapter.arduino.UNO\_POWERFUNCTIONS\_Adapter

## Input Values

CHANNEL_1_A	stringType [132]	-7 .. 7, BRAKE
CHANNEL_1_B	stringType [132]	-7 .. 7, BRAKE
CHANNEL_2_A	stringType [132]	-7 .. 7, BRAKE
CHANNEL_2_B	stringType [132]	-7 .. 7, BRAKE
CHANNEL_3_A	stringType [132]	-7 .. 7, BRAKE
CHANNEL_3_B	stringType [132]	-7 .. 7, BRAKE
CHANNEL_4_A	stringType [132]	-7 .. 7, BRAKE
CHANNEL_4_B	stringType [132]	-7 .. 7, BRAKE

## Parameter (mandatory)

serial.baud	intType [131]	Default is 115200. This value is used in firmware.
serial.device	stringType [132]	on windows, use COMn, e.g. COM6 on raspberry, use /dev/tty, e.g. /dev/ttyAMA0

## Sample configuration

```
<adapter class='adapter.arduino.UNO_POWERFUNCTIONS_Adapter' name='UNO'>
  <!-- Sample arduino communication. Needs arduino sketch programmed in arduino. -->

  <input_value name='CHANNEL_1_A'>
    <variable name='c_1_A' />
  </input_value>
  <input_value name='CHANNEL_1_B'>
    <variable name='c_1_B' />
  </input_value>
  <input_value name='CHANNEL_2_A'>
    <variable name='c_2_A' />
  </input_value>
  <input_value name='CHANNEL_2_B'>
    <variable name='c_2_B' />
  </input_value>
  <input_value name='CHANNEL_3_A'>
    <variable name='c_3_A' />
  </input_value>
  <input_value name='CHANNEL_3_B'>
    <variable name='c_3_B' />
  </input_value>
  <input_value name='CHANNEL_4_A'>
    <variable name='c_4_A' />
  </input_value>
  <input_value name='CHANNEL_4_B'>
    <variable name='c_4_B' />
  </input_value>

  <!-- ===== -->
  <!-- on windows, use COMn, e.g. COM6 -->
  <!-- on raspberry, use /dev/tty, e.g. /dev/ttyAMA0 -->

  <!--
    <parameter name='serial.device' value='/dev/ttyUSB0' />
  -->
```

```
<parameter name='serial.device' value='COM6' />

<parameter name='serial.baud' value='115200' />

</adapter>
```

## 11.68. W1\_DS1820

DS1820 and related devices, using w1-gpio driver

Needs w1-gpio driver.

### Class

adapter.w1\_gpio.W1\_DS1820

### Output Values

temperature	floatType [131]	value is temperature in °C
-------------	-----------------	----------------------------

### Parameter (mandatory)

poll.interval	floatType [131]	Poll interval in seconds, 0.5 or slower is good.
w1.device	stringType [132]	the id on the w1-bus.

### Sample configuration

```
<adapter class='adapter.w1_gpio.W1_DS1820' name='temp_DS1820'>
  <description>Temp values from DS1820</description>

  <output_value name='temperature'>
    <sensor name='ds18b20' />
  </output_value>

  <parameter name='poll.interval' value='1.0' />

  <!-- start kernel driver gl-gpio
    base dir /sys/bus/w1/devices
  -->
  <parameter name='w1.device' value='10-0008023b57b9' />
</adapter>
```

## 11.69. WebsocketXY\_Adapter

X, Y-Values from an orientation sensor

X, Y-Values from an orientation sensor on a smartphone, sent through some javascript, websocket to RPI. There is the need of a web page providing the javascript too.

### Class

adapter.websocket.WebsocketXY\_Adapter

### Output Event

click	The javascript code sends click-events. These are propagated to scratch.
-------	--

### Output Values

cntValue	intType [131]	
xValue	floatType [131]	x-angle
yValue	floatType [131]	y-angle

## Sample configuration

```
<adapter class='adapter.websocket.WebsocketXY_Adapter' name='XY'>
  <description>X, Y-Values from an orientation sensor</description>

  <output_value name='xValue'>
    <sensor name='goto_X' />
  </output_value>

  <output_value name='yValue'>
    <sensor name='goto_Y' />
  </output_value>

  <output_value name='cntValue'>
    <sensor name='counter' />
  </output_value>

  <output name='click'>
    <broadcast name='click_event' />
  </output>

  <webserver>
    <!-- implement a web socket link 'route' -->
    <route name='pendel' route='/adapter/pendel' />

    <!-- implement a link on start page of web server -->
    <html name='pendel' path='websocket/pendel.html' comment='positional sensor from a smar' />
  </webserver>
</adapter>
```

## 11.70. Wire\_SHTx

SHT15 or alike humidity sensors

Provides scan results from a barcode scanner.

### Class

adapter.wire\_gpio.Wire\_SHTx

### Output Values

humidity	floatType [131]	relative humidity
temperature	floatType [131]	temperature in °C

### Parameter (mandatory)

poll.interval	floatType [131]	polling interval in seconds, min 2 sec.
---------------	-----------------	---

### Sample configuration

```
<adapter class='adapter.wire_gpio.Wire_SHTx' name='Humidity'>
  <description>Humidity-Value from SHT15</description>

  <gpio port='GPIO23' alias='clock'>
    <default dir='IN' pull='PUD_UP' />
    <active dir='IN' pull='PUD_UP' />
  </gpio>

  <gpio port='GPIO24' alias='data'>
    <default dir='IN' pull='PUD_UP' />
    <active dir='IN' pull='PUD_UP' />
  </gpio>

  <output_value name='humidity'>
    <sensor name='humidity' />
  </output_value>
```

```

<output_value name='temperature'>
  <sensor name='temperature' />
</output_value>

<!-- poll time min 1 sec (self heating permits max 1 measurement per sec) -->
<parameter name='poll.interval' value='2' />

</adapter>

```

## 11.71. WS2801\_Adapter

WS2801-LED chain driver

Streaming out Bytes to a WS2801-Device. To keep it simple, the input variable is a concatenated list of color names 'red', 'darkred', 'green', 'blue', 'yellow', 'pink'. Could also be #rrgbbb-hex values, but not implemented for simplicity. Separators are blank.

### Class

adapter.spiAdapter.WS2801\_Adapter

### Input Values

led	colorType [131]	blank-separated color names
-----	-----------------	-----------------------------

### Parameter (mandatory)

led.length	intType [131]	Length of LED chain, e.g. 50
spi.bus	intType [131]	
spi.device	intType [131]	

### Sample configuration

```

<adapter class='adapter.spiAdapter.WS2801_Adapter' name='led_stripe'>

  <description>LED Stripe of 50 </description>

  <input_value name='led'>
    <variable name='led' />
  </input_value>

  <parameter name='led.length' value='50' />

  <parameter name='spi.bus' value='0' />
  <parameter name='spi.device' value='0' />
</adapter>

```

## 11.72. Adapter Data Types

anyType	[.]	scratch will accept any type for variable/sensor input.
binary4Type	b[01]{4}	binary 4 bits, sample is "b0100"
binaryType	[01]	
booleanType	(1 TRUE YES Y HIGH) (0 FALSE NO N LOW)	case insensitive
char7segmentType	[0-9AbCcDEfR-]	case sensitive
colorType	[.]	Colors in plain text format ('red', 'green', 'blue', 'darkred', 'darkgreen', 'darkblue', 'yellow', 'pink', 'magenta', 'off', 'white') or hex format r,g,b (e.g. 'ee23a0' or '#ee23a0')
digitType	[0-9]	0..9
float100Type	[0-9]+([.][0-9]*)?	0..100
floatType	[0-9]+([.][0-9]*)?	0..
intOrHexType	([0-9]+) ([0x0-9A-Fa-f]+)	integer or hex values
intType	[0-9]+	0..



levelType	(1 ON HIGH) (0 OFF LOW)	case insensitive
restrictedStringType	[.]	String, except ['\$V<>&~*']
stringType	[.]	String

---

## Chapter 12. Index

### Index

#### A

##### adapter

- adapter.adapters.Gpio7segment, 81
- adapter.adc.ADC\_MCP3202\_10\_Input, 72
- adapter.adc.ADC\_MCP3202\_12\_Input, 73
- adapter.adc.IRDistanceInput, 92
- adapter.adc\_zone.ADC\_MCP3008\_10\_Input, 71
- adapter.adc\_zone.ADC\_MCP3202\_10\_Zone\_Input, 73
- adapter.arduino.NEOPIXEL\_Adapter, 102
- adapter.arduino.UNO\_Adapter, 126
- adapter.arduino.UNO\_POWERFUNCTIONS\_Adapter, 127
- adapter.broadcast.ScratchStartClickedAdapter, 116
- adapter.broadcast.TimeAdapter, 121
- adapter.Cap1188Adapter.PianoHat\_CAP1188\_Adapter, 104
- adapter.cap1xxxAdapter.CAP1208Adapter, 75
- adapter.dma\_pwm.DMA\_PWM, 78
- adapter.dma\_pwm.DMA\_PWMServo, 79
- adapter.dma\_pwm.DMA\_PWM\_ON\_OFF, 78
- adapter.encoder.GPIODialPlateEncoder, 83
- adapter.encoder.GPIOEncoder, 83
- adapter.gpio.GpioButtonInput, 82
- adapter.gpio.GpioEventInput, 84
- adapter.gpio.GpioInput, 84
- adapter.gpio.GpioMotorPWM, 85
- adapter.gpio.GpioOutput, 86
- adapter.gpio.GpioOutputPWM, 86
- adapter.gpio.GpioOutputPWMServo, 87
- adapter.gpio.GpioOutputPWM\_ON\_OFF, 87
- adapter.gpio.GpioStateOutput, 88
- adapter.gpio.GpioValueInput, 89
- adapter.gpio.GpioValueOutput, 89
- adapter.gpio.Gpio\_HCSR04\_OnePin\_Input, 80
- adapter.gps.GY\_GPS6MV2, 90
- adapter.i2cAdapter.ADC\_ADS1015\_Input, 70
- adapter.i2cAdapter.ADC\_DAC\_PCF8591, 70
- adapter.i2cAdapter.Luminosity\_BH1750\_Input, 96
- adapter.i2cAdapter.Pressure\_BMP085\_Input, 109
- adapter.i2cAdapter.PWM\_PCA9685, 109
- adapter.i2cAdapter.PWM\_SN3218, 112
- adapter.i2cAdapter.Touch\_MPR121, 121
- adapter.iotAdapter.MQTT\_Adapter, 101
- adapter.linux.Linux\_Adapter, 93
- adapter.linux.Linux\_APLAY\_Adapter, 93
- adapter.linux.Linux\_ARECORD\_Adapter, 94
- adapter.linux.Linux\_ASR\_Adapter, 94
- adapter.mcp23s17.MCP23S17\_Adapter, 97
- adapter.microdotAdapter.Microdot\_Adapter, 99
- adapter.minecraftAdapter.MinecraftAdapter, 100
- adapter.openweathermapAdapter.Openweathermap\_Adapter, 103
- adapter.pigpiodAdapter.HC\_SR04\_Adapter, 91
- adapter.pigpiodAdapter.Pigpiod\_DHT11\_Adapter, 108
- adapter.pigpiodAdapter.Pigpiod\_PWM\_Adapter, 108
- adapter.remote.CommunicationAdapter, 77
- adapter.scrollphatHdAdapter.ScrollPhatHd\_Adapter, 116
- adapter.senseHat\_adapter.SenseHat\_Adapter, 117
- adapter.serialAdapter.PicoBoard\_Adapter, 106
- adapter.serialAdapter.RFID\_Reader\_Adapter, 115
- adapter.servoblaster.ServoBlaster, 119
- adapter.sonicpiAdapter.SonicPi\_Adapter, 120
- adapter.spiAdapter.MAX31855\_Adapter, 97
- adapter.spiAdapter.WS2801\_Adapter, 131
- adapter.stepper.BipolarStepper, 74
- adapter.stepper.UnipolarStepperModule, 124
- adapter.stepper.UnipolarStepperStep, 125
- adapter.textToSpeech.Festival\_Adapter, 79
- adapter.textToSpeech.Pico2Wave\_Adapter, 106

- adapter.twitterAdapter.Twitter\_Adapter, 123
- adapter.uinputAdapter.LIRC\_Adapter, 96
- adapter.usbAdapter.Blink\_Adapter, 75
- adapter.usbAdapter.HIDScanner\_Adapter, 91
- adapter.w1\_gpio.W1\_DS1820, 129
- adapter.websocket.WebsocketXY\_Adapter, 129
- adapter.wire\_gpio.Wire\_SHTx, 130
- state display, 12

## ADC

- ADS1015, 16
- atmel atmega328, 30
- MCP3008, 15
- MCP3202, 15
- PCF8591, 17
- arduino NANO, 38
- arduino UNO, 38, 43
- arduino UNO, LEGO POWERFUNCTIONS, 44

## B

- barcode scanner, 34
- barometric pressure sensor
  - BMP085, 16
- blink(1), 35
- broadcast events
  - scratch-startclicked, 23

## D

### DAC

- PCF8591, 17

### devices

- ADS1015, 16
- arduino NANO, 38
- arduino UNO, 38
- atmel atmega328, 30
- barcode scanner, 34
- BH1750, 16
- bipolar stepper motor, 11
- blink(1), 35
- BMP085, 16
- DS1820, 18
- DS18B20, 18
- ExplorerHat Pro, 57
- gpio, 10, 10
- GY-GPS6MV2, 38
- HC-SR04, 54
- HCSR04, 12
- L293 motor, 10
- LEGO POWERFUNCTIONS, 44
- LEGO WeDo 2.0 Adapter, 47
- linux aplay, 25
- linux arecord, 25
- Linux lirc, 27
- linux speechrecognition, 25
- MAX31855, 13
- MCP23S17, 13
- MCP3008, 15
- MCP3202, 15
- MPR121, 16
- Neopixel, 43
- Openweathermap, 46
- os-command, 24
- PCA9685, 17
- PCF8591, 17
- pi2go, 17, 57
- PIFACE, 13
- piGlow, 18
- remote communications, 19, 20
- rotary encoder, 12
- servo, 11, 17, 31, 32, 38
- servoblaster, 31
- seven segment display, 12

- SHT015, 12
- sim800, 36
- SN3218, 18
- telephone dial plate, 12
- text to speech, 24
- Twitter\_Adapter, 46
- unipolar stepper motor, 11
- usb, 34, 35
- WS2801 LED Stripe, 15
- WS2812, 43
- DHT11 temperature, humidity
  - atmel atmega328, 30
- DHT22 temperature, humidity
  - atmel atmega328, 30

## E

- ExplorerHat Pro, 57

## F

- frequency counter
  - atmel atmega328, 30

## G

- gpio
  - bipolar stepper motor, 11
  - button input, 10
  - hbridge motor, 10
  - input, 10, 10
  - marshmallow button input, 10
  - output, 10, 10
  - pwm output, 10
  - seven segment display, 12
  - unipolar stepper motor, 11
- GPS, 38
- gsm modem
  - sim800, 36
- GY-GPS6MV2, 38

## H

- HC-SR04, 54
- humidity sensor
  - SHT015, 12

## I

- ID-12LA, 36
- ID-20LA, 36
- ID-2LA, 36
- IoT MQTT, 19, 23
- IS31FL3730, 54
- IS31FL3731, 55

## L

- LED
  - WS2801 LED Stripe, 15
- LEGO POWERFUNCTIONS, 44
- LEGO WeDo 2.0 Adapter, 47
- linux aplay, 25
- linux arecord, 25
- linux speechrecognition, 25
- lirc, 27
- luminosity sensor
  - BH1750, 16

## M

- micro dot phat, 54
- minecraft, 56
- monitoring
  - gui, 58

mosquito, 19  
motor, 10  
MQTT, 19

## N

network  
  remote communications, 19, 20

## O

Openweathermap, 46  
operation  
  command line options, 62  
  custom config files, 62  
  installation, 60  
  logging, 63  
  logging desktop notifications, 64  
  quick installation guide, 60  
  start scratchClient, 62  
  stop scratchClient, 64  
os  
  system time, 24  
os-command, 24

## P

pi2go, 57  
picoBoard, 36  
pimoroni  
  MICRO DOT PHAT, 54  
  SCROLL PHAT HD, 55  
pocketsphinx, 25  
port expander  
  MCP23S17, 13  
PWM  
  PCA9685, 17  
  SN3218, 18

## R

remote control  
  Linux lirc, 27  
RFID, 36  
robot  
  pi2go, 57  
rotary encoder, 12

## S

scratch 1.4 sample  
  arduinoUNO, 40  
  lego\_powerfunctions, 45, 46  
  minecraft, 56  
  mqtt, 20, 20  
  neopixel, 44  
  pi2go, 57  
  pianoHat, 33  
  piglow, 18  
  scratchCommunicationServer, 22, 22  
  scrollphatd, 56  
  sensehat, 32  
  speechrecognition, 25  
  wedo2, 51  
  ws2801, 15  
ScratchBoard, 36  
scroll phatd, 55  
servo, 11, 17, 31, 32, 38  
servoblaster, 31  
smartphone positional sensor  
  websocket, 33  
Sonic Pi, 23  
sound, 23  
stepper motor  
  bipolar, 11

unipolar, 11

## **T**

telephone dial plate, 12

text to speech, 24

thermocouple

MAX31855, 13

thermometer

DS1820, 18

DS18B20, 18

MAX31855, 13

Touch

MPR121, 16

Twitter\_Adapter, 46

---

## Chapter 13. References

/rsp/ see [http://wiki.scratch.mit.edu/wiki/Remote\\_Sensors\\_Protocol](http://wiki.scratch.mit.edu/wiki/Remote_Sensors_Protocol)

/simon/ see <http://cymplecy.wordpress.com/2013/04/22/scratch-gpio-version-2-introduction-for-beginners/>

/silent/ „SILENT: un'interfaccia tra Scratch e LEGO NXT“, Luca Zenatti